

Three-phase power analyzer and power quality

CVMk2



USER's MANUAL

(M98206501-03-10A)



ADVERTENCIAS / SIMBOLOS

PELIGRO



Una conexión incorrecta del equipo puede producir la muerte, lesiones graves y riesgo de incendio. Lea y entienda el manual antes de conectar el equipo. Observe todas las instrucciones de instalación y operación durante el uso de este instrumento.

La instalación, operación y mantenimiento de este instrumento debe ser efectuado por personal cualificado solamente. El Código Eléctrico Nacional define a una persona cualificada como "una que esté familiarizada con la construcción y operación de equipo y con los riesgos involucrados".

ATENCIÓN



Consultar el manual de instrucciones antes de utilizar el equipo.

En el presente manual, si las instrucciones precedidas por este símbolo no se respetan o realizan correctamente, pueden ocasionar daños personales o dañar el equipo y /o las instalaciones.

WARNINGS / SYMBOLS

DANGER



Death, serious injury, or fire hazard could result from improper connection of this instrument. Read and understand this manual before connecting this instrument. Follow all installation and operating instructions while using this instrument.

Installation, operation, and maintenance of this instrument must be performed by qualified personnel only. The National Electrical Code defines a qualified person as "one who has the skills and knowledge related to the construction and operation of the electrical equipment and installations, and who has received safety training on the hazards involved."

ATTENTION **Consult the instruction manual before using the equipment.**



In this manual, if the instructions preceded by this symbol are not met or done correctly, can cause personal injury or equipment damage and / or facilities.

AVERTISSEMENT / SYMBOLES

DANGER



Un branchement incorrect de l'appareil peut entraîner la mort ou des lésions graves et peut provoquer un incendie. Avant de brancher votre appareil, lisez attentivement le manuel et assurez-vous de bien avoir compris toutes les explications données. Respectez toutes les instructions concernant le mode d'installation de l'appareil et son fonctionnement.

L'installation, le fonctionnement et la maintenance de cet appareil doivent être réalisés uniquement par du personnel qualifié. Le code électrique national définit en tant que personne qualifiée "toute personne connaissant le montage et le fonctionnement de l'appareil ainsi que les risques que ceux-ci comportent".

ATTENTION Consulter le manuel d'instructions avant d'utiliser l'appareil



Si les instructions suivantes, précédées dans le manuel d'un symbole, ne sont pas respectées ou sont réalisées incorrectement, elles pourront provoquer des dommages personnels ou abîmer l'appareil et/ou les installations

AVVERTENZE / SIMBOLI

PERICOLO



Un collegamento errato del dispositivo può provocare morte, lesioni gravi nonché rischio di incendio. Prima di collegare il dispositivo leggere attentamente il manuale. Osservare tutte le istruzioni relative all'installazione e all'operatività durante l'uso di questo strumento.

L'installazione, operatività e manutenzione di questo strumento devono essere realizzate solamente da personale qualificato. Il Codice Elettrico Nazionale definisce una persona qualificata come "colui che ha familiarità con la costruzione e operatività del dispositivo e con i rischi che ne possano derivare".

ATTENZIONE Consultare il manuale di istruzioni prima di utilizzare il dispositivo



Qualora le istruzioni riportate nel presente manuale precedute da questo simbolo non vengano osservate o realizzate correttamente, possono provocare danni personali o danneggiare il dispositivo e/o gli impianti.



WARNHINWEISE / SYMBOLE

GEFAHR



Durch einen nicht sachgemäßen Anschluss der Anlage können Tod, schwere Verletzungen und Brandrisiko hervorgerufen werden. Bevor Sie die Anlage anschließen, lesen Sie bitte das Handbuch durch und machen Sie sich dessen Inhalt klar. Beachten Sie bei Einsatz dieses Instrumentes sämtliche Installations- und Betriebshinweise.

Installation, Betrieb und Wartung dieses Instrumentes müssen ausschließlich von entsprechend qualifiziertem Personal vorgenommen werden. Von dem nationalen Elektrocode wird eine qualifizierte Person als jemand definiert, "der mit der Konstruktion und dem Betrieb einer Anlage und der damit verbundenen Risiken vertraut ist".

ACHTUNG



Vor Inbetriebnahme der Anlage ist das Handbuch zu lesen.

Werden die in dem vorliegenden Handbuch mit diesem Symbol versehenen Hinweise nicht beachtet oder falsch verstanden, können Personenschäden und Schäden an der Anlage und/oder den Installationen verursacht werden.



ADVERTÊNCIAS / SÍMBOLOS

PERIGO



Uma ligação incorrecta do equipamento pode provocar a morte, lesões graves e risco de incêndio. Leia e compreenda o manual antes de ligar o equipamento. Observe todas as instruções de instalação e operação durante o uso deste aparelho.

A instalação, operação e manutenção deste aparelho devem ser levadas a cabo exclusivamente por pessoal qualificado. O Código Eléctrico Nacional define uma pessoa qualificada como "uma pessoa que se encontre familiarizada com a construção e operação do equipamento assim como com os riscos inerentes"

ATENÇÃO



Consultar o manual de instruções antes de utilizar o equipamento.

No presente manual, se as instruções que precedem este símbolo não forem respeitadas ou realizadas de forma correcta, podem ocorrer ferimentos pessoais ou danos no equipamento e/ou nas instalações.

INDICE MANUAL

1. INTRODUCTION

| | |
|---------------------------------------|----|
| 1.1 DESCRIPTION..... | 11 |
| 1.2 TYPES AVAILABLE | 12 |
| 1.3 EXPANSION CARDS | 13 |
| 1.4 CODING FOR OTHER PARAMETERS | 13 |
| 1.5 ANALYSIS PARAMETERS | 14 |
| 1.6 ACCESORIES..... | 14 |

2. INSTALLATION

| | |
|---|----|
| 2.1 ITEMS TO VERIFY UPON RECEPTION..... | 15 |
| 2.2 ASSEMBLY SITE..... | 15 |
| ENVIRONMENTAL CONDITIONS..... | 15 |
| CONSIDERATIONS | 15 |
| 2.3 INSTALLATION METHODS | 16 |
| 2.3.1 PROCEDURE | 16 |
| 2.4 SYSTEM CONNECTION | 18 |
| 2.4.1 AUXILIARY POWER SUPPLY..... | 18 |
| 2.4.2 RATED VOLTAGE IN VOLTAGE MEASURING CIRCUIT..... | 18 |
| 2.4.3 RATED CURRENT IN CURRENT MEASURING CIRCUIT..... | 18 |
| 2.4.4 WORKING CONDITIONS..... | 18 |
| 2.4.5 SAFETY | 19 |
| 2.4.6 TECHNICAL FEATURES..... | 19 |
| 2.5 TERMINALS DESCRIPTION | 20 |
| 2.5.1 TAG FOR VOLTAGE AND CT CONNECTIONS..... | 20 |
| 2.5.2 POWER SUPPLY AND COMMUNICATIONS TAG | 20 |
| 2.6 MEASURING INPUT CONNECTION DIAGRAMS | 21 |
| 2.6.1 - 4 CT AND 5 VOLTAGE REFERENCES..... | 21 |
| 2.6.2 - 4 CT AND 4 VOLTAGE REFERENCES..... | 21 |
| 2.6.3 - 3 CT AND 4 VOLTAGE REFERENCES..... | 22 |
| 2.6.4 - 3 CT AND 3 VOLTAGE REFERENCES..... | 22 |
| 2.6.5 - 4 CT AND 2 VOLTAGE TRANSFORMERS | 23 |
| 2.6.6 - 3 CT AND 2 VOLTAGE TRANSFORMERS | 23 |

| | |
|---|-----------|
| 2.6.7 - 2 CT AND 2 VOLTAGE TRANSFORMERS | 24 |
| 2.7 POWER SUPPLY CONNECTION DIAGRAM..... | 24 |
| 3. OPERATION | |
| 3.1 DESCRIPTION OF DEVICE | 25 |
| 3.1.1 FRONTAL VIEW | 25 |
| 3.1.1.a. Display | 26 |
| 3.1.1.b. Function buttons | 26 |
| 3.1.1.c. Navigation buttons | 26 |
| 3.1.1.d. <i>SET</i> button | 26 |
| 3.1.1.e. Upper and lower menus | 26 |
| 3.1.1.f. Module name | 27 |
| 3.1.1.e. Icons | 27 |
| 3.2. START-UP..... | 28 |
| 4. CONFIGURATION | |
| 4.1 MEASURING | 29 |
| 4.2. QUALITY | 30 |
| 4.2.1. QUALITY..... | 31 |
| 4.2.2. EVENTS..... | 32 |
| 4.3. DEMAND | 34 |
| 4.4 TARIFFS | 35 |
| 4.5 DELETE | 36 |
| 4.6 COMMUNICATIONS..... | 37 |
| 4.7 EXPANSION CARDS | 38 |
| 4.7.0. INSERTING EXPANSION CARDS | 38 |
| 4.7.1. 8 DIGITAL INPUTS AND 8 DIGITAL OUTPUTS | 40 |
| 4.7.1.1. Alarm configuration..... | 41 |
| 4.7.1.2. Digital outputs configuration | 43 |
| 4.7.1.3. Digital inputs configuration | 44 |
| 4.7.1.4. Expansion card parameters | 46 |
| 4.7.1.5. Features | 46 |
| 4.7.2 - 8 DIGITAL INPUTS AND 4 RELAY OUTPUTS | 47 |
| 4.7.2.1. Alarm configuration..... | 48 |

| | |
|--|----|
| 4.7.2.2. Relay outputs configuration..... | 50 |
| 4.7.2.3. Digital inputs configuration | 51 |
| 4.7.2.4. Card Connections..... | 52 |
| 4.7.2.5. Expansion card parameters | 53 |
| 4.7.2.6. Features | 53 |
| 4.7.3 - 8 ANALOGUE INPUTS AND 4 ANALOGUE OUTPUTS | 54 |
| 4.7.3.1. Analogue outputs configuration..... | 55 |
| 4.7.3.2. Analogue inputs codes | 56 |
| 4.7.3.3. Analogue inputs configuration | 57 |
| 4.7.3.4. Expansion card parameters | 59 |
| 4.7.3.5. Features | 59 |
| 4.7.4 - ETHERNET AND SD MEMORY..... | 60 |
| 4.7.4.1. Network and communications Protocol..... | 61 |
| 4.7.4.2. IP Address Configuration..... | 61 |
| 4.7.4.3. SD card configuration..... | 63 |
| 4.7.4.4. SD Card parameters | 63 |
| 4.7.4.5. Expansions card icons | 64 |
| 4.7.4.6. Ethernet card features..... | 64 |
| 4.7.5 - SD MEMORY | 65 |
| 4.7.5.1. SD Card configuration | 65 |
| 4.7.5.2. SD card parameters | 66 |
| 4.7.5.3. Expansion card icons | 67 |
| 4.7.5.4. Ethernet output features..... | 67 |
| 4.7.6 - 4 \pm 5 MA ANALOGUE AND STATIC OUTPUTS | 68 |
| 4.7.6.1. \pm 5 mA analog outputs card configuration..... | 68 |
| 4.7.6.2. \pm 5 mA analog outputs configuration..... | 69 |
| 4.7.6.3. Alarm configuration..... | 69 |
| 4.7.6.4. Static outputs configuration | 71 |
| 4.7.6.5. Outputs wiring..... | 71 |
| 4.7.6.6. Technical Features | 72 |
| 4.7.7 - PROFIBUS COMMUNICATIONS CARD..... | 73 |
| 4.7.7.1. Profibus card configuration..... | 73 |

| | |
|--|----|
| 4.7.7.2. Card parameters..... | 73 |
| 4.7.7.3. Slave number configuration..... | 74 |
| 4.7.7.4. Leds information..... | 75 |
| 4.7.7.5. Profibus connector..... | 75 |
| 4.7.7.6. GSD Modules | 76 |

5. OTHER SYSTEM CONFIGURATIONS

| | |
|---------------------------------|-----------|
| 5.1 PREFERENCES | 77 |
| 5.1.1 SCREEN..... | 77 |
| 5.1.2 CLOCK / TEMPERATURE | 78 |
| 5.1.3 SECURITY..... | 79 |
| 5.2. TOOLS..... | 80 |
| 5.2.1 DEVICE..... | 80 |
| 5.3 MODULES | 81 |
| 5.3.1 LIST | 81 |
| 5.3.2 SETUP..... | 83 |

6. DISPLAY SCREENS

| | |
|--|-----------|
| 6.1 MEASURING | 84 |
| 6.1.1 MAIN..... | 84 |
| 6.1.1.1. System information..... | 84 |
| 6.1.1.2. Maximums | 87 |
| 6.1.1.3. Minimums | 88 |
| 6.1.2 PHASE-NEUTRAL VOLTAGE | 89 |
| 6.1.2.1. Voltage waveform display..... | 90 |
| 6.1.2.2 Voltage phasors display | 91 |
| 6.1.3 PHASE-PHASE VOLTAGE..... | 92 |
| 6.1.4 CURRENT | 93 |
| 6.1.4.1. Current waveform display..... | 94 |
| 6.1.4.2 Current phasors display | 95 |
| 6.1.5 POWERS | 96 |
| 6.1.5.1 Active power | 96 |
| 6.1.5.2 Inductive Power | 96 |
| 6.1.5.3 Capacitive Power..... | 97 |

| | |
|--|------------|
| 6.1.5.4 Apparent Power..... | 98 |
| 6.1.5.5 Total Power..... | 99 |
| 6.1.6, POWER FACTOR | 100 |
| 6.1.7 COS φ | 100 |
| 6.2. DEMAND | 103 |
| 6.3 ENERGY | 104 |
| 6.3.1 PRESENT ENERGY | 104 |
| 6.3.2 MONTH ENERGY | 105 |
| 6.3.3 YEARLY ENERGY..... | 105 |
| 6.4 EXPANSION CARDS | 106 |
| 6.4.1 CARD WITH 8 DIGITAL INPUTS / 8 OUTPUTS | 106 |
| 6.4.2 CARD WITH 8 RELAY INPUTS / 4 OUTPUTS..... | 107 |
| 6.4.3 CARD WITH 8 ANALOGUE INPUTS / 4 OUTPUTS | 107 |
| 6.4.4 SD-ETHERNET AND SD MEMORY CARD | 108 |
| 6.4.5 SD MEMORY CARD | 108 |
| 6.4.6 ANALOGUE ± 5 MA AND STATIC OUTPUTS CARD..... | 109 |
| 6.4.7 PROFIBUS COMMUNICATIONS CARD | 110 |
| 7. QUALITY | |
| 7.1 HARMONICS..... | 111 |
| 7.1.1 VOLTAGE THD..... | 112 |
| 7.1.2 CURRENT THD..... | 113 |
| 7.1.3 VOLTAGE HARMONICS | 114 |
| 7.1.4 CURRENT HARMONICS | 116 |
| 7.2. DISTURBANCES | 118 |
| 7.2.1 FLICKER | 118 |
| 7.2.1.1 PST Calculation | 119 |
| 7.2.1.2 Real Time Weighted Average Calculation | 119 |
| 7.2.2 K FACTOR | 120 |
| 7.2.3 UNBALANCE AND ASYMMETRY | 121 |
| 7.2.4 CREST FACTOR | 122 |
| 8. COMMUNICATIONS | |
| 8.1. MODBUS/RTU PROTOCOL ©..... | 123 |

| | |
|--|------------|
| 8.2. CONNECTION DIAGRAM..... | 124 |
| 8.2.1. CIRCUTOR INTELLIGENT CONVERTER | 124 |
| 8.2.2. TCP2RS CONVERTER | 125 |
| 8.2.3. USB CONVERTER..... | 126 |
| 8.2.4. SCREEN-MODULES COMMUNICATIONS BUS | 127 |
| 8.3. MODBUS/RTU © MEMORY MAP | 128 |
| 8.3.1. ELECTRIC VARIABLES | 128 |
| 8.3.2. CURRENT ENERGY VARIABLES | 131 |
| 8.3.3. ENERGY VARIABLES FROM PREVIOUS PERIODS | 133 |
| 8.3.4. ENERGY VARIABLES FOR THE PREVIOUS YEAR | 135 |
| 8.3.2. MAXIMUM DEMAND VARIABLES | 137 |
| 8.3.6. VOLTAGE HARMONICS VARIABLES..... | 139 |
| 8.3.7. CURRENT HARMONICS VARIABLES | 140 |
| 8.3.8. DIGITAL INPUT EXPANSION CARD VARIABLES..... | 141 |
| 8.3.9. ANALOGUE INPUT EXPANSION CARD VARIABLES | 142 |
| 8.4. RS-485 NETWORK FEATURES | 143 |
| 9 . MAINTENANCE AND CALIBRATION | |
| 9.1 MAINTENANCE..... | 143 |
| 10. FEATURES | |
| 10.1. STANDARDS..... | 144 |
| 10.2. TECHNICAL FEATURES | 144 |
| 10.3. OTHER CONCEPTS | 146 |
| 10.3.1 UNBALANCE COEFFICIENT (KD) | 146 |
| 10.3.1 ASYMMETRY COEFFICIENT (KA) | 146 |
| 10.3.3 FLICKER..... | 146 |
| 10.3.4. K FACTOR..... | 147 |
| 10.3.5. CREST FACTOR | 147 |
| 11. SOFTWARE | |
| 11.1 POWER STUDIO SCADA. | 149 |

1. INTRODUCTION

This manual is intended to be used as a guide in the installation, configuration and operation of the **CVMk2** network analyzer, for optimising the system's benefits. Read with attention and follow the warnings and symbols.

1.1 DESCRIPTION



CVMk2 measures, calculates and displays the primary electric parameters in balanced or unbalanced three-phase industrial networks.

True RMS values are measured using three alternating voltage inputs, two voltage references (neutral and ground), and four current inputs to measure secondaries .../1A or .../5A, coming from the outside current transformers. It should be considered that when secondary .../1 is selected, the calculation is made by the software.

The **CVMk2** network and power supply quality analyzer is a programmable measuring instrument. It offers a wide variety of uses, which can be selected from the instrument's configuration menus. Prior to using the analyzer, read the following sections carefully: power supply, connection and configuration. Then, choose the best operating method for obtaining the desired data.

CVMk2 permits viewing the electric parameters on a backlit 1/4 VGA graphical display. Real time, maximum or minimum electric parameters can be viewed by pressing the corresponding key. Internal processor shows more than 500 electric parameters via the display screen and communication. Said parameters may be fed from a single or three phase system.

CVMk2 has the following important features:

- Outside dimensions 144x144x116 mm.
- Mounted on a DIN rail (measurement module) with display screen on panel (96x96 mm, 144x144 mm or 103 mm (4") diameter hole).
- True RMS value (TRMS) measurement.
- Class 0,2 or 0,5 in Power and Energy (*).
- Real time, maximum and minimum values for each parameter with date and time.
- 1/4 VGA graphical display.
- RS-485 (Modbus/RTU©) communication incorporated.
- Possible to configure the display screen as the MASTER for 32 measurement modules.
- Multi-tariff equipment (allows to program up to 9 tariff)
- Memory of present, month and annual energy consumed and generated.
- Graphical display of wave forms and voltage and current phasors.
- 8 digit (100 GW·h) counter to track energy consumed and energy generated.
- Recording of power supply quality events on voltage.
- Expandable with inputs/outputs expansion card.
- Implemented in the **CIRCUTOR** energy management software, **PowerStudio Scada**.
<http://powerstudio.circutor.com>

(*) Depending on the model



CVMk2 has no battery. When supply falls down the analyzer do not store electrical parameters and no quality events. Is very important to guarantee the supply of the device from an interrupted source (Battery, SAI, ...)

1.2 TYPES AVAILABLE

| CODE | TYPE | VALID FOR .../5 AND .../1 A TRANSFORMERS | THREE PHASE 50...60HZ | TRUE RMS VALUE (TRMS) | INSULATED CURRENT INPUTS ITF | COMMUNICATION PORTS (*) | EXPANSION SLOTS | ANALYSIS OF VOLT & CURR (50°) HARMONICS. | DISTURBANCE DETECTION | MULTI-TARIFF EQUIPMENT (9 TARIFF) | 4 QUADRANTS | VOLTAGE AND CURRENT WAVE FORMS | CLASS 0.5 (POWER AND ENERGY) | CLASS 0.2 (POWER AND ENERGY) | NETWORK PROTOCOL | COMMUNICATION PROTOCOL |
|--------|---------------|--|-----------------------|-----------------------|------------------------------|-------------------------|-----------------|--|-----------------------|-----------------------------------|-------------|--------------------------------|------------------------------|------------------------------|------------------|------------------------|
| M54400 | CVMk2-ITF-405 | • | • | • | • | 2 | 3 | • | • | • | • | • | • | | RS485 | Modbus-RTU |
| M54402 | CVMk2-ITF-402 | • | • | • | • | 2 | 3 | • | • | • | • | • | | • | RS485 | Modbus-RTU |

Measurement modules (without display)

| | | | | | | | | | | | | | | | | |
|--------|-----------------|---|---|---|---|---|---|---|---|---|---|---|---|---|-------|------------|
| M54410 | M-CVMk2-ITF-405 | • | • | • | • | 2 | 3 | • | • | • | • | • | • | | RS485 | Modbus-RTU |
| M54412 | M-CVMk2-ITF-402 | • | • | • | • | 2 | 3 | • | • | • | • | • | | • | RS485 | Modbus-RTU |

(*) COM1 to communicate only with the display and COM2 bus RS-485 Modbus/RTU



To insure the system class, it is recommended to use type TCH high precision transformers. See the M7 family of current transformers.

1.3 EXPANSION CARDS

CVMk2 has a wide range of expansion cards that enable users to interact with the system or to communicate with other protocols. The expansion cards and corresponding codes are in the following table

| CODIGO | I/O | DESCRIPCIÓN |
|--------|-----------------------------------|--|
| M54501 | 8I/8O | 8 opto-coupled digital inputs |
| | | 8 optocoupled transistor digital outputs |
| M54502 | 8I/4O | 8 analogue inputs (0/4...20 mA) |
| | | 4 analogue outputs (0/4...20 mA) |
| M54503 | 8I/4O | 8 opto-coupled digital inputs |
| | | 4 relay outputs (3 NO + 1 NO/NC) |
| M54504 | Ethernet (Modbus/TCP) + SD Memory | |
| M54506 | SD Memory | |
| M54507 | 4O/4O | 4 analogue outputs of $\pm 5\text{mA}$ |
| | | 4 opto-coupled digital outputs |
| M5450A | Profibus DP | |

1.4 CODING FOR OTHER PARAMETERS

For coding attributes or special features or power measuring equipment, or as modules, you must use the following encoding table.

| M | 5 | 4 | X | X | X | 0 | 0 | X | X | X |
|----------------------------------|--|---|---|---|---|---------------|---|---|---|---|
| Code | | | | | | Internal code | | | | |
| Voltage supply (High Voltage) | 85 ... 265 V a.c. 100 ... 300 V c.c | | | | | | 0 | | | |
| | SDC 24...90 V c.c | | | | | | 8 | | | |
| Voltage measured (TM) | Standard 300 / 520 V a.c | | | | | | | | 0 | |
| | 63,5 / 110 V a.c. (*) | | | | | | | | 1 | |
| | 500 / 866 V a.c. | | | | | | | | 3 | |
| Current input | exterior ITF (WG20) | | | | | | | | | 3 |

(*) The extent to voltage 110 Vac and / or measured using external transformers WG20 measuring transformer secondary is only possible in the measurement module 402, model code M54412. **If asked this particular module should know that the display is not included and must be requested separately. (see paragraph 1.6 ACCESSORIES)**

1.5 ANALYSIS PARAMETERS

| PARAMETER | UNIT | L1 | L2 | L3 | N | III |
|---|---------------|----|----|----|---|-----|
| Ph-N VOLTAGE | V | • | • | • | • | • |
| Ph-Ph VOLTAGE | V | • | • | • | | • |
| CURRENT | A | • | • | • | • | • |
| FREQUENCY | Hz | • | | | | |
| ACTIVE POWER (Consumption and Generation) | kW | • | • | • | | • |
| INDUCTIVE POWER (Consumption and Generation) | kvar L | • | • | • | | • |
| CAPACITIVE POWER (Consumption and Generation) | kvar C | • | • | • | | • |
| APPARENT POWER (Consumption and Generation) | kV·A | • | • | • | | • |
| POWER FACTOR | PF | • | • | • | | • |
| COS φ | Cos φ | • | • | • | | • |
| MAXIMUM ACTIVE POWER DEMAND | Pd | | | | | • |
| MAXIMUM APPARENT POWER DEMAND | Pd | | | | | • |
| MAXIMUM CURRENT DEMAND | Pd | • | • | • | | • |
| NEUTRAL LINE CURRENT | I_N | | | | | |
| VOLTAGE THD (RMS AND FUNDAMENTAL) | U_{THD} | • | • | • | • | |
| CURRENT THD (RMS AND FUNDAMENTAL) | I_{THD} | • | • | • | • | |
| VOLTAGE HARMONICS 2 nd ...50 th | harm V | • | • | • | • | |
| CURRENT HARMONICS 2 nd ...50 th | harm A | • | • | • | • | |
| ACTIVE ENERGY (Consumption and Generation) | kW·h | | | | | • |
| INDUCTIVE ENERGY (Consumption and Generation) | kvar·h L | | | | | • |
| CAPACITIVE ENERGY (Consumption and Generation) | kvar·h C | | | | | • |
| APPARENT ENERGY (Consumption and Generation) | kV·A·h | | | | | • |
| TOTAL ACTIVE ENERGY and Tariff (Consum. and Gen.) | kW·h | | | | | • |
| TOTAL INDUCT. ENERGY and Tariff (Consum. and Gen.) | kvar·h L | | | | | • |
| TOTAL CAPAC.. ENERGY and Tariff (Consum. and Gen.) | kvar·h C | | | | | • |
| TOTAL APPARENT ENERGY and Tariff (Consum. and Gen.) | kV·A·h | | | | | • |
| FLICKER (WA and PST) | Wa / Pst | • | • | • | | |
| K-FACTOR (current) | | • | • | • | | |
| CREST FACTOR (voltage) | | • | • | • | | |
| UNBALANCE (voltage and current) | | • | • | • | | |
| ASYMMETRY (voltage and current) | | • | • | • | | |
| SCREENS PARAMETERS | | | | | | |
| PHASE DIFFERENCE BETWEEN VOLTAGES | | | | | | |
| PHASE DIFFERENCE BETWEEN CURRENTS | | | | | | |
| DIFFERENCE BETWEEN VOLTAGES AND CURRENTS | | | | | | |
| WAVEFORMS | | • | • | • | | |
| PHASORS | | • | • | • | | |

1.6 ACCESORIES

| CODE | DESCRIPTION |
|---------------|--------------------|
| M5ZZH1 | Connector of CVMk2 |
| M54420 | Display of CVMk2 |

2. INSTALLATION

This manual provides information and warnings that the user should heed to guarantee that the system operates safely and is kept in good conditions for safe use.



If the system is handled in a way contrary to the manufacturer's specifications, it may not be protected.

2.1 ITEMS TO VERIFY UPON RECEPTION

Verify the following upon receiving the instrument:

- The device meets specifications in the order.
- The device was not damaged during transport.
- The instrument comes with the quick guide and/or the user's manuals.



In order to safely use the **CVMk2**, the personnel in charge of installing or handling it must follow the standard safety guidelines and heed all warnings provided in the instruction manual.

This analyzer should be installed and maintained by qualified personnel.

2.2 ASSEMBLY SITE

ENVIRONMENTAL CONDITIONS

To guarantee its optimal operation, it is recommended to use the system at between -10 and 40 °C with relative humidity between 5 and 95%, but with no condensation. Temperature range **according UL**. In internal testing until 50 °C

CONSIDERATIONS

The **CVMk2** should be mounted in a distribution cabinet that protects the system from environmental contamination such as oil, moisture, dust, corrosive vapours or other volatile substances.





When it is likely that the system has lost its safety guards (due to visible damages), it should be disconnected from the auxiliary power supply and the input supplies. In this case, contact a qualified tech support.

The system can be installed in one of two basic ways:


- As a compact system in a distribution cabinet, installing at the panel.
- As a modular system, installing the display on the panel and the measuring module on DIN 46277 (EN 50022) rail.

2.3 INSTALLATION METHODS

The figures illustrate the different installation possibilities, permitted by the display screen design. The system design facilitates screwing the panel on ($92^{+0.8} + 92^{+0.8}$ mm, $138^{+0.8} + 138^{+0.8}$ mm and a 103 mm diameter hole).




Picture 3




The figures illustrate how to mount the front part (display) in a 92x92 mm (3,62 x 3,62 in) hole, a 103 mm (4,06 in) diameter hole and in a 138x138 mm (5,43 in) hole.

After inserting the front part, install the mount ring, making sure that the tabs are not blocked (see procedure). Also, assure that the white arrow, which indicates the point where the communications cable and the RJ-45 display screen power supply cable run out, lines up with the arrow on the measuring equipment.

2.3.1 PROCEDURE




The tabs are components used to fasten the system to the panel. When mounting the system, the tabs must be free, and unblocked, so that as pressure is applied to the mount ring the tabs go over the clamp zipper teeth. Similarly, to dismount the panel display the tabs should be blocked, i.e. opened prior to dismounting.




A zoomed view of the previous image is provided in the figure. It provides a detailed view of the movements necessary to lock and unlock **CVMk2** display screen mount ring.

As shown in the figure, the guide arrow should point upward and line up with the arrow found on the rear of the viewer or display screen. The arrow points to the position where the RJ-45 communications cable and the display screen power supply cables run out.



The mount diagram is shown in the following figure. The measuring unit can then be mounted on the ring behind the display screen, or it can be installed on a DIN rail and communicate with the display screen via a communication cable and transparent RJ-45 power supply. (See Table 3.1, physical description).



To install the screen in a panel as shows the 2.3 installations methods, you have to use a flat surface of a type 1 enclosure.

2.4 SYSTEM CONNECTION

Before connecting the equipment, the following points should be verified:

- 2.3.1 Auxiliary Power Supply Features
- 2.3.2 Maximum Voltage in the Voltage Measuring Circuit
- 2.3.3 Maximum Current in the Current Measuring Circuit
- 2.3.4 Working Conditions
- 2.3.5 Safety

2.4.1 AUXILIARY POWER SUPPLY

| | | |
|-----------------------|-----------|--------|
| Standard power supply | 85...265 | V a.c. |
| | 100...300 | V d.c. |
| Frequency | 50...60 | Hz |
| Optional power supply | 24...90 | V d.c. |

2.4.2 RATED VOLTAGE IN VOLTAGE MEASURING CIRCUIT

| | | |
|--|-----------|---------------------|
| Standard rated voltage (*) | 300 / 520 | V_{f-n} / V_{f-f} |
| Other voltages (*) | 500 / 866 | V_{f-n} / V_{f-f} |
| (*) <i>Current limited. Máximo 0.6 V·A</i> | | |

| | | |
|-----------------|---------------|----|
| Rated frequency | 45,00...65,00 | Hz |
|-----------------|---------------|----|

$$U_{\max} = U_N \times 1.2$$

2.4.3 RATED CURRENT IN CURRENT MEASURING CIRCUIT

| | | |
|-------------------------------|---|--------|
| Secondaries .../5A (*) | 5 | A a.c. |
| Secondaries .../1A (*) | 1 | A a.c. |
| (*) <i>limited in voltage</i> | | |

$$I_{\max} = I_N \times 1.2$$

2.4.4 WORKING CONDITIONS

| | | |
|-----------------------|-----------|----|
| Operating temperature | -10...+40 | °C |
| Relative Humidity | 5...95 | % |

2.4.5 SAFETY

Designed for CAT III 300/520 Vac installations in accordance with EN-61010.
Protected against electrical shock by class II double insulation.
Designed and identified by the distinctive CE marks.



To increase system capacity with expansion cards prior to handling, modify its connections or replace equipment; the power supply should be shut off and the inputs disconnected from the CVMk2. Handling the system while it is powered up is dangerous.

2.4.6 TECHNICAL FEATURES

| VOLTAGE INPUTS | |
|---------------------------------------|--|
| Measuring range | from 5 to 120% of U_n for $U_n = 300$ Vac (f-N) from 5 to 120% of U_n for $U_n = 520$ Vac (f-f) |
| Frequency | 45...65 Hz |
| Maximum measured voltage | 360 Vac |
| Acceptable overvoltage | 750 Vac |
| Maximum Consumption (limited current) | < 0.6 V·A |
| CURRENT INPUTS | |
| Measuring range | from 1 to 120% of I_n for $I_n = 5$ A |
| Secondary for the TCs (I_n) | 1 or 5 A |
| Primary current measured | Programmable < 30.000 A |
| Acceptable overload | 6 A continuous, 100 A $t < 1$ s |
| Consumption | < 0.45 V·A |
| AUXILIARY POWER SUPPLY | |
| Power supply | 85 to 265 V ac (50...60 Hz) (consumption < 30 V·A) 90 to 300 V dc (consumption < 25 W) |
| MECHANICAL | |
| Maximum torque | 0.8 Nm |
| Maximum wire rigid diameter | 4.5 mm ² (AWG 11) |



When the system is connected, it may be dangerous to touch the terminals. Additionally, dangerous parts may be exposed when covers are opened or when protective components are removed. The system should not be used until it is completely installed.

2.5 TERMINALS DESCRIPTION

2.5.1 TAG FOR VOLTAGE AND CT CONNECTIONS

P/N: 50627/1

Serial no. : 0430646001

CE
Made in EU


9 VL1 10 VL2 11 VL3 12 VREF 13 N

P-N 300V~ P-P 520V~ CAT III

Model : M-CVMk2-ITF-405
 Measuring Range: 300V~, (P-N), 5A~.
 Power Supply: 85-265 V~, 50/60 Hz, 30VA.
 100-300 V~, 25W.

| TERMINAL | DESCRIPTION |
|----------|---|
| 1 | Current transformer, L1 phase S1 connection |
| 2 | Current transformer, L1 phase S2 connection |
| 3 | Current transformer, L2 phase S1 connection |
| 4 | Current transformer, L2 phase S2 connection |
| 5 | Current transformer, L3 phase S1 connection |
| 6 | Current transformer, L3 phase S2 connection |
| 7 | Current transformer, neutral line S1 connection |
| 8 | Current transformer, neutral line S2 connection |
| 9 | L1 phase voltage input |
| 10 | L2 phase voltage input |
| 11 | L3 phase voltage input |
| 12 | Input voltage V_{REF} (GND) |
| 13 | Input voltage NEUTRAL LINE |


2.5.2 POWER SUPPLY AND COMMUNICATIONS TAG




The system should be connected to a power supply circuit protected by fuses with current ratings between 0.5 and 1 A / 600 V (UL listed). It should be provided with a MCCB or equivalent device to switch off the system from the power supply circuit. The power supply and voltage measuring circuit is connected with cable minimum cross section of 1 mm² (AWG 17). The current transformer secondary side connection line should have a minimum cross section of 2 mm² (AWG 14 Cu) and with a minimum temperature rating of 60 °C.

2.6 MEASURING INPUT CONNECTION DIAGRAMS


2.6.1 - 4 CT AND 5 VOLTAGE REFERENCES




2.6.2 - 4 CT AND 4 VOLTAGE REFERENCES




2.6.3 - 3 CT AND 4 VOLTAGE REFERENCES




2.6.4 - 3 CT AND 3 VOLTAGE REFERENCES




2.6.5 - 4 CT AND 2 VOLTAGE TRANSFORMERS




2.6.6 - 3 CT AND 2 VOLTAGE TRANSFORMERS



2.6.7 - 2 CT AND 2 VOLTAGE TRANSFORMERS



2.7 POWER SUPPLY CONNECTION DIAGRAM



The system should be connected to a power supply circuit protected by fuses with current ratings between 0.5 and 1 A / 600 V (UL listed). It should be provided with a MCCB or equivalent device to switch off the system from the power supply circuit. The power supply and voltage measuring circuit is connected with cable minimum cross section of 1 mm² (AWG 17). The current transformer secondary side connection line should have a minimum cross section of 2 mm² (AWG 14) and with a minimum temperature rating of 60 °C.

3. OPERATION

3.1 DESCRIPTION OF DEVICE

The external dimensions of the **CVMk2** network analyzer are 144 x 144 x 116 mm. It is comprised of a display screen and a measuring module. The display screen communicates with the measuring module via an RJ-45 line, which is "transparent" or direct. The wire layout is provided in the figure below:

| DISPLAY SCREEN | | MEASURING EQUIPMENT | |
|----------------|--------|---------------------|-----|
| PIN | SIGNAL | SIGNAL | PIN |
| 1 | V+ | V+ | 1 |
| 2 | GND | GND | 2 |
| 3 | B (-) | B (-) | 3 |
| 4 | Shield | Shield | 4 |
| 5 | Shield | Shield | 5 |
| 6 | A (+) | A (+) | 6 |
| 7 | GND | GND | 7 |
| 8 | V - | V - | 8 |

3.1.1 FRONTAL VIEW



The front is divided into several parts:

- a) Display screen.
- b) Function buttons.
- c) Navigation buttons.
- d) *SET* button.
- e) Upper and lower menus.
- f) Module name.
- g) Icons.

3.1.1.a. Display

The **CVMk2** network analyzer incorporates a 320 x 240 pixel, backlit, 1/4 VGA (QVGA) LCD monitor. The monitor surface area is 90 x 70 mm² (4,5 in). The display screen has backlighting to facilitate reading the parameters when they are presented on the display screen in poor lighting conditions.

CVMk2 allows program a timer to shut off the backlighting after several seconds have passed. Said timer can be programmed for 10, 90 or 180 seconds. It is also possible to leave the backlighting always ON or always OFF.

To access the display screen properties configuration menu, use the left navigation button to navigate to *MENU*. Use the *SET* button or the down arrow button to open the drop-down menu. Select *SYSTEM--PREFERENCES--DISPLAY SCREEN*.



WARNING: The maximum working temperature for the 1/4 VGA display screen is 40 °C. Operating the system above this temperature can quickly deteriorate the equipment or lead to permanent malfunctioning.

3.1.1.b. Function buttons

The system has 4 function buttons on the front side (F1, F2, F3 and F4). The function buttons are used to access the different menus that appear on the bottom of the display.

3.1.1.c. Navigation buttons

On the front side, the system has 4 arrow buttons used to navigate through the different menus that appear on the lower side of the screen. Press the left arrow button to exit at any time the current menu.

3.1.1.d. *SET* button

This button is used to access the menu that is selected with the cursor and to confirm any change before to press *OK* (F4). Is necessary to press *SET* to store any chage.




















3.1.1.e. Upper and lower menus

The upper and lower menus change based on the current screen. A detailed description of all the menus and the options in each menu is provided in the upcoming chapters.

3.1.1.f. Module name

The measuring module currently being viewed is defined on this part of the display screen. This is important in facilities where measuring modules are communicating with one single display screen.

3.1.1.e. Icons

-  Editable configuration menu (without password).
-  Configuration menu locked with password.
-  None of the voltages for the phases are connected, or they are not detected.
-  Voltage is only detected at the phase 1 input.
-  Voltage is only detected at the phase 2 input.
-  Voltage is only detected at the phase 3 input.
-  Voltage is only detected at the phase 1 and 2 inputs.
-  Voltage is only detected at the phase 1 and 3 inputs.
-  Voltage is only detected at the phase 2 and 3 inputs.
-  Voltage is detected at the phase 1, 2 and 3 inputs.
-  Correct SD memory status.
-  Incorrect SD memory status.
-  Extraction of SD card enabled.
-  Short circuit or hole detected. This only appears during the event.
-  Overvoltage detected. This only appears during the event.
-  Switching detected. This only appears during the event.
-  There is no consumption and no generation.
-  Generation
-  Consumption.

3.2. START-UP



Before power ON the device, make sure that all the cables are properly connected. A bad connection can cause serious injuries to the personnel that are working on the equipment and can damage the equipment.

When power supply is connected to the **CVMk2**, the system will show an initial presentation and initialize its internal software indicating the firmware version on the display screen. After a time of searching, it will also display the firmware versions of the modules that are connected to the COM 1 DISPLAY port as well as the cards that are inserted in each one of the modules.

Once initialization is complete, the **CVMk2** will display the switched module's real time values on the main screen.

The **CVMk2** principal screen changes. This is because the system will keep a memory the last screen that was viewed for more than 20 seconds before disconnected. This screen will be displayed the next time the display is turn on except if it is an expansion card screen. They are not stored in memory.



Once the CVMk2 has been installed, is recommended to restart the meter and the maximums and minimums of the device. It is possible that the installation process will produce some recorded parameters outside the range of normal working and subsequently affect the display of records in graphs or tables.


4. CONFIGURATION



The analyzer does not store programming changes that are made until programming is complete. These changes are confirmed by pressing *SET* and after the *OK* button. If the system is reset before said programming is complete or if the user exits the menu using the *ESC* button, the configuration settings will not be stored in memory. To access to the configuration menu, refer to Chapter 4.


Measurement, communication and expansion card parameters (if available) can be modified from the configuration menu.

To access the configuration inside the *MENU*, select *SETUP* and confirm with the *SET* key. The menu on the top of the screen will appear as seen in the following figure.



4.1 MEASURING

In the *MEASURE* menu, the list of voltage and current transformers can be accessed. To modify the transformer configuration parameters, press the *EDIT* button (F4).



Position the cursor in the first line of parameters (primary voltage). Use the up-down arrow buttons to move the cursor to the desired parameter. Press *SET* to enter the numeric value to be modified. The cursor will be positioned over the first digit, corresponding to the largest value. Use the left/right arrow buttons to navigate from one digit to another and the up/down arrow buttons to increase/decrease the value of the digit.

| Menu | Measure | Comm. | Exp. Card |
|----------------|-----------|-------|-----------|
| Measure | Tran. Rel | | |
| Prim. U | | | 000001 |
| Sec. U | | | 001 |
| Prim. I | | | 83050 |
| Prim. In | | | 83050 |
| Sec. I | | | 180 |

Parameters that can be configured on this screen follow:

- **PRIM. U:** Primary on the voltage transformers. If it does not exist, program 1. The maximum configurable value is 999999.
- **SEC. U:** Secondary on the voltage transformers. If it does not exist, program 1. The maximum configurable value is a 3 digit number 999.
- **PRIM. I:** Primary on the current transformer. The maximum configurable value is 30000.
- **PRIM. In:** Primary on the current transformer for the neutral line. The maximum configurable value is 30000.
The default value is 5. If it is desirable for the **CVMk2** to show the neutral line current that is calculated, configure 0.
- **SEC. I:** Secondary on the current transformer. It is possible to program 5 or 1.

To store the modified parameters in memory, press **SET** and confirm with **OK** (F4). To exit without saving changes press **ESC** (F3).



WARNING: The CVMk2 power calculation is limited according to the following ratio:



$$(\text{Prim V}) \times (\text{Prim I}) < 45.000.000$$

4.2. QUALITY

To access the power supply quality parameters configuration screen, position the cursor over **QUALITY** and press **SET**. Two options are provided in the quality menu, **QUALITY** and **EVENTS**.




CVMk2 has no battery. When supply falls down the analyzer do not store electrical parameters and no quality events. Is very important to guarantee the supply of the device from an interrupted source (Battery, SAI, ...)



4.2.1. QUALITY

To access the quality parameters configuration menu, go to the *QUALITY* menu, in the main configuration menu, and select *QUALITY*. From the two options provided, select *QUALITY*. Parameters that can be configured on this screen are:



- **THD CALC:** To calculate the harmonic distortion rate based on the fundamental, select *FUND*. Select *RMS* to make the calculation based on the RMS value.
- **PERIOD:** Enter the desired period for the registration of the variables. Must be between 1 and 240 minutes. If no memory card available this period applies to the calculation of flicker and STD. If one card SD external memory expansion, this period is only to the calculation of flicker. The registration of STD is managed by the Power Studio. Means setup time period (minutes) of the window of integration.
- **NOM. FREQ.:** Enter the network rated frequency value. This is used in the flicker calculation.

- *NOM. V*: Enter the network rated phase-neutral voltage value. If using a voltage transformer, enter the transformer secondary value. If there is no neutral line, enter the voltage value as if there was one. This is used for quality events calculations.

To modify the current values, press *EDIT* (F4). The cursor will be positioned in the first line of parameters. Use the up-down arrow buttons to move the cursor to the desired parameter. Press *SET* to enter the corresponding numeric value.

Position the cursor over the first digit, corresponding to the largest value. Use the left/right arrow buttons to navigate from one digit to another and the up/down arrow buttons to increase/decrease the value of the digit where the cursor is currently positioned.

To store the modified parameters in memory, press *SET* and confirm with *OK* (F4). To exit without saving changes press *ESC* (F3).



If values entered are not within the acceptable range or are not valid, the modifications will not be recorded. The values used prior to the modification will be restored.

4.2.2. EVENTS

To access the event margins configuration menu, go to the *MEASURE* menu in the main configuration menu. Then, select *EVENTS* in the quality *MENU*.

Parameters configured on this screen are in % with respect to the *NOM. V* from the previous screen (*QUALITY*).

Thus, the % value that should be configured for the overvoltage threshold must always be greater than 100% of the value configured for the *NOM V* variable on the previous screen (4.2.1. *QUALITY*).

| Menu | Measure | Comm. | Exp. | Card |
|--------------------------|---------|----------------------|------|------|
| Measure Quality » Events | | | | |
| Swell Thr. | | 110.0 | | |
| Sag Thr. | | 090.0 | | |
| Inter.Thr. | | 010.0 | | |
| Swell Hys. | | 002.0 | | |
| Sag Hys. | | 002.0 | | |
| Inter.Hys. | | 002.0 | | |
| [] [] [] | | EDIT [] [] [] [] | | |

To modify the current values, press *EDIT* (F4). The cursor will be positioned in the first line of parameters. Use the up-down arrow buttons to move the cursor to the desired parameter. Press *SET* to enter in the corresponding numeric value.

The cursor will be positioned over the first digit, corresponding to the largest value. Use the left/right arrow buttons to navigate from one digit to another and the up/down arrow buttons to increase/decrease the value of the digit where the cursor is currently positioned.

To save the modified parameters to memory, press *OK* (F4) before exiting. If saving the changes is not desired, press *ESC* (F3).


Parameters that can be configured on this screen are:

- *SWELL THR*: This corresponds to the threshold value, in %, to detect an overvoltage event.
- *SAG THR*: This corresponds to the threshold value, in %, to detect a hole event.
- *INTER. THR*: This corresponds to the threshold value, in %, to detect a short circuit event.
- *SWELL HYS*: Hysteresis, in %, over the programmed value in the detection threshold.
- *SAG HYS*: Hysteresis, in %, over the programmed value in the detection threshold.
- *INTER. HYS*: Hysteresis, in %, over the programmed value in the detection threshold.



The value of the hysteresis is always, in part, more restrictive. It is not a symmetric hysteresis. The detection value is over the programmed value, as a %. The hysteresis applies in the disconnection or the disappearance of the event. If the event is for a maximum (*OVER V THD*), the hysteresis will be applied when the signal drops. If the event is for a minimum (*HOLE THD* and *SHORT CIRCUIT THD*), the hysteresis will be applied when the signal increases again.

Example graph:



In the graph is showed an example of an Swell voltage in the interval t_0 . The time of that overvoltage event is the time that the signal is over the swell value (usually 110%) plus the time of the hysteresis for this swell (usually 2%).


Another example of event are showed in times period t_1 , t_3 and t_4 . They are Sags. They are configured usually unther 90% of the nominal voltage.

When the voltage goes down unther 10% it is stored as an interruption. That interruption is showed in period t_2 .

Thre quality events has to be longer than 10ms. If the duration is less than 10ms, the event will not be stored but will affect to the calculus of the average value for that period.

4.3. DEMAND

To access the maximum demand control parameters configuration screen, position the cursor over *DEMAND* and confirm by pressing *SET*.



Parameters that can be configured on this screen follow:

PERIOD: Integration window minutes used calculating the maximum demand. Values can be programmed from 1 up to a maximum of 60.

WIN. TYPE: It is possible to select between two window types to calculate the maximum demand. These are:

- **FIXED:** Each period duration initializes the maximum demand value. If programmed for 15 minutes, the measured values are integrated every 15 minutes, and the values for the next 15 minutes are set to zero.
- **MOVING:** The beginning and end of the integration period moves with each sample collected. The calculation for maximum demand is made with the values, in the integration time, each time a new sample is recorded.



To store the modified parameters in memory, press *SET* and confirm with *OK* (F4). To exit without saving changes press *ESC* (F3).

4.4 TARIFFS



WARNING: CVMk2 has an internal clock that you have to configure. The device will work with this local hour but, if you communicate the device with Power Studio the local time of the device will be changed to UTC hour.

CVMk2 permits configuring up to 9 tariff. To access the tariff configuration screen, position the cursor over *TARIFF* and press *SET*.



Parameters that can be configured on this screen follow:

- **NO. OF TARIFF.:** The number of tariff. Specify how many different tariff are going to be configured.
- **SYNCH.:** Use the internal clock or calendar to manage tariff, select the *CLOCK* option. To use an external signal to change tariff (activating static inputs for a **CVMk2** expansion card), select the *EXTERNAL* option.

It is possible to load a yearly fee calendar to the memory. This calendar can only be saved from the **CIRCUTOR** POWER STUDIO SCADA software. The calendar is stored in the memory and is synchronised with the internal clock.

- **NO. IN.:** If *EXTERNAL* was selected in the previous option, *SYNCH.*, specify the input for the expansion card, which will receive the impulse for each one of the tariff

Since the **CVMk2** expansion cards can be inserted in different positions, four digits have been reserved to configure the inputs. The digits that occupy the most memory indicate the position in which the inputs card is inserted in the **CVMk2** measurement module.

The last digits correspond to the input number to be programmed for tariff 2.

Numbers *100X* correspond to the digital inputs for the expansion card inserted in slot 1. Numbers *200X* correspond to the digital inputs for the expansion card inserted in slot 2, and numbers *300X* correspond to the digital inputs for the expansion card inserted in slot 3.

Example:


You wish to configure 5 tariff and assign them to **CVMk2** inputs 3, 4, 5 and 6. One expansion card with static digital inputs is available and inserted in position 2 of the measure module.

Activate 5 tariff and configure the input corresponding to tariff 2 in input *2003*. Accordingly, input 3 in slot 2 will be defined as that which corresponds to tariff 2. The following tariff are configured in the input: 4, 5 and 6, consecutively.

WARNING: The consecutive tariffs are automatically assigned to the inputs subsequent to the one configured for tariff 2

4.5 DELETE

CVMk2 has a screen from which parameters, stored to the memory, can be deleted. To access this display screen, go to the *SETUP* menu. In this *MENU*, access the *MEASURE* drop-down menu. Position the cursor over *DELETE* and confirm by pressing *SET*.



The following entries can be deleted in this menu:


- *ALL.*: Delete all stored values. Values that are deleted with this option include: maximums, minimums, energy meters, maximum demand and input pulse meters for all of the expansion cards.
- *MAXIMUMS*: This deletes maximum values stored with the corresponding date and time.
- *MINIMUMS*: This deletes minimum values stored with the corresponding date and time.
- *ENERGY.*: Zero the accumulated energy meters, including those for different tariff in the current, monthly and yearly meters.

- **DEMAND.:** Zero the maximum demand values, including those for different tariff.
- **EXT. CONT.:** Zero accumulated pulse values for the inputs from all static digital input expansion cards.

4.6 COMMUNICATIONS

To access the **CVMk2** communications configuration, select **SETUP** inside the **MENU**.

Once inside the configuration menu, select **COMM** and press **SET** to enter the menu. In this screen, configure the COM2 port to communicate the analyzer with the master PC or PLC.



The screenshot shows the 'Comm.' menu with the following settings:

| Menu | Measure | Comm. | Exp. Card |
|------------|---------|--------|-----------|
| Comm. | Comm. | | |
| Periph num | | 001 | |
| Baud | | 38400 | |
| Parity | | NO | |
| Data bit | | 8 | |
| Stop bit | | 1 | |
| Protocol | | MODBUS | |
| | | EDIT | |

At the bottom right, there are icons for a printer, a USB drive, and a lock.

The following entries can be edited in this menu:

- **PERIPH. NO.:** Peripheral number to be assigned to the device. The value should be between 1 and 255.
- **BAUDS:** Communication speed assigned to the COM2 serial port. The speeds that can be configured are: 9600, 19200, 38400 or 57600 bps.
- **PARITY:** Choose between NO, EVEN, ODD.
- **DATA BIT:** 8; this cannot be modified (in Modbus/RTU protocol).
- **STOP BIT:** It is possible to choose 1 or 2.
- **PROTOCOL:** MODBUS; this cannot be modified.



The communications parameters set in this screen are for the measurement module. The baudrate configured in that menu affect to the serial COM2 port and the ethernet communications. In case of communicate through ethernet expansion card o ethernet converter, the baudrate configured in that menu has to be the same than configured in XPORT of the ethernet expansion card o TCP 2RS converter

4.7 EXPANSION CARDS

4.7.0. INSERTING EXPANSION CARDS



Before doing any maintenance or repair work or handling any of the system connections, disconnect the device from all power sources: power supplies and input signals alike. Working on the system while it is powered up is dangerous, and it can cause irreversible damage to the system.

To insert an expansion card in the **CVMk2**, follow the procedure described here. Keep in mind that the images demonstrate how an expansion card is inserted in slot (position) 1. Position/slot 2 is immediately below slot 1, and position/slot 3 is furthest away from the terminal strips.



Shut off the power supply to the system.
Unscrew and remove the protective cover.



Insert the card by sliding it between the two lateral guides.




Carefully press to assure that the expansion card is properly connected in the **CVMk2**.




Now, screw on the top provided with the card.

To access the configuration menu for the different expansion cards, select *EXP.CARDS* in *SETUP MENU*. Select the position of the card to be configured.




If there is no card inserted in the position selected, the *NO CARD* message will be displayed on the screen.

The menu could be different depending on the expansion card inserted. In the manual will explain all menus of all expansion cards.




Before to powering up the machine, make sure that all the cables are properly connected. A wrong connection can cause serious injuries to the personnel that is working on the system.

4.7.1. 8 DIGITAL INPUTS AND 8 DIGITAL OUTPUTS



Read Section 4.7.0., Inserting Expansion Cards.


To access the configuration of the card with 8 digital inputs and 8 digital outputs, enter the configuration menu (*MENU* ---> *SETUP*) and in the *EXP.CARD* menu, select the position where the card is inserted. To modify the card configuration parameters, press the *EDIT* button (F4).



The parameters configured on the alarms screen have different meanings depending on the electric variable chosen on the configuration line, *VAR. CODE*. (See Chapter 8.3, Modbus Memory Map, to see the codes for all variables.)

Two types of electric variables are distinguished to configure an alarm.

- One real time value that is measured or calculated by the analyzer. (type a).
- Assigned an output for impulses (kW-h). One example of this type of variable can be consumed active energy with code 129 (type b).



4.7.1.1. Alarm configuration

When cards configuration is accessed, the following menu will appear for *ALARM 01*

VAR. CODE: The code entered in this variable may be an instantaneous electric variable or an energy variable to which an impulses output is assigned.

MAXIMUM: If instantaneous variable was selected, the maximum value of that real time electric variable should be configured. This should be considered as a maximum value alarm.
If energy variable was selected, the size of the pulse, that the alarm will have should be provided in W·h.

Example: If *000.010* is entered, the alarm will activate every 10W·h. Will generate a pulse every 10W·h.

MINIMUM: If instantaneous variable is selected, the minimum value of the real time electric variable should be configured. This should be considered as a minimum value alarm.
If energy variable is selected, it is not necessary to configure this parameter.

DELAY. ON: If instantaneous variable is selected, it corresponds to the minimum time in 10 milliseconds blocks that the condition must be activated to turn on the alarm.

Example: If the *000010* value is programmed, the alarm will be activated after 100ms.

If energy variable is selected, this value corresponds to the time ON impulse. This is the number of 10 ms steps that the alarm will be activated to generate the impulse.

Example: If the *000010* value is programmed, the alarm will be activated during 100ms.

DELAY. OFF: If instantaneous variable is selected, it corresponds to the minimum time in 10 milliseconds blocks that the condition must be deactivated, to turn off the alarm.

Example: If the *000010* value is programmed, the alarm will be deactivated after 100ms.

If energy variable is selected, this value corresponds to the time OFF impulse. This is the number of 10 ms steps that the alarm will be deactivated to generate the impulse.

Example: If the *000010* value is programmed, the alarm will be deactivated during 100ms

To access the configuration for alarm 2 and subsequent alarms, press the *NEXT* button (F2). The configuration screens for all the alarms, up to a maximum of 16 alarms, can be accessed in this way.

From the alarm 16 screen, the equation editor screen is accessed to activate the expansion card's physical outputs by pressing the F2 (*NEXT*) button once again. This card allows configuring outputs 01 to 08.

It is possible to access the inputs configuration screen (section 4.7.1.3., Digital Inputs Configuration) from any alarm screen by pressing *IN* (F1). It is also possible to access the output equations configuration screen (section 4.7.1.2. Digital Outputs Configuration) by pressing *EQ* (F3).

4.7.1.1.a Digital inputs codes

To configure the expansion card inputs, enter the corresponding input code. The code that corresponds to each input depends on the input number to be selected and the position in which the card is inserted (see attached table).

| CARD POSITION | VARIABLE | SYMBOL | CODE | MODBUS ADDRESS |
|---------------|---------------|---------|------|----------------|
| CARD 1 | Input 1 meter | IN_1001 | 400 | 0C80-0C81 |
| | Input 2 meter | IN_1002 | 401 | 0C82-0C83 |
| | Input 3 meter | IN_1003 | 402 | 0C84-0C85 |
| | Input 4 meter | IN_1004 | 403 | 0C86-0C87 |
| | Input 5 meter | IN_1005 | 404 | 0C88-0C89 |
| | Input 6 meter | IN_1006 | 405 | 0C8A-0C8B |
| | Input 7 meter | IN_1007 | 406 | 0C8C-0C8D |
| | Input 8 meter | IN_1008 | 407 | 0C8E-0C8F |
| CARD 2 | Input 1 meter | IN_2001 | 408 | 0C90-0C91 |
| | Input 2 meter | IN_2002 | 409 | 0C92-0C93 |
| | Input 3 meter | IN_2003 | 410 | 0C94-0C95 |
| | Input 4 meter | IN_2004 | 411 | 0C96-0C97 |
| | Input 5 meter | IN_2005 | 412 | 0C98-0C99 |
| | Input 6 meter | IN_2006 | 413 | 0C9A-0C9B |
| | Input 7 meter | IN_2007 | 414 | 0C9C-0C9D |
| | Input 8 meter | IN_2008 | 415 | 0C9E-0C9F |
| CARD 3 | Input 1 meter | IN_3001 | 416 | 0CA0-0CA1 |
| | Input 2 meter | IN_3002 | 417 | 0CA2-0CA3 |
| | Input 3 meter | IN_3003 | 418 | 0CA4-0CA5 |
| | Input 4 meter | IN_3004 | 419 | 0CA6-0CA7 |
| | Input 5 meter | IN_3005 | 420 | 0CA8-0CA9 |
| | Input 6 meter | IN_3006 | 421 | 0CAA-0CAB |
| | Input 7 meter | IN_3007 | 422 | 0CAC-0CAD |
| | Input 8 meter | IN_3008 | 423 | 0CAE-0CAF |

4.7.1.1.b Reverse configuration logic output

When a variable code corresponding to the status of an expansion card input is selected, an alarm can be activated in one of two possible ways: direct or inverse logic.

To configure the alarms using direct logic, with respect to the input, [i.e., the alarm activates (value = 1) when the input activates (value = 1)], the parameters should be configured as follows:

$M_{AX} = 1$ and $M_{IN} = -1$.

To configure the alarms using inverse logic, with respect to the input, [i.e., the alarm activates (value = 0) when the input deactivates (value = 1)], the parameters should be configured as follows:

$M_{AX} = 0$ and $M_{IN} = 0$.

4.7.1.2. Digital outputs configuration

On this screen, equations are configured for the alarms that are applied to activate the system outputs. Equations can be configured using AND (*) and/or OR (+) functions between one or more of the 16 previously configured alarms (see Section 4.7.1.1., Alarm Configuration), in order to activate each one of the card's 8 digital outputs.

To modify the card equations' configuration parameters, press the *EDIT* button (F4). Select the output to be configured and press *SET* to begin editing.

| Menu | Measure | Comm. | Exp. Card |
|------------------|-------------------------|-------|-----------|
| Exp. Card Card 1 | | | |
| OUT 01 | 00*00*00*00*00*00*00*00 | | |
| OUT 02 | 00*00*00*00*00*00*00*00 | | |
| OUT 03 | 00*00*00*00*00*00*00*00 | | |
| OUT 04 | 00*00*00*00*00*00*00*00 | | |
| OUT 05 | 00*00*00*00*00*00*00*00 | | |
| OUT 06 | 00*00*00*00*00*00*00*00 | | |
| OUT 07 | 00*00*00*00*00*00*00*00 | | |
| OUT 08 | 00*00*00*00*00*00*00*00 | | |
| | | ESC | OK |

Edit the two digits in the equation that correspond to the appropriate alarm. Between the two digits corresponding to the alarm, an "*" or "+" sign can be entered. These correspond to the AND or OR functions, respectively, and will be applied between the alarms configured.


Press (F3) to return to the *ALARM 01* screen (Section 4.7.1.1).

Press (F1) to return to the *INPUTS* screen (Section 4.7.1.3).



WARNING: The value 00 in an outputs activation equation means that nothing at all should be done. Thus, it should only be entered at the end of the equation. If the value 00 is entered at the beginning of the equation, the **CVMk2** will not make the calculation or activate the corresponding output.

4.7.1.3. Digital inputs configuration



The card inputs are also configured in two different ways depending on whether the user desires to configure the input as an incremental counter or a two-state logic input (ON/OFF).

SIZE = 0000

Accordingly, the input is configured as a two-state input, ON/OFF. When the input is configured as ON/OFF, it is not necessary to configure the next menu option, *DEC. POS.*

SIZE ≠ 0000

When an input size other than zero is configured, this is configured as an incremental pulse counter, which can have a maximum counter value of 10M. The value to enter is the multiplier for each input pulse.

DEC. POS.: Indicate the decimal positions that the corresponding input counter should have.


The options available in the lower menu include:

NEXT(F2). This increases the input number from 1 to a maximum of 08 to access its configuration. From the 08 input configuration screen, pressing F2 (*NEXT*) again will take the user back to the 01 input configuration screen.


OUT (F1): Press this button to access the alarms configuration screen, Section 4.7.1.1.

To store the modified parameters in memory, press *SET* and confirm with *OK* (F4). To exit without saving changes press *ESC* (F3).

The connection of the card inputs and outputs is shown in the following figure:




An example of the wiring of the expansion cards is:



4.7.1.4. Expansion card parameters

To see the parameters of the expansion card, you have to intro in *MENU*, select *CARDS*, and go to the card to see the parameters.




The picture shows the status of the inputs of the cards or the number of impulses that has conuted each one.

4.7.1.5. Features

| FEATURES | VALUE | UNIT |
|-------------------------------|--------------------------|-----------------|
| LOGICAL INPUTS | | |
| Type of input | Non voltage / NPN | |
| Type of coupling | Optically isolated input | |
| Maximum peak voltage | 24 | V d.c |
| Minimum times | t_{on} 40 | ms |
| | t_{off} 40 | ms |
| STATUS OUTPUT | | |
| Rated voltage | < 48 | V d.c |
| Rated current | 100 | mA |
| Maximum power | 0.8 | W |
| Maximum Ron | 35 | Ω |
| CONNECTIONS | | |
| Rigid conductor cross section | 0,05..1 (AWG 30...18) | mm ² |
| Terminal torque | 0,3 | Nm |


4.7.2 - 8 DIGITAL INPUTS AND 4 RELAY OUTPUTS



Read Section 4.7.0., Inserting Expansion Cards.

To access the configuration of the card with 8 digital inputs and 4 relay outputs, enter the configuration menu (*MENU* ---> *SETUP*.) and in the *EXP. CARDS* menu, select the position where the card is inserted.


To modify the card configuration parameters, press the *EDIT* button (F4).



The parameters configured on the alarms screen have different meanings depending on the electric variable chosen on the configuration line, *VAR. CODE*, (See Chapter 8.3, Modbus Memory Map, to see the codes for all variables.)

Two types of electric variables are distinguished to configure an alarm.

- One real time value that is measured or calculated by the analyzer. (type a).
- Assigned an output for impulses (kW·h). One example of this type of variable can be active energy consumed with code 129 (type b).



4.7.2.1. Alarm configuration

When cards configuration is accessed, the following menu will appear for *ALARM 01*

VAR. CODE: The code entered in this variable may be an instantaneous electric variable or an energy variable to which an impulses output is assigned.

MAXIMUM: If instantaneous variable was selected, the maximum value of that real time electric variable should be configured. This should be considered as a maximum value alarm.
If energy variable was selected, the size of the pulse, that the alarm will have should be provided in W·h.

Example: If *000.010* is entered, the alarm will activate every 10W·h. Will generate a pulse every 10W·h.

MINIMUM: If instantaneous variable is selected, the minimum value of the real time electric variable should be configured. This should be considered as a minimum value alarm.
If energy variable is selected, it is not necessary to configure this parameter.

DELAY. ON: If instantaneous variable is selected, it corresponds to the minimum time in 10 milliseconds blocks that the condition must be activated to turn on the alarm.

Example: If the *000010* value is programmed, the alarm will be activated after 100ms.

If energy variable is selected, this value corresponds to the time ON impulse. This is the number of 10 ms steps that the alarm will be activated to generate the impulse.

Example: If the *000010* value is programmed, the alarm will be activated during 100ms.

DELAY. OFF: If instantaneous variable is selected, it corresponds to the minimum time in 10 milliseconds blocks that the condition must desactivated, to turn off the alarm.

Example: If the *000010* value is programmed, the alarm will be desactivated after 100ms.

If energy variable is selected, this value corresponds to the time OFF impulse. This is the number of 10 ms steps that the alarm will be deactivated to generate the impulse.

Example: If the *000010* value is programmed, the alarm will be desactivated during 100ms

To access the configuration for alarm 2 and subsequent alarms, press the *NEXT* button (F2). The configuration screens for all the alarms, up to a maximum of 16 alarms, can be accessed in this way.

From the alarm 16 configuration screen, the equation editor screen is accessed to activate the expansion card's physical outputs by pressing again the F2 (*NEXT*) button. This card allows configuring outputs 01 to 04.

It is possible to access the inputs configuration screen (section 4.7.2.3., Digital inputs configuration) from any alarm screen by pressing *IN* (F1). It is also possible to access the output equations configuration screen (section 4.7.2.2. Relay output configuration) by pressing *EQ* (F3).

4.7.2.1.a Digital input codes

To configure the expansion card outputs, enter the corresponding input code. The code that corresponds to each input depends on the input number to be selected and the position in which the card is inserted (see attached table).

| CARD POSITION | VARIABLE | SYMBOL | CODE | MODUS ADDRESS |
|---------------|---------------|---------|------|---------------|
| CARD 1 | Input 1 meter | IN_1001 | 400 | 0C80-0C81 |
| | Input 2 meter | IN_1002 | 401 | 0C82-0C83 |
| | Input 3 meter | IN_1003 | 402 | 0C84-0C85 |
| | Input 4 meter | IN_1004 | 403 | 0C86-0C87 |
| | Input 5 meter | IN_1005 | 404 | 0C88-0C89 |
| | Input 6 meter | IN_1006 | 405 | 0C8A-0C8B |
| | Input 7 meter | IN_1007 | 406 | 0C8C-0C8D |
| | Input 8 meter | IN_1008 | 407 | 0C8E-0C8F |
| CARD 2 | Input 1 meter | IN_2001 | 408 | 0C90-0C91 |
| | Input 2 meter | IN_2002 | 409 | 0C92-0C93 |
| | Input 3 meter | IN_2003 | 410 | 0C94-0C95 |
| | Input 4 meter | IN_2004 | 411 | 0C96-0C97 |
| | Input 5 meter | IN_2005 | 412 | 0C98-0C99 |
| | Input 6 meter | IN_2006 | 413 | 0C9A-0C9B |
| | Input 7 meter | IN_2007 | 414 | 0C9C-0C9D |
| | Input 8 meter | IN_2008 | 415 | 0C9E-0C9F |
| CARD 3 | Input 1 meter | IN_3001 | 416 | 0CA0-0CA1 |
| | Input 2 meter | IN_3002 | 417 | 0CA2-0CA3 |
| | Input 3 meter | IN_3003 | 418 | 0CA4-0CA5 |
| | Input 4 meter | IN_3004 | 419 | 0CA6-0CA7 |
| | Input 5 meter | IN_3005 | 420 | 0CA8-0CA9 |
| | Input 6 meter | IN_3006 | 421 | 0CAA-0CAB |
| | Input 7 meter | IN_3007 | 422 | 0CAC-0CAD |
| | Input 8 meter | IN_3008 | 423 | 0CAE-0CAF |

4.7.2.1.b Reverse configuration logic output

When a variable code corresponding to the status of an expansion card input is selected, an alarm can be activated in one of two possible ways: direct or inverse logic.

To configure the alarms using direct logic, with respect to the input, [i.e., the alarm activates (value = 1) when the input activates (value = 1)], the parameters should be configured as follows:

$MAX = 1$ and $MIN = -1$.

To configure the alarms using inverse logic, with respect to the input, [i.e., the alarm activates (value = 0) when the input deactivates (value = 1)], the parameters should be configured as follows:

$MAX = 0$ and $MIN = 0$.

4.7.2.2. Relay outputs configuration

On this screen, equations are configured for the alarms that are applied to activate the system outputs. Equations can be configured using AND (*) and/or OR (+) functions between one or more of the 16 previously configured alarms (see Section 4.7.2.1. Alarm Configuration) in order to activate each relay output.

To modify the card configuration parameters, press the *EDIT* button (F4). Select the output to be configured and press *SET* to begin editing.

| Menu | Measure | Comm. | Exp. Card |
|------------------|-------------------------|-------|-----------|
| Exp. Card Card 1 | | | |
| OUT 01 | 00*00*00*00*00*00*00*00 | | |
| OUT 02 | 00*00*00*00*00*00*00*00 | | |
| OUT 03 | 00*00*00*00*00*00*00*00 | | |
| OUT 04 | 00*00*00*00*00*00*00*00 | | |




WARNING: The value 00 in the outputs activation equation means that nothing at all should be done. Thus, it should only be entered at the end of the equation. If the value 00 is entered at the beginning of the equation, the **CVMk2** will not make the calculation or activate the corresponding output.

Press (F3) to return to the *ALARM 01* screen (Section 4.7.2.1).

Press (F1) to return to the *INPUTS* screen (Section 4.7.2.3).

Edit the two digits in the equation that correspond to the appropriate alarm(s). Between the two digits corresponding to the alarm, an "*" or "+" sign can be entered. These correspond to the AND or OR functions, respectively, and will be applied between the alarms configured.

4.7.2.3. Digital inputs configuration



The card inputs are also configured in two different ways depending on whether the user desires to configure the input as an incremental counter or a two-state logic input (ON/OFF).

SIZE = 0000

By setting the input size to zero, the input will be configured for ON/OFF input status. When the input is configured as Boolean, it is not necessary to configure the next menu option, *DEC. POS.*

SIZE ≠ 0000

When an input size other than zero is configured, this is configured as an incremental pulse counter, which can have a maximum counter value of 10M. The value to enter is the multiplier for each input pulse.

DEC. POS.: Indicate the decimal positions that the corresponding input counter should have.

The options available in the lower menu include:


NEXT(F2). This increases the input number from 1 to a maximum of 08 to access its configuration. From the 08 input configuration screen, pressing F2 (*NEXT*) again will take the user back to the 01 input configuration screen.

OUT (F1): Press this button to access the alarms configuration screen, Section 4.7.2.1.


To store the modified parameters in memory, press *SET* and confirm with *OK* (F4). To exit without saving changes press *ESC* (F3).

4.7.2.4. Card Connections

The connection of the card inputs and outputs is shown in the following figure:




An example of the wiring of the expansion cards is:



4.7.2.5. Expansion card parameters

To see the parameters of the expansion card, you have to intro in *MENU*, select *CARDS*, and go to the card to see the parameters.




The picture shows the status of the inputs of the cards or the number of impulses that has counted each one.

4.7.2.6. Features


| FEATURES | VALUE | UNIT |
|-------------------------------|---|-----------------|
| LOGICAL INPUTS | | |
| Type of input | Voltage free contact | |
| Type of coupling | Optically isolated input | |
| Maximum peak voltage | 24 | V dc |
| Minimum times | t_{on} 40 | ms |
| | t_{off} 40 | ms |
| RELAY OUTPUT | | |
| Maximum voltage | 250 | V a.c |
| Maximum current | 3 | A |
| Minimum relay load | 1 | V a.c |
| | 1 | mA |
| Mechanical life | 5×10^6 | cycles |
| Electrical life at rated load | NA: 5×10^4 , NC: 3×10^4 | cycles |
| CONNECTIONS | | |
| Maximum torque | 0.3 | Nm |
| Rigid conductor cross section | 0,05..1 (AWG 30...18) | mm ² |

4.7.3 - 8 ANALOGUE INPUTS AND 4 ANALOGUE OUTPUTS




Read Section 4.7.0., Inserting Expansion Cards.

To access the configuration of the card with 8 digital inputs and 4 analogue outputs, enter the configuration menu (*MENU* ---> *SETUP*), and in the *EXP.CARD* menu, select the position where the card is inserted. Press *SET* to enter in the card menu.




To access the card configuration parameters, press the *EDIT* button (F4). Select the analogue output to be configured and press *SET* to enter edit mode.



4.7.3.1. Analogue outputs configuration

The card's analogue outputs configuration screen is shown in the following screen:



The analogue outputs' configuration parameters are:

VAR. CODE: Real time electric variable code to be assigned to the output (see Chapter 8.3, Modbus Memory Map, to see the codes for all variables).
Energy code not permitted.

SCALE: It is possible to select between 0 and 4, which correspond to scales 0...20 mA and 4...20 mA, respectively.

ZERO: The variable should be assigned this value to have an output of 0 or 4 mA (depends on the scale selected).

BOTTOM OF SCALE.: The variable should be assigned this value to have an output of 20 mA.

The function buttons give us the following options when in edit mode:

ESC: Exit the current menu without saving changes.

OK: Confirm and save the changes made.

The different buttons that appear on this screen are:

NEXT: This button is clicked to increase the output number up to a maximum of 4 (*A/D OUT 04*). Click it again to return to output 01 (*A/D OUT 01*).

IN: From any screen, click on this button to go to the analogue inputs' configuration screen. (Section 4.7.3.3. Analogue Inputs Configuration)

EDIT: Click on this option to access the edit menu. The arrow buttons are used to select the parameter to be modified (in bold). Enter by pressing the *SET* Button.

4.7.3.2. Analogue inputs codes


To configure alarms based on the analogue input values of the expansion card, enter the corresponding input code. The code that corresponds to each input depends on the input number to be selected and the position in which the card is inserted (see attached table).

| CARD POSITION | VARIABLE | SYMBOL | CODE | MODBUS ADDRESS |
|---------------|------------------|---------|------|----------------|
| CARD 1 | Analogue input 1 | AD_1001 | 424 | 0CB2-0CB3 |
| | Analogue input 2 | AD_1002 | 425 | 0CB4-0CB5 |
| | Analogue input 3 | AD_1003 | 426 | 0CB6-0CB7 |
| | Analogue input 4 | AD_1004 | 427 | 0CB8-0CB9 |
| | Analogue input 5 | AD_1005 | 428 | 0CBA-0CBB |
| | Analogue input 6 | AD_1006 | 429 | 0CBC-0CBD |
| | Analogue input 7 | AD_1007 | 430 | 0CBE-0CBF |
| | Analogue input 8 | AD_1008 | 431 | 0CC0-0CC1 |
| CARD 2 | Analogue input 1 | AD_2001 | 432 | 0CC2-0CC3 |
| | Analogue input 2 | AD_2002 | 433 | 0CC4-0CC5 |
| | Analogue input 3 | AD_2003 | 434 | 0CC6-0CC7 |
| | Analogue input 4 | AD_2004 | 435 | 0CC8-0CC9 |
| | Analogue input 5 | AD_2005 | 436 | 0CCA-0CCB |
| | Analogue input 6 | AD_2006 | 437 | 0CCC-0CCD |
| | Analogue input 7 | AD_2007 | 438 | 0CCE-0CCF |
| | Analogue input 8 | AD_2008 | 439 | 0CD0-0CD1 |
| CARD 3 | Analogue input 1 | AD_3001 | 440 | 0CD2-0CD3 |
| | Analogue input 2 | AD_3002 | 441 | 0CD4-0CD5 |
| | Analogue input 3 | AD_3003 | 442 | 0CD6-0CD7 |
| | Analogue input 4 | AD_3004 | 443 | 0CD8-0CD9 |
| | Analogue input 5 | AD_3005 | 444 | 0CDA-0CDB |
| | Analogue input 6 | AD_3006 | 445 | 0CDC-0CDD |
| | Analogue input 7 | AD_3007 | 446 | 0CDE-0CDF |
| | Analogue input 8 | AD_3008 | 447 | 0CE0-0CE1 |

To configure an alarm through its variable code, you need an analog outputs expansion card that allow to enter the code and configure the maximum or minimum value and assigning it to an alarm to activate an output.

4.7.3.3. Analogue inputs configuration

The card's analogue inputs configuration screen is shown in the following figure:



The different buttons that appear on this screen are:

NEXT: This button is clicked to increase the input number to a maximum of 8 (*A/D IN 08*). Select it again to return to input 01 (*A/D IN 01*).

OUT: From any input screen, click on this option to access the analogue outputs' configuration screen. (See Section 4.7.3.1)

EDIT: Click on this option to access the parameters edit menu. The arrow buttons are used to select the parameter to be modified (in bold) and access the parameters by pressing **SET**.

The analogue inputs' configuration parameters follow:

SCALE: Input range. Choose between 0...20 mA or 4...20 mA.

ZERO: The value to be viewed at the origin of the axis (4 or 20 mA).

BOTTOM OF SCALE.: The value to be viewed when the input is set at 20 mA.


DEC. POS.: Decimal point position.

The following menu options will appear on the parameters' edit screen.


ESC: Exit the current menu without saving changes.

OK: Save the changes made and exit the edit screen.


The connection of the card inputs and outputs is shown in the following figure:



An example of the wiring of the expansion cards is:




When the load connected to the outputs is greater than 300 Ω , the outputs can be powered by an external power supply. In order to supply the outputs with an external power supply, change the position of the plate jumper to position 2, as indicated in the figure. To connect the source, connect the positive cable to terminal No. 9 and the negative cable to any of the ground connections.



4.7.3.4. Expansion card parameters

To see the parameters of the expansion card, you have to intro in *MENU*, select *CARDS*, and go to the card to see the parameters.




The picture shows the status of the inputs of the cards or the number of impulses that has configured each one.

4.7.3.5. Features


| FEATURES | VALUE | UNIT |
|--|-----------------------|--------|
| ANALOGUE OUTPUTS | | |
| Maximum internal/external voltage | 24 | V d.c |
| Rated output range | 0/4 _ 20 mA | mA d.c |
| Linearity | 1 | % |
| Load resistance range | < 500 | Ω |
| Resolution | 4000 | points |
| ANALOGUE INPUTS | | |
| Type of measurement | Current | |
| Rated input range | 0/4 _ 20 mA | mA d.c |
| Measurement precision | 1 | % |
| Input impedance | 200 | Ω |
| CONNECTIONS | | |
| Rigid/flexible conductor cross section | 0,05..1 (AWG 30...18) | mm² |
| Maximum torque | 0,3 | Nm |
| MECHANICAL | | |
| Terminals protection | IP 20 | |

4.7.4 - ETHERNET AND SD MEMORY




Read Section 4.7.0., Inserting Expansion Cards.

To access the Ethernet and SD memory card configuration, enter the configuration menu (*MENU* ---> *SETUP*), and in the *EXP.CARD* menu, select the position where the card is inserted.



In the Ethernet and SD memory card configuration screen, it is possible to delete every file saved to the memory. The data saved is basically separated into two formats as seen in the figure: quality events with the *.EVQ extension and the standard registries with the *.STD extension.

A single *.EVQ events file is generated, in which are stores all the quality voltage events. The *.STD files are automatically generated every day.





WARNING: When an SD card is installed in the system, it is automatically formatted. It is recommended not to install cards with documents that should be preserved.

The card format should be FAT 16 and the maximum capacity is 2 Gb. Neither FAT 32 nor HCSD formats are accepted.

To modify the card configuration parameters, press the *EDIT* button (F4). Select the option to be configured and press *SET* to begin editing.

It is possible to select between *YES* or *NO* values using the up/down arrow buttons, and the selection is confirmed with the *OK KEY*.

Edit screen options follow:

ESC: Exit the current menu without saving changes.

OK: Save the changes made and exit the edit screen.

Parameters that can be configured on this screen follow:

DELETE STD: Delete the last day stored in SD memory (*.STD).

DELETE EVQ: Delete the quality file stored in SD memory (*.EVQ).

FORMAT: Delete all files stored in SD memory.

4.7.4.1. Network and communications Protocol

The **CVMk2's** Ethernet card and SD memory are specifically designed to communicate in Ethernet networks with Modbus/TCP protocol.

With this system, all the RS-485 communication BUS wiring is extraordinarily optimised, thus optimising the IT infrastructure already created and facilitating its installation.

4.7.4.2. IP Address Configuration



WARNING: The IP assigned to the **CVMk2** with the *arp* commands is temporary and the system will recover its original IP when it loses the power supply. To save the new IP in the system, enter the configuration menu, verify the modifications and exit the menu after saving changes. Accordingly, the new IP will be saved in the analyzer.

The ARP commands can be used to configure the Ethernet card's IP address.

As for the Windows ARP command, the PC ARP table must have at least one IP address defined in addition to its own IP address. If the ARP table is empty, the command will return an error message. From a command window, type in "arp-a", to verify that there is at least one entry in the ARP table. If the ARP table does not exist or the machine using it is the only one in the table, ping any other IP address on the network to generate a new entry in the table. As example if you want to configure the IP address 172.16.14.254 and the MAC address of the card is 00-20-4A-8D-66-66

- a) Once that is done, enter the following command to assign the IP address to the expansion card connection.

```
c:\ arp -s 172.16.14.254 00-20-4A-8D-66-66
```

- b) Now, execute a telnet to port 1. The connection attempt will always fail, but the **CVMk2** will change its IP to the one previously assigned.

```
c:\ telnet 172.16.14.254 1
```

- c) Finally, execute a telnet to port 9999 and configure all the required parameters. Then, it is possible to begin configuration of the expansion card's Ethernet converter. It is very important to save the changes before exiting the configuration menu. Example:

```
c:\ telnet 172.16.14.254 9999
```

The configuratios screen is as follow

```

C:\ Telnet 172.16.14.254

Press Enter to go into Setup Mode
Model: Device Server Plus+! <Firmware Code:XA>
Modbus/TCP to RTU Bridge Setup
1) Network/IP Settings:
   IP Address ..... 172.16.14.254
   Default Gateway ..... --- not set ---
   Netmask ..... --- not set ---
2) Serial & Mode Settings:
   Protocol ..... Modbus/RTU,Slave(s) attached
   Serial Interface ..... 19200,8,N,1,RS485
3) Modem/Configurable Pin Settings:
   CP1 ..... Not Used
   CP2 ..... RS485 Output Enable
   CP3 ..... Not Used
4) Advanced Modbus Protocol settings:
   Slave Addr/Unit Id Source .. Modbus/TCP header
   Modbus Serial Broadcasts ... Disabled <Id=0 auto-mapped to 1>
   MB/TCP Exception Codes ..... Yes <return 00AH and 00BH>
   Char. Message Timeout ..... 00050msec, 05000msec
D)default settings, S>ave, Q>uit without save
  
```

In this menu you can configure all options of CVMk2 ethernet card. Once the desired configuration exit the application must exit saving changes




The speed set in the configuration menu CVMk2 ethernet port must match the speed configured on the device itself (see chapter 4.6 Communications). If no match, the device did not communicate properly with the application or master.

Connection with the master system is made with Ethernet cables consisting of four pairs of twisted pair wires (screened). The card is connected on one end while the corporate network's electronics (hub or switch) is connected on the other end.

If a computer or device is directly connected through its Ethernet port, the Ethernet cable wiring should have a special provision for said communication.

It is also possible to configure the **CVMk2's** expansion card IP address using Power Studio or **PowerStudio Scada** by **CIRCUTOR**. (Said software can be downloaded from www.circutor.com).

Once installed, the **CVMk2** Ethernet Modbus/TCP device should be selected, as illustrated in the figure:



New CVMk2 Ethernet

Name: CVMk2

Description:

Peripheral number: 1


IP address: 172.16.14.254

Port: 502

Configuration port: 30718

Buttons: Setup, Advanced setup, Accept, Cancel

You must assign a name and the desired IP address. The IP address must be in the same address limit than does the computer. This step will fail because they do not find the device with the IP that was assigned and display the next screen to request the MAC address of the card.



Device configuration CVMk2 Ethernet

Physical address (MAC):

IP address: 172 . 16 . 14 . 254

Physical address (MAC): Ethernet address written on the device label, unique and different for every system device. It is a number like 00-20-4A-61-05-19.

Buttons: Accept, Cancel

You must enter the MAC address of the ethernet card and click accept. The software sends the new IP address to the expansion card analyzer

4.7.4.3. SD card configuration

Once the card is inserted, continue with its configuration. To do so, select the *MENU* option from the upper bar on the display and press *SET* to access the drop-down menu.


From the three options that appear on the drop-down menu (card 1, card 2 or card 3), count from the top side of the system to select the position where the expansion card is inserted.

NOTE: If there is no card inserted in the position selected, the message *NO CARD* will appear on screen

Confirm the selection with the *SET* button, and continue with the card configuration.

4.7.4.4. SD Card parameters

To view the memory card parameters, enter the *MENU*, select *CARDS*, and navigate to the corresponding card to see the features.



MEMORY SPACE: This indicates the real capacity of the SD card.

REGISTRY: This provides the days recorded since start or from the last format.


EVENTS: This indicates the number of voltage events detected since start or from the last formatting.

FREE: This indicates the percentage of free memory space.

STATUS: The memory status is indicated with text as well as with the icon on the bottom of the screen.

- a) **SD OK:** The memory card is functioning properly
- b) **NO SD:** There is no card inserted.
- c) **WRITE PROT:** The card is write protected.
- d) **ERROR:** There is a problem with the SD card, and it should be formatted.

4.7.4.5. Expansions card icons

 Correct SD memory status.

 Incorrect SD memory status.

 Extraction of SD card enabled.




If there is a card error, it is advised to format the card. If the error persists after formatting the SD card, make sure that it is SD FAT 16 format and that the capacity is equal to or less than 2 Gb. Any other format or greater capacity will not work. If the error persists, replace the memory card.

4.7.4.6. Ethernet card features

| ETHERNET OUTPUT | |
|------------------------|--------------------------------|
| Network protocol | RJ-45 Ethernet |
| Communication protocol | Modbus-TCP |
| Speed | 10baseT / 100baseTx compatible |
| SD CARD | |
| Model | SD |
| Size | 2 Gb |
| Format | FAT 16 |

4.7.5 - SD MEMORY



Read Section 4.7.0., Inserting Expansion Cards.

To access to SD memory card configuration, enter the configuration menu (*MENU* ---> *SETUP*), and in the *EXP.CARD* menu, select the position where the card is inserted.



WARNING: When an SD card is installed in the system, it is automatically formatted. It is recommended not to install cards with documents that should be preserved.
The card format should be FAT 16 and the maximum capacity is 2 Gb.
Neither FAT 32 nor HCSD formats are accepted.


4.7.5.1. SD Card configuration

Once the card is inserted, continue with its configuration. To do so, select the *MENU* option from the upper bar on the display and press *SET* to access the drop-down menu.

From the three options that appear on the drop-down menu (card 1, card 2 or card 3), count from the top side of the system to select the position where the expansion card is inserted.

NOTE: If there is no card inserted in the position selected, the message *NO CARD* will appear on screen

Confirm the selection with the *SET* button, and continue with the card configuration.



A single *.EVQ events file is generated with voltage quality events stored. The *.STD files are automatically generated every day.

The value can be toggled between *YES* and *NO* using the up/down arrow buttons, and the value is confirmed with *OK*. If *YES* is selected, this indicates that the user wishes to delete the selected file.

ESC: Exit the current menu without saving changes.

OK: Save the changes made and exit the edit screen.

Parameters that can be configured on this screen follow:


DELETE STD: Delete the last day stored in SD memory (*.STD).

DELETE EVQ: Delete the quality file stored in SD memory (*.EVQ).

FORMAT: Delete all files stored in SD memory.

4.7.5.2. SD card parameters

To view the memory card parameters, enter the *MENU*, select *CARDS*, and navigate to the corresponding card to see the features.



Parameters that can be viewed on this screen follow:

MEMORY SPACE: Capacity of the SD card.

REGISTRY: Days recorded since start or from the last format.

EVENTS: Number of voltage events detected since start or from the last formatting.

FREE: Percentage of free memory space.

STATUS: Memory status.

- a) *SD OK*: The card is functioning properly
- b) *NO SD*: There is no card inserted.
- c) *WRITE PROT*: The card is write protected.
- d) *ERROR*: There is a problem with the SD card, and it should be formatted.



If there is a card error, it is advised to format the card. If the error persists after formatting the SD card, make sure that it is SD FAT 16 format and that the capacity is equal to or less than 2 Gb. Any other format or greater capacity will not work. If the error persists, replace the memory card.

4.7.5.3. Expansion card icons



Correct SD memory status.



Incorrect SD memory status.




Extraction of SD card enabled.

4.7.5.4. Ethernet output features

| SD CARD | |
|---------|--------|
| Model | SD |
| Size | 2 Gb |
| Format | FAT 16 |


4.7.6 - 4 ± 5 MA ANALOGUE AND STATIC OUTPUTS




Read Section 4.7.0., Inserting Expansion Cards.

4.7.6.1. ± 5 mA analog outputs card configuration

To access the configuration of the card with 4 analog and 4 statics outputs, enter the configuration menu (*MENU* ---> *SETUP*). in the *EXP.CARD* menu, select the position where the card is inserted. Press *SET* to enter in the card menu.




To access the outputs configuration parameters, press the *EDIT* button (F4). Select the analogue output to be configured and press *SET* to enter edit mode.



4.7.6.2. ± 5 mA analog outputs configuration

The configuration screen is as follows

| Menu | Medida | Com. | Tarjetas |
|--|--------|-------|----------|
| Tarjetas Tarjeta 3 | | | |
| A/D OUT 01 | | | |
| Cód. Var. | | 001 | |
| Val -5 mA | | 00000 | |
| Val +5 mA | | 00000 | |
| <div> <div>IN</div> <div>PROX</div> <div></div> <div>EDIT</div> <div>  </div> </div> | | | |

The parameters that we can modify are:

VAR. CODE: That value in the electrical variable code that we want to assign to the (see variable code table). Are not allowed energy codes.

VARL - 5 mA: Select the value that corresponds to -5 mA in the output.

VARL +5 mA: Select the value that corresponds to +5 mA in the output.

In the edition screen appears the keys:

ESC: Used to go back without saving changes.

OK: Used to confirm / save changes and go out of editor mode.

The function keys are:

NEXT: It increases the output number until number 4 (A/D OUT 04). If we press **NEXT** again, returns to output number 1 (A/D OUT 01).

DIG: Pressing that key we can go to alarm screens configuration (Section 4.7.6.3).

EDIT: Press to edit the parameters of the analog outputs. Move with the arrows to select the parameter to modify and press **SET** to enter the value.

4.7.6.3. Alarm configuration

When cards configuration is accessed, the following menu will appear for **ALARM 01**

VAR. CODE: The code entered in this variable may be an instantaneous electric variable or an energy variable to which an impulses output is assigned.

MAXIMUM: If instantaneous variable was selected, the maximum value of that real time electric variable should be configured. This should be considered as a maximum value alarm.
If energy variable was selected, the size of the pulse, that the alarm will have should be provided in W·h.

Example: If *000.010* is entered, the alarm will activate every 10W·h. Will generate a pulse every 10W·h.

MINIMUM: If instantaneous variable is selected, the minimum value of the real time electric variable should be configured. This should be considered as a minimum value alarm.
If energy variable is selected, it is not necessary to configure this parameter.

DELAY. ON: If instantaneous variable is selected, it corresponds to the minimum time in 10 milliseconds blocks that the condition must be activated to turn on the alarm.

Example: If the *000010* value is programmed, the alarm will be activated after 100ms.

If energy variable is selected, this value corresponds to the time ON impulse. This is the number of 10 ms steps that the alarm will be activated to generate the impulse.

Example: If the *000010* value is programmed, the alarm will be activated during 100ms.

DELAY. OFF: If instantaneous variable is selected, it corresponds to the minimum time in 10 milliseconds blocks that the condition must be deactivated, to turn off the alarm.

Example: If the *000010* value is programmed, the alarm will be deactivated after 100ms.

If energy variable is selected, this value corresponds to the time OFF impulse. This is the number of 10 ms steps that the alarm will be deactivated to generate the impulse.

Example: If the *000010* value is programmed, the alarm will be deactivated during 100ms

To access the configuration for alarm 2 and subsequent alarms, press the *NEXT* button (F2). The configuration screens for all the alarms, up to a maximum of 16 alarms, can be accessed in this way.

The equations are the physical outputs of the device. From *OUT 01* to *OUT 04*.


To go to analog output screen configuration pressing *ANL* key. (Section 4.7.6.1). To go to equations screen press *ECU* (Section 4.7.6.4). To go to alarm screen press *DIG* (Section 4.7.6.3).

4.7.6.4. Static outputs configuration

The outputs of the expansion card are configuring in that screen. The transistor are called *OUT 01*, *OUT 02*, *OUT 03* and *OUT 04*.

On this screen you configure alarms equations that are applied to select the outputs of the device. You can set up equations with functions AND (*) and / or OR (+) in one or more of the 16 pre-configured alarms (see section 4.7.6.3 Alarm configuration), to activate each of the 4 output transistor of the team.

To modify the configuration parameters of the card, you must press the *EDIT* (F4). Select the output you want to configure and press *SET* to enter editing.




4.7.6.5. Outputs wiring

The layout of the outputs of the expansion card is as follows


| A. OUTPUTS | | | | | | | | | T. OUTPUTS | | | | | | | | |
|------------------------------|---|---|---|---|---|---|---|---|------------------------------|---|---|---|---|---|---|---|---|
| 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 |
| <div>⊘ ⊘ ⊘ ⊘ ⊘ ⊘ ⊘ ⊘ ⊘</div> | | | | | | | | | <div>⊘ ⊘ ⊘ ⊘ ⊘ ⊘ ⊘ ⊘ ⊘</div> | | | | | | | | |
| 1- COMMON | | | | | | | | | 1- COMMON | | | | | | | | |
| 2- Analogic output 1 | | | | | | | | | 2- COMMON | | | | | | | | |
| 3- COMMON | | | | | | | | | 3- COMMON | | | | | | | | |
| 4- Analogic output 2 | | | | | | | | | 4- COMMON | | | | | | | | |
| 5- COMMON | | | | | | | | | 5- COMMON | | | | | | | | |
| 6- Analogic output 3 | | | | | | | | | 6- Transistor ouput 1 | | | | | | | | |
| 7- COMMON | | | | | | | | | 7- Transistor ouput 2 | | | | | | | | |
| 8- Analogic output 4 | | | | | | | | | 8- Transistor ouput 3 | | | | | | | | |
| 9- No used | | | | | | | | | 9- Transistor ouput 4 | | | | | | | | |

An example of the wiring of the expansion cards is:

SALIDAS / OUTPUTS




SALIDAS / OUTPUTS



4.7.6.6. Technical Features

| FEATURES | VALUE | UNIT |
|--------------------------------|-----------------------|-----------------|
| ANALOGICAL OUTPUTS | | |
| Output range | ± 5 | mA c.c |
| Lineality | 1 | % |
| Load resistance | < 1000 | Ω |
| Output range | 4000 | points |
| STATIC OUTPUTS | | |
| Nominal voltage | < 100 | Vcc / Vac |
| Non repetitive voltage pk | 350 | V. pk. |
| Nominal current | 100 | mA |
| Maximum power of dissipation | 0,8 | W |
| Maximum R _{ON} | | |
| Repetitive current during t=1s | 120 | mA |
| Maximum current t=10ms | 350 | mA |
| CONNECTIONS | | |
| Wire section | 0,05..1 (AWG 30...18) | mm ² |
| Maximum torque | 0,3 | Nm |
| MECHANICAL | | |
| Protection | IP 20 | |


4.7.7 - PROFIBUS COMMUNICATIONS CARD



Read Section 4.7.0., Inserting Expansion Cards.

4.7.7.1. Profibus card configuration

To access the configuration of the card of profibus protocol, enter the configuration menu (*MENU* ---> *SETUP*). in the *EXP. CARD* menu, select the position where the card is inserted. Press *SET* to enter in the card menu.



This card has no parameters to configure. Only the peripheral number (Slave ID) explained in chapter 4.7.7.3

Going into configuration menu only will appear: *CARD. OK* or *CARD NOK*.

4.7.7.2. Card parameters

To visualize the parameters that CVMk2 shows referring to the profibus communications card, you have to go to the cards menu:

MENU --> *EXP. CARD* --> *CARD X**.

(*) Value 1, 2 or 3, depending on the card position.


The screen shows the parameters:

Periph num 0
 Bus Status ACTIVE / INACTIVE.

The default peripheral number is 0 but it will change to the configured by the user when the communications starts. To configure slave ID see chapter 4.7.7.3.

The bus status shows if the bus is working or not.


4.7.7.3. Slave number configuration



To configure the slave ID of the device we have to use the blue selectors of the card (Slave ID).

The selectors are two to codify the slave number in hexadecimal code. The one HI corresponds to the HI part of the value and the LO one, corresponds to the low part of the code.

See example of the picture:




The different speeds that the card supports are:

- 19,2 kbs
- 93,75 kbs
- 187,5 kbs
- 500 kbs
- 1500 kbs
- 3000 kbs
- 6000 kbs
- 12000 kbs

4.7.7.4. Leds information


The profibus card has two LEDS that indicates the status of the card and the communications bus. When the led are ON indicates some error in expansion card or in communications bus. All the possibilities of the LED's status are showed in the next picture.



On: Led ON means error.

Off: Led OFF means that works correctly

4.7.7.5. Profibus connector



The DB-9 connector has the following configuration:

1. Shield.
2. -.
3. "B" Non inverting input/output signal from profibus.
4. -.
5. "M5" GND. Data reference potential.
6. "P5" 5V supply voltage.
7. -.
8. "A" Inverting input/output signal from profibus.
9. -.

4.7.7.6. GSD Modules

The GSD modules are configured as the table bellow.

The table shows the number of each module, the parameters inside and the total size of the module.

| MOD | PARAMETERS | BYTE | SIZE |
|-----|-----------------------------------|------|------|
| 1 | Single voltages ph-n | 12 | 52 |
| | Phase currents | 12 | |
| | Phase-Phase voltages | 12 | |
| | Power Factor | 12 | |
| | Frequency | 4 | |
| 2 | Power | 48 | 48 |
| 3 | Average values | 12 | 44 |
| | Neutral values | 8 | |
| | Three-phase values | 24 | |
| 4 | Energy | 48 | 48 |
| 5 | THD V / I | 32 | 32 |
| 6 | THD odd / even | 64 | 64 |
| 7 | Unbalanced / Asimetry / Flicker | 44 | 44 |
| 8 | Odd voltage harmonics (15°) | 72 | 72 |
| 9 | Odd current harmonics (15°) | 72 | 72 |
| 10 | Digital Input 1 / Analog Inputs 2 | 64 | 64 |
| 11 | Digital Input 2 / Analog Inputs 3 | 64 | 64 |
| 12 | Digital Input 3 / Analog Inputs 1 | 64 | 64 |
| 13 | Cos φ | 12 | 12 |



The limits of the Profibus protocol to charge the GSD modules are:


- Máximum 4 modules.
- Total maximum size 244 bytes.

5. OTHER SYSTEM CONFIGURATIONS

5.1 PREFERENCES

5.1.1 SCREEN


To configure the screen display preferences, select the *SYSTEM* option on the *MENU*. In *SYSTEM*, drop down the *PREFERENCES* menu and select *DISPLAY*.



To modify the current values, press *EDIT* (F4). The cursor will be positioned in the first line of parameters. Use the up-down arrow buttons to move the cursor to the desired parameter. Press *SET* to enter configuration mode for the desired value.

Use the left/right arrow buttons to navigate from one digit to another and the up/down arrow buttons to increase/decrease the value of the digit where the cursor is currently positioned.

To store the modified parameters in memory, press *SET* and confirm with *OK* (F4). To exit without saving changes press *ESC* (F3).




Parameters that can be modified on this screen follow:

- CONTRAST:** It is possible to change the contrast of the digits displayed on the screen and to adapt the screen to better suit the lighting in the facility. Values that can be entered can vary from *00* to *99*.
- LCD OFF:** Choose between *YES* and *NO*. If *YES* is selected, the screen switchs off is activated to save energy. The screen disconnection time is automatically configured for 5 minutes.
- BACKLIGHT:** Enter the time (in seconds) over which the screen backlighting should be activated. Select on of the following: *10*, *90* or *180*. It is possible to select *ON* or *OFF*. If *ON* is selected, backlighting is always on. If *OFF* is selected, backlighting is always off.
- LANGUARGE:** This indicates the system interface language to be used on screens and menus. It is currently possible to select Spanish, English, French or German.

To store the modified parameters in memory, press *SET* and confirm with *OK* (F4). To exit without saving changes press *ESC* (F3).

5.1.2 CLOCK / TEMPERATURE

To configure the internal system clock, go to *SYSTEM* in *MENU*. In *SYSTEM*, drop down the *PREFERENCES* menu and select *CLOCK/T.*



To modify the current values, press *EDIT* (F4). The cursor will be positioned in the first line of parameters. Use the up-down arrow buttons to move the cursor to the desired parameter. Press *SET* to enter edit mode for the desired value.

Use the left/right arrow buttons to navigate from one digit to another and the up/down arrow buttons to increase/decrease the value of the digit where the cursor is currently positioned. Parameters that can be modified on this screen follow:

TIME: Enter the local time in the system.

DATE: Enter the current date into the system with the format: DAY / MONTH / YEAR.

TEMPERATURE: Select the unit for displaying the temperature. It is possible to choose between $^{\circ}\text{C}$ (Celsius) or $^{\circ}\text{F}$ (Fahrenheit).


To store the modified parameters in memory, press **SET** and confirm with **OK** (F4). To exit without saving changes press **ESC** (F3).



WARNING: CVMk2 has an internal clock that you have to configure. The device will work with this local hour but, if you communicate the device with Power Studio the local time of the device will be changed to UTC hour.

5.1.3 SECURITY

To enter a security password for disabling the system's configuration menu, choose the **SYSTEM** option from the **MENU**. In **SYSTEM**, access the **PREFERENCES** drop down menu and select **SECURITY**.



To modify the current values, press **EDIT** (F4). The cursor will be positioned in the first line of parameters. Use the up-down arrow buttons to move the cursor to the desired parameter. Press **SET** to enter configuration mode for the desired value.

Use the left/right arrow buttons to navigate from one digit to another and the up/down arrow buttons to increase/decrease the value of the digit where the cursor is currently positioned.

Parameters that can be modified on this screen follow:

LOCK: Select whether the password should be activated (**YES**) or deactivated (**NO**).

PASSWORD: Enter the system password in order to make the changes (by default *1234*). The new password should be a four digit number between *0001* and *9999*.

NEW: Enter the new system password. The password should be a four digit number between *0001* and *9999*.

REPEAT: Enter the password again to confirm it.

To store the modified parameters in memory, press *SET* and confirm with *OK* (F4). To exit without saving changes press *ESC* (F3).




WARNING: Changing the password disables the screen, thus not blocking access to the system configuration menus.

5.2. TOOLS

5.2.1 DEVICE

To change the configuration parameters for communication between the screen and the connected module(s), choose the *SYSTEM* option on *MENU*. In *SYSTEM*, access the *TOOLS* drop down menu and select *DEVICE*.



To modify the current values, press *EDIT* (F4). The cursor will be positioned in the first line of parameters. Use the up-down arrow buttons to move the cursor to the desired parameter. Press *SET* to enter edit mode for the desired value.



WARNING: Changing the screen's communication speed can cause communication to be lost with the module(s) that are not connected to the screen at the time the change is made.

Use the left/right arrow buttons to navigate from one digit to another and the up/down arrow buttons to increase/decrease the value of the digit where the cursor is currently positioned.

Parameters that can be modified on this screen follow:

RESET: Select *YES* to restart the screen and start to automatically search for the connected modules.

UPDATE: Select *YES* to leave the screen in standby mode in order to receive the firmware update through the measurement system COM1 port (display).

BAUD RATE: By default 57600. It is recommended not to change this parameter since this could cause communication to be lost with the module(s) that are not connected to the screen.

When the screen indicates that there is a communication error with the module(s), it is recommended to check the communication speed between the screen and the module(s). Over very long distances, it may be necessary to change the speed between the screen and the measurement modules.



WARNING: Before changing the speed, make sure that all the modules are properly connected and functioning. For the modules that are not connected when screen speed is modified, this parameter should be changed individually.

To store the modified parameters in memory, press *SET* and confirm with *OK* (F4). To exit without saving changes press *ESC* (F3).

5.3 MODULES


The **CVMk2** screen automatically recognises the modules that are connected. To begin detecting modules, restart the display screen. Said screen can be restarted by disconnecting it from the power supply (disconnecting the RJ-45 communications connector and the power supply from the display screen) or by resetting it. To do this, access the *SYSTEM* menu in the *TOOLS* option (See chapter 5.2.1 herein) and select *YES* in the *RESET* option. Confirm using the *OK* button.

5.3.1 LIST

The **CVMk2** display screen will generate a list with the serial numbers of the systems it detects when it restarts. This list will always be the same as long as no new systems are entered in the display communications BUS, identified with COM1 on the tag.

The modules detected by the display screen will be assigned an informative peripheral number (*PER. NUM.*). This is an automatically generated number between 1 and 32.

To change the module that is viewed on the display, choose *SYSTEM* from the *MENU*. In *SYSTEM*, access the *MODULES* drop down menu and select the *LIST* option. Then, confirm with the *SET* button.



To view another measurement module, press the *SEL* (F4) button and access the list of connected modules. The cursor will be positioned over the first line, which corresponds with the first module configured in the list.

Use the up-down arrow buttons to move the cursor to the desired module. Press *SET* to enter the desired value.

On the screen a list will outline all measurement modules that have been configured and entered on the screen. The list shows the following parameters.

0123456789 *ABCDEFGHIJ* *YES/NO*

0123456789: This is the serial number of the module detected by the screen.

ABCDEFGHIJ: This is the name configured for this module.


YES/NO: This indicates the module selected to view in the screen.

The name of the module selected is displayed on the upper right hand side of the screen. If another module is selected, the name will change to indicate the measurement module that corresponds with the values currently displayed at any time.

To view the parameters of another module in the list, navigate to the module using the arrow buttons. When the cursor is over the desired module, select it by pressing *SEL* (F4) in order to change the menu option to *YES* and then confirm with *OK*.

5.3.2 SETUP

To change the modules' configuration parameters, choose the *SYSTEM* option on *MENU*. In the *SYSTEM* menu, access the *MODULES* drop down menu and select the *SETUP* option. Then, confirm with the *SET* button.



To modify the current values, press *EDIT* (F4). The cursor will be positioned in the first line of parameters. Use the up-down arrow buttons to move the cursor to the desired parameter and press *SET* to enter edit mode.

Use the left/right arrow buttons to navigate from one digit to another and the up/down arrow buttons to increase/decrease the value of the digit where the cursor is currently positioned.

Parameters that can be viewed on this screen follow:

MOD. NAME: Current name or name to be given to the measurement module. When the parameters of this module are displayed, this name is also displayed in the upper right hand corner of the screen.

MODULE S/N: The module serial number. This number is only informative, not editable.

PER. NUM.: By default, this is 1 when there is only one measurement module connected. This number is automatically generated. It is only informative and cannot be edited. It also indicates the order in which the modules will appear on the *LIST* display screen discussed in Section 5.3.1.


If more than one module is connected, other modules can be modified by pressing the *NEXT* button (F1). This advances the user to the next module in the list, where names can be edited without exiting the edit screen.

6. DISPLAY SCREENS

6.1 MEASURING

6.1.1 MAIN

To access the main display screen from which parameters can be viewed in real time, choose the *MEASURE* option from the *MENU*.



The following variables are displayed on the main measurement screen.


- V. AVG:* Mean value of the three phase-neutral voltages.
- P. TOTAL:* Sum of the real time active power values of the three phases.
- S. TOTAL:* Sum of the real time apparent power values of the three phases.
- FP. AVG:* Three phase power factor
- FREQ:* Frequency of phase 1.

6.1.1.1. System information

The function keys allows to visualize the following information:

INFO : (F1) System Information.

The first window gives information on the parameters configured in the display screen and in the memory.



The following information appears on the screen:

| TEXT | VALUE | DESCRIPTION |
|---------------------|-------------|---|
| Display Version | D-CVMk2-xxx | Firmware version stored in the display screen. |
| S/N Display | ***** | Display screen serial number. |
| Language | Spanish | Language selected. |
| Measurement modules | 01 | Number of modules detected by the display screen. |
| Block | NO | Display screen is or is not password protected. |
| LDC OFF | NO | Display screen turns off with the lighting. |
| Light for | ON | Selected time over which backlighting will be on. |
| Date | **/**/** | Date configured in the module. |
| Time | **.**.**.* | Time configured in the module. |
| Temperature | **.* | Measurement module's internal temperature. |
| Days since reset | *.** | Days since the last reset was performed. |
| Days in operation | *.** | Total days the system has been in operation. |

It is important to refer to this screen, because it provides a summary of the display screen configuration. Accordingly, it is not necessary to navigate through the configuration menus to verify the system's configuration.

- MAXIMUMS:

(F2) This displays the maximum parameters stored in the system memory since the last time the maximum values were reset or since the system was put into operation. (See Section 6.1.1.2. Maximums)
- MINIMUMS:


(F3) This displays the minimum parameters stored in the system memory since the last time the minimum values were reset or since the system was put into operation. (See Section 6.1.1.3. Minimums)

The menus that appear above the function buttons are the following:

EXIT : (F1) Use this button to exit the system information screens. Press this button to return to the main measurement screen from which the current screen was accessed.

MEI : (F2) System Information.

This button is used to display the measurement module configuration screen.



The following information is shown on the measurement system's information display screen.

| TEXT | VALUE | DESCRIPTION |
|--------------------|--------------------------|--|
| Measurement number | 01 / 01 | Module number / total modules connected. |
| Version measured | CVMk2-ITF-405-*** | Module type and firmware version of the same. |
| Measurement name | GENERAL | Edited name for the measurement module. |
| S/N measured | ***** | Module serial number. |
| | | |
| Prim. U | 0000001 | Primary for the programmed voltage transformer. |
| Sec. U | 001 | Secondary for the programmed voltage transformer. |
| Prim. I | 00500 | Primary for the programmed current transformer. |
| Prim. In | 00005 | Primary for the programmed neutral line current transformer. |
| Sec. I | 5 | Secondary for the programmed current transformer. |
| | | |
| Card 1 | NONE*****_ | No card is detected in slot 1. |
| Card 2 | EXP-DIG-8I/40 1.0 | Digital inputs/relay outputs card detected. |
| Card 3 | EX-SD/ETHERNET 1.0 | SD memory and Ethernet card detected. |





The menus that appear above the function buttons on this screen are the following:

EXIT : (F1) Use this button to exit the system information screens. Press this button to return to the main measuring screen from which the current screen was accessed.

DISP : (F2) Press this button to return to the previous screen where the display screen configuration parameters are shown.

6.1.1.2. Maximums

The maximum values are displayed on the screen, along with the date and time when they were recorded for the instantaneous variables.

| Menu Measure Demand Energy | | | |
|---|-------------|----------|----------|
| Measure | Main | | MAX |
| V. avg. | 2302.0 V | 19/04/06 | 10:30:25 |
| P.total | 172.905 kW | 19/04/06 | 10:30:25 |
| S.total | 172.905 kVA | 19/04/06 | 10:30:25 |
| PF. avg. | 0.999 | 19/04/06 | 10:30:25 |
| Freq. | 50.00 Hz | 19/04/06 | 10:30:25 |
| <div> <div>INFO</div> <div>INST</div> <div>MIN</div> <div></div> <div>     </div> </div> | | | |

The following variables are displayed on the maximum values screen:

- V. AVG.:** Maximum value for the mean of the three phase voltages.
- P. TOTAL:** Maximum value of the sum of the real time power values of the three phases.
- S. TOTAL:** Maximum value of the sum of the real time apparent power values of the three phases.
- PF. AVG:** Maximum value for the mean of the three phase power factor.
- FREQ:** Maximum line frequency (referenced from the maximum phase 1 frequency).

When the maximum values are displayed, the exact time and date when they were recorded is displayed with each one of them. These maximum values are referenced to the date when the system was connected. If the maximum values have been deleted, these values make reference to the period since the date when the last delete was performed.

The menus that appear above the function buttons on this screen are the following:

- INFO :** (F1) Press this button to return to the system information screen (section 6.1.1.1. System Information)
- INST:** (F2) Press this button to return to the screen on which the variables' real time values are displayed. (See Section 6.1.1. Main)
- MIN :** (F3) Press this button to exit the maximum values screen and to enter the minimum values screen (See Section 6.1.1.3.).

6.1.1.3. Minimums

This screen displays the minimum values for the variables in real time, along with the date and the time when they were recorded.

| Menu Measure Demand Energy | | | |
|----------------------------|-------------|----------------------|-----|
| Measure | Min | | MIN |
| V. avg. | 2296.5 V | 19/04/06 10:30:25 | |
| P. total | 172.060 kW | 19/04/06 10:30:25 | |
| S. total | 172.060 kVA | 19/04/06 10:30:25 | |
| PF. avg. | 0.999 | 19/04/06 10:30:25 | |
| Freq. | 50.00 Hz | 19/04/06 10:30:25 | |
| INFO MAX INST | | | |

The following variables are displayed on the minimum values screen:

- V. AVG:* Minimum value for the mean of the three phase voltages.
- P. TOTAL:* Minimum value of the sum of the real time power values of the three phases.
- S. TOTAL:* Minimum value of the sum of the real time apparent power values of the three phases.
- PF. AVG:* Minimum value for the mean of the three phase power factor.
- FREQ:* Minimum line frequency (referenced from the minimum phase 1 frequency).

When the minimum values are displayed, the exact time and date when they were recorded is displayed with each one of them.

These minimum values are referenced to the date when the system was connected. If the minimum values have been deleted, these values make reference to the period since the date when the last reset was performed.

The menus that appear above the function buttons on this screen are the following:


INFO : (F1) Press this button to return to the system information screen (Section 6.1.1.1. System Information).

MAX: (F2) Press this button to access the screen that displays the maximum values stored (See section 6.1.1.2.).

INST: (F3) Press this button to return to the previous screen from which the current screen was accessed. The previous screen that displays real time values for the variables. (See Section 6.1.1. Main)

6.1.2 PHASE-NEUTRAL VOLTAGE

Simple voltages referenced to the neutral of each one of the phases are listed on this screen.



The bottom menu offers the following options:

INFO : Press this button to access the system information screen (Section 6.1.1.1., System Information).

MAX: Press this button to access the screen that displays the maximum values stored. Maximum values for each variable recorded since the last reset, along with the date and time of the registry, are displayed on this screen.


On the **MAX** screen, the **INST** option appears, which can be used to return to the screen that displays the instantaneous variables.

MIN : Press this button to access the screen that displays the minimum values stored. Minimum values for each variable recorded since the last reset, along with the date and time of the registry, are displayed on this screen.

On the *MIN* screen, the *INST.* option appears, which can be used to return to the screen that displays the instantaneous variables.

SCOP: Pressing this button will access the screen for the wave form of the voltage between the phases and neutral.

6.1.2.1. Voltage waveform display



The simple or phase-neutral voltage waveform is displayed on this screen. The up/down arrow buttons can be used to navigate inside the screen between the L1, L2 and L3 phases.

Upon accessing the screen, the cursor is situated over L1 and is activated by default. To view the phases, place the cursor over the desired phase and press *SET*. If the phase selected was already activated, pressing *SET* will deactivate it and said phase will no longer be displayed.

Accordingly, the three waveforms on the three phase line can be simultaneously viewed. They can also be grouped according to preference.

The boxes situated on the right side of the screen, which correspond to each phase, provide the RMS value of the simple voltage for each one of the phases.



WARNING: Refreshing screens that display graphics such as waveforms and phasors takes one second. If there is any event that last less than one second or that is not cyclic, it will not be displayed.

The buttons that appear on the bottom menu include:

Zhx1: This button can be pressed to horizontally zoom in on the waveform displayed. This is a cyclic zoom with x1, x2 and x4 options, which then returns to normal.


- $\bar{Z} \times 1$:

This button can be pressed to vertically zoom in on the waveform displayed. This is a cyclic zoom with x1, x2, x4 and x8 options, which then returns to normal.
- HOLD:

This option takes a screen shot of the waveform currently being viewed. The RUN button allows returning to the continuous waveform display mode.
- PHAS:

This accesses the phasors graphical display screen. The phasors display screen only gives the DATA (F4) option on the bottom menu. Pressing DATA will return the user to the screen that displays the variables' real time numeric values. (See Section 6.1.2.)

6.1.2.2 Voltage phasors display



Phasors are graphically displayed on this screen. A table of the most representative numeric values is also displayed on this screen.


| TEXT | VALUE | DESCRIPTION |
|---------|---------|--|
| L1 | 240.0 | RMS value for VL1 |
| L2 | 239.8 | RMS value for VL2 |
| L3 | 240.1 | RMS value for VL3 |
| | | |
| V1 FUND | 230.2 | Value of the phase 1 fundamental. |
| V2 FUND | 230.0 | Value of the phase 2 fundamental. |
| V3 FUND | 230.4 | Value of the phase 3 fundamental. |
| | | |
| Ø 1-2 | 120.4 ° | Angular difference between phases 1 and 2. |
| Ø 2-3 | 120.4 ° | Angular difference between phases 2 and 3. |
| Ø 3-1 | 119.2 ° | Angular difference between phases 3 and 1. |
| | | |
| Freq: | 50.14 | Phase 1 frequency. |



WARNING: It is only possible to navigate through the top menu using the right/left arrow buttons in the numeric display screen (Section 6.1.2.).

6.1.3 PHASE-PHASE VOLTAGE

The instantaneous values of the compound voltages are displayed on this screen, which are the values of voltage between phases.



The menus that appear above the function buttons on this screen are the following:

INFO : Press this button to access the system information screen (Section 6.1.1.1., System Information).

MAX: Press this button to access the screen that displays the maximum values stored. Maximum values for each variable recorded since the last reset, along with the date and time of the registry, are displayed on this screen.


On the **MAX** screen, the **INST.** option appears, which can be used to return to the screen that displays the instantaneous variables.

MIN : Press this button to access the screen that displays the minimum values stored. Minimum values for each variable recorded since the last reset, along with the date and time of the registry, are displayed on this screen.

On the **MIN** screen, the **INST.** option appears, which can be used to return to the screen that displays the instantaneous variables.

6.1.4 CURRENT

Instantaneous values for the currents of each phase and the neutral are displayed on this screen.



NOTE: The neutral line current is that which is measure by the **CVMk2** if a neutral transformer is configured and connected. If no transformer is connected, the system can be programmed to calculate the neutral current.

On this screen, the following options are shown above the function buttons:

INFO : Press this button to access the system information screen (Section 6.1.1.1., System Information).

MAX: Press this button to access the screen that displays the maximum values stored. Maximum values for each variable recorded since the last reset along with the date and time of the registry are displayed on this screen.


On the **MAX** screen, the **INST.** option appears, which can be used to return to the screen that displays the instantaneous variables.

MIN : Press this button to access the screen that displays the minimum values stored. Minimum values for each variable recorded since the last reset along with the date and time of the registry are displayed on this screen.

On the **MIN** screen, the **INST.** option appears, which can be used to return to the screen that displays the instantaneous variables.

SCOP: Pressing **SCOP** will access the waveform screen for the currents of the phases.

6.1.4.1. Current waveform display



The current waveform is displayed on this screen. The up/down arrow buttons can be used to navigate inside the screen to select or deselect each one of the L1, L2 and L3 phases.

Upon accessing the screen, the cursor is situated over L1 and is activated by default. To view the other phases, place the cursor over the desired phase and press *SET*. If the phase selected was already activated, pressing *SET* will deactivate it.

Accordingly, the three waveforms on the three phase line can be simultaneously viewed. They can also be grouped according to preference.

The boxes situated on the right side of the screen, which correspond to each phase, provide the RMS value of the current for each one of the phases.



WARNING: Refreshing screens that display graphics such as waveforms and phasors takes one second. If there is any event that last less than one second or that is not cyclic, it will not be displayed.

The menus that appear above the function buttons on this screen are the following:


Zhx1: Horizontally zoom in on the waveform displayed. This is a cyclic zoom with x1, x2 and x4 options, which then returns to normal.

Zvx1: This button can be pressed to vertically zoom in on the waveform displayed. This is a cyclic zoom with x1, x2, x4 and x8 options, which then returns to start.

HOLD: This option takes a screen shot of the waveform currently being viewed.
The *RUN* button permits returning to the continuous waveform display mode.

PHAS: This access the phasors graphical display screen. The phasors display screen only gives the *DATA* (F4) option on the bottom menu. Pressing *DATA* will return the user to the screen that displays the variables' real time numeric values. (See Section 6.1.4.)

6.1.4.2 Current phasors display



Phasors are graphically displayed in this figure. A table of the most representative numeric values is also displayed on this screen.

| TEXT | VALUE | DESCRIPTION |
|---------|---------|--|
| L1 | 240.0 | RMS value for line 1. |
| L2 | 239.8 | RMS value for line 2. |
| L3 | 240.1 | RMS value for line 3. |
| I1 FUND | 235.2 | Value of the phase 1 fundamental. |
| I2 FUND | 233.5 | Value of the phase 2 fundamental. |
| I3 FUND | 235.6 | Value of the phase 3 fundamental. |
| Ø 1-2 | 120.4 ° | Angular difference between phases 1 and 2. |
| Ø 2-3 | 120.4 ° | Angular difference between phases 2 and 3. |
| Ø 3-1 | 119.2 ° | Angular difference between phases 3 and 1. |
| Freq: | 50.14 | Frequency of the phases (phase 1). |

WARNING: It is only possible to navigate through the top menu using the right/left arrow buttons in the numeric display screen (6.1.4.).

6.1.5 POWERS




WARNING: The CVMk2 power calculation is limited according to the following formula:

$$(\text{Prim V}) \times (\text{Prim I}) < 45.000.000$$

6.1.5.1 Active power

Instantaneous values for the active powers of each phase and the three phase active power (kW) are displayed on this screen.



On this screen, the following options are shown above the function buttons:

INFO : This displays the system information screen (Section 6.1.1.1., System Information).

MAX: This displays the screen with the maximum values stored. The maximum values for each variable recorded since the last reset are displayed on the screen along with the date and time of registry.


On the **MAX** screen, appears the **INST.** option, which can be used to return to the screen that displays the instantaneous variables.

MIN : This displays the screen with the minimum values stored. The minimum values for each variable recorded since the last reset are displayed on the screen along with the date and time of registry.

On the **MIN** screen, appears the **INST.** option, which can be used to return to the screen that displays the instantaneous variables.

6.1.5.2 Inductive Power

Instantaneous values for the inductive powers of each phase and the three phase inductive power (kvar) are displayed on this screen.



On this screen, the following options are shown above the function buttons:

INFO : This displays the system information screen (Section 6.1.1.1., System Information).

MAX : This displays the screen with the maximum values stored. The maximum values for each variable recorded since the last reset are displayed on the screen along with the date and time of registry.


On the **MAX** screen, the **INST.** option appears, which can be used to return to the screen. that displays the instantaneous variables.

MIN : This displays the screen with the minimum values stored. The minimum values for each variable recorded since the last reset are displayed on the screen along with the date and time of registry.

On the **MIN** screen, the **INST.** option appears, which can be used to return to the screen. that displays the instantaneous variables.

6.1.5.3 Capacitive Power

Instantaneous values for the capacitive powers of each phase and the three phase capacitive power (kvar) are displayed on this screen.



On this screen, the following options are shown above the function buttons:

INFO : This displays the system information screen (Section 6.1.1.1., System Information).

MAX: This displays the screen with the maximum values stored. The maximum values for each variable recorded since the last reset are displayed on the screen along with the date and time of registry.


On the *MAX* screen, appears the *INST.* option, which can be used to return to the screen that displays the instantaneous variables.

MIN : This displays the screen with the minimum values stored. The minimum values for each variable recorded since the last reset are displayed on the screen along with the date and time of registry.

On the *MIN* screen, appears the *INST.* option, which can be used to return to the screen that displays the instantaneous variables.

6.1.5.4 Apparent Power

Instantaneous values for the apparent powers of each phase and the three phase apparent power (kV·A) are displayed on this screen.



On this screen, the following options are shown above the function buttons:

INFO : This displays the system information screen (Section 6.1.1.1., System Information).

MAX: This displays the screen with the maximum values stored. The maximum values for each variable recorded since the last reset are displayed on the screen along with the date and time of registry.


On the *MAX* screen, the *INST.* option appears, which can be used to return to the screen. that displays the instantaneous variables.

MIN : This displays the screen with the minimum values stored. The minimum values for each variable recorded since the last reset are displayed on the screen along with the date and time of registry.

On the *MIN* screen, the *INST.* option appears, which can be used to return to the screen. that displays the instantaneous variables.

6.1.5.5 Total Power

The values of the three phase power are displayed on this screen.



On this screen, the following options are shown above the function buttons:

INFO : This displays the system information screen (Section 6.1.1.1., System Information).

MAX: This displays the screen with the maximum values stored. The maximum values for each variable recorded since the last reset are displayed on the screen, along with the date and time of registry.


On the *MAX* screen, the *INST.* option appears, which can be used to return to the screen. that displays the instantaneous variables.

MIN : This displays the screen with the minimum values stored. The minimum values for each variable recorded since the last reset are displayed on the screen, along with the date and time of registry.

On the *MIN* screen, the *INST.* option appears, which can be used to return to the screen. that displays the instantaneous variables.

6.1.6, POWER FACTOR

Real time values for the power factor corresponding to each phase and the total power factor are displayed on this screen.



On this screen, the following options are shown above the function buttons:

INFO : This displays the system information screen (Section 6.1.1.1., System Information).

MAX: This displays the screen with the maximum values stored. The maximum values for each variable recorded since the last reset are displayed on the screen, along with the date and time of registry.


On the **MAX** screen, the **INST.** option appears, which can be used to return to the screen that displays the instantaneous variables.

MIN : This displays the screen with the minimum values stored. The minimum values for each variable recorded since the last reset are displayed on the screen, along with the date and time of registry.

On the **MIN** screen, the **INST.** option appears, which can be used to return to the screen that displays the instantaneous variables.

6.1.7 COS ϕ

Instantaneous values for the cos ϕ value for each phase and the total cos ϕ are displayed on this screen.



On this screen, the following options are shown above the function buttons:

INFO : This displays the system information screen (Section 6.1.1.1., System Information).


MAX: This displays the screen with the maximum values stored. The maximum values for each variable recorded since the last reset are displayed on the screen along with the date and time of registry.

On the *MAX* screen, the *INST.* option appears, which can be used to return to the screen that displays the instantaneous variables.

MIN : This displays the screen with the minimum values stored. The minimum values for each variable recorded since the last reset are displayed on the screen along with the date and time of registry.

On the *MIN* screen, the *INST.* option appears, which can be used to return to the screen that displays the instantaneous variables.

PHAS: This accesses the phasors graphical display screen. The phasors display screen only gives the *DATA* (F4) option on the bottom menu. Pressing *DATA* will return the user to the screen that displays the variables' real time numeric values. (See Section 6.1.6)



Phasors are graphically displayed on this screen along with a table of the most representative numeric values.

| TEXT | VALUE | DESCRIPTION |
|---------|---------|---|
| V1 FUND | 240.0 | Value of the phase 1 voltage fundamental. |
| V2 FUND | 239.8 | Value of the phase 2 voltage fundamental. |
| V3 FUND | 240.1 | Value of the phase 3 voltage fundamental. |
| | | |
| I1 FUND | 235.2 | Value of the phase 1 current fundamental. |
| I2 FUND | 233.5 | Value of the phase 2 current fundamental. |
| I3 FUND | 235.6 | Value of the phase 3 current fundamental. |
| | | |
| Ø V1-I2 | 120.4 ° | Angular difference between phase 1 voltage and current. |
| Ø V2-I3 | 120.4 ° | Angular difference between phase 2 voltage and current. |
| Ø V3-I1 | 119.2 ° | Angular difference between phase 3 voltage and current. |
| | | |
| Freq: | 50.14 | Frequency of the phases (phase 1). |


6.2. DEMAND

On the *DEMAND* screen, the user can select the *DEMAND* to be displayed. This corresponds to the desired fee from among all those that are configured.

If no tariff has been configured, number 1 will be chosen by default.

The following parameters are displayed for all tariff on the *DEMAND* screen.

| | |
|------------------|--------------------------------------|
| <i>P. TOTAL:</i> | Total active power for the tariff. |
| <i>S. TOTAL:</i> | Total apparent power for the tariff. |
| <i>I1:</i> | Phase 1 current |
| <i>I2:</i> | Phase 2 current |
| <i>I3:</i> | Phase 3 current |
| <i>I. AVG:</i> | Mean for the three phase currents. |



On this screen, the following options are shown above the function buttons:

INFO : This displays the system information screen (Section 6.1.1.1., System Information).

MAX: This displays the screen with the maximum values stored. The maximum values for each variable recorded since the last reset are displayed on the screen along with the date and time of registry.

On the *MAX* screen, the *INST.* option appears, which can be used to return to the screen that displays the instantaneous variables.



The maximum demand values stored in memory are displayed on the MAX screen.

6.3 ENERGY

The energy menu has the following options:

- CURRENT:** This is the energy accumulated to date. Within this option it is possible to break down the tariff or to display a total for all the tariff.
- MONTHLY:** **CVMk2** stores the closing data for energy consumed during the previous month in its internal memory. This energy data stored from the previous month can also be broken down by tariff, or the total counter can be displayed.
- YEARLY:** Along the same lines, the **CVMk2** saves data to its memory relating to the energy consumed up to the previous year. This data can be broken down by tariff, or the total counter can be displayed.

The energy data display screen is the same for all options displayed in the energy menu.

Consumption and generation values are displayed for all energy that is measured by the analyzer.

6.3.1 PRESENT ENERGY

| Menu | Measure | Demand | Energy |
|----------|-----------------|--------|--------|
| Energy | Current » Total | | |
| kWh | 00000000 | .114 | kWh |
| kvarLh | 00000000 | .016 | kvarh |
| kvarCh | 00000000 | .014 | kvarh |
| kVAh | 00000000 | .114 | kVAh |
| kWh - | 00000000 | .000 | kWh |
| kvarLh - | 00000000 | .000 | kvarh |
| kvarCh - | 00000000 | .000 | kvarh |
| kVAh - | 00000000 | .000 | kVAh |
| INFO | | | |

All energy accumulated, being generated and being consumed is displayed on the screen. The user can select total, which will display the total energy accumulated in all counters, or the user can select each fee schedule separately.

6.3.2 MONTH ENERGY

| Menu | Measure | Demand | Energy |
|----------|-----------------|--------|--------|
| Energy | Monthly » Total | | |
| kWh | 00000000 | .000 | kWh |
| kvarLh | 00000000 | .000 | kvarh |
| kvarCh | 00000000 | .000 | kvarh |
| kVAh | 00000000 | .000 | kVAh |
| kWh - | 00000000 | .000 | kWh |
| kvarLh - | 00000000 | .000 | kvarh |
| kvarCh - | 00000000 | .000 | kvarh |
| kVAh - | 00000000 | .000 | kVAh |
| INFO | | | |

CVMk2 stores the energy value accumulated up to the last day of the previous month. This stored energy value is kept in a totaling meter and in the partial meter for all tariff that have been configured.


6.3.3 YEARLY ENERGY

| Menu | Measure | Demand | Energy |
|----------|----------------|--------|--------|
| Energy | Yearly » Total | | |
| kWh | 00000000 | .000 | kWh |
| kvarLh | 00000000 | .000 | kvarh |
| kvarCh | 00000000 | .000 | kvarh |
| kVAh | 00000000 | .000 | kVAh |
| kWh - | 00000000 | .000 | kWh |
| kvarLh - | 00000000 | .000 | kvarh |
| kvarCh - | 00000000 | .000 | kvarh |
| kVAh - | 00000000 | .000 | kVAh |
| INFO | | | |

CVMk2 stores the energy value accumulated up to the previous year. This stored energy value is kept in a totaling meter and in the partial meter for all tariff that have been configured.

6.4 EXPANSION CARDS


In order to view the status of the expansion card inputs or outputs, navigate to *CARDS* on the *MENU*, and select the *CARDS* option. Then, select the appropriate option on the top menu (card 1, card 2 or card 3), depending on the position in which the card to be displayed is inserted.



If there is no card inserted in the position selected or the card is not recognised, the *NO CARD* message will be displayed.

6.4.1 CARD WITH 8 DIGITAL INPUTS / 8 OUTPUTS

If a position is selected in which a static digital input / output card is inserted, the following screen will be displayed.



The figure provides the status of the digital inputs or the number of pulses received in each one of the inputs, depending on how the inputs were configured.

6.4.2 CARD WITH 8 RELAY INPUTS / 4 OUTPUTS

If a position is selected in which a static relay input / output card is inserted, the following screen will be displayed.

| Menu | Card 1 | Card 2 | Card 3 |
|--------|----------|--------|--------|
| Card 1 | Card 1 | | |
| IN 01 | 00000000 | | |
| IN 02 | 00000000 | | |
| IN 03 | 00000000 | | |
| IN 04 | 00000000 | | |
| IN 05 | 00000000 | | |
| IN 06 | 03979776 | | |
| IN 07 | 90225152 | | |
| IN 08 | 20800000 | | |
| INFO | | | |

The figure provides the status of the digital inputs or the number of pulses received in each one of the inputs, depending on how the inputs were configured.

6.4.3 CARD WITH 8 ANALOGUE INPUTS / 4 OUTPUTS


If a position is selected in which a analogue input / output card is inserted, the following screen will be displayed.

| Menu | Card 1 | Card 2 | Card 3 |
|----------|----------|--------|--------|
| Card 3 | Card 3 | | |
| AD IN 01 | 00000001 | | |
| AD IN 02 | 00000001 | | |
| AD IN 03 | 00000001 | | |
| AD IN 04 | 00000001 | | |
| AD IN 05 | 00000001 | | |
| AD IN 06 | 00000001 | | |
| AD IN 07 | 00000001 | | |
| AD IN 08 | 00000001 | | |
| INFO | | | |

The status of the analogue inputs is displayed on the screen along with the values configured in the configuration menu.

6.4.4 SD-ETHERNET AND SD MEMORY CARD

If a position is selected in which an Ethernet communication and SD memory card is inserted, the following screen will be displayed.




The memory card status and registry values such as the following are displayed on the screen:

| | |
|----------------------|---|
| <i>MEMORY SPACE:</i> | Real capacity of the SD card. |
| <i>REGISTRY:</i> | Days recorded since start or from the last format. |
| <i>EVENTS:</i> | Number of voltage events detected since start or since the last format. |
| <i>FREE:</i> | Percentage of free memory space. |
| <i>STATUS:</i> | Memory status. |

- a) *SD OK:* The card is functioning properly
- b) *NO SD:* There is no card inserted.
- c) *WRITE PROT:* The card is write protected.
- d) *ERROR:* There is a problem with the SD card memory, and it should be formatted.

6.4.5 SD MEMORY CARD

If a position is selected in which an SD memory card is inserted, the following screen will be displayed.



The memory card status and registry values such as the following are displayed on the screen:

- MEMORY SPACE:* Real capacity of the SD card.
- REGISTRY:* Days recorded since start or from the last format.
- EVENTS:* Number of voltage events detected since start or since the last format.
- FREE:* Percentage of free memory space.
- STATUS:* Memory status.
- a) *SD OK:* The card is functioning properly
 - b) *NO SD:* There is no card inserted.
 - c) *WRITE PROT:* The card is write protected.
 - d) *ERROR:* There is a problem with the SD card memory, and it should be formatted.

6.4.6 ANALOGUE \pm 5 MA AND STATIC OUTPUTS CARD

If a position is selected in which an analogue and static outputs card is inserted, the following screen will be displayed. *CARD OK* when the card is working correctly and *CARD NOK* when there is any problem



6.4.7 PROFIBUS COMMUNICATIONS CARD

If a position is selected in which a profibus communications card is inserted, the following messages will be displayed in the screen.


| | |
|-------------------|---------------------------|
| <i>PERIPH. N°</i> | <i>0</i> |
| <i>BUS STATUS</i> | <i>ACTIVE / INACTIVE.</i> |

The peripheral number is *0*, but when the communications starts this value changes to the slave number configured by the user (See chapter 4.7.7.3).

The status bus shows if the bus is working or not.

7. QUALITY


To access and display the parameters from the quality menu, navigate to *QUALITY* in the main *MENU*.



This quality menu is divided in two parts: harmonics and disturbances.

7.1 HARMONICS

There are two large parts in the harmonics menu. One for voltage and another for current. These two large blocks are then subdivided into harmonic distortion rate and harmonic decomposition rate.



7.1.1 VOLTAGE THD

Depending on how the values are set to be displayed or on which values are to be displayed, various options can be chosen in the U THD menu.

The possible option in the voltage THD menu follow:

THD: This displays the total harmonic distortion for voltage as a % for each one of the phases and the neutral.

ODDS: The displays the voltage THD value as a % for all phases and the neutral, but it only displays odd harmonics

EVEN: The displays the voltage THD value as a % for all phases and the neutral, but it only displays even harmonics

On this screen, the following options are shown above the function buttons:

INFO : This displays the system information screen (Section 6.1.1.1., System Information).

MAX: This displays the screen with the maximum values stored. The maximum values for each variable recorded since the last reset are displayed on the screen, along with the date and time of registry.

On the *MAX* screen, the *INST.* option appears, which can be used to return to the screen that displays the instantaneous variables.

MIN : This displays the screen with the minimum values stored. The minimum values for each variable recorded since the last reset are displayed on the screen, along with the date and time of registry.

On the *MIN* screen, the *INST.* option appears, which can be used to return to the screen that displays the instantaneous variables.

7.1.2 CURRENT THD


The harmonics menu is also divided in two blocks: one for voltage and one for current. These parts include the voltage and current harmonic distortion rate and the harmonic decomposition for both.

The possible option in the current THD menu follow:

THD: This displays the total harmonic distortion for current as a % for each one of the phases and the neutral.

ODDS: This displays the current THD value as a % for all phases and the neutral, but it only displays odd harmonics

EVEN5: This displays the current THD value as a % for all phases and the neutral, but it only displays even harmonics



On this screen, the following options are shown above the function buttons:

INFO : This displays the system information screen (Section 6.1.1.1., System Information).

MAX: This displays the screen with the maximum values stored. The maximum values for each variable recorded since the last reset are displayed on the screen, along with the date and time of registry.

On the **MAX** screen, the **INST.** option appears, which can be used to return to the screen that displays the instantaneous variables.

MIN : This displays the screen with the minimum values stored. The minimum values for each variable recorded since the last reset are displayed on the screen, along with the date and time of registry.

On the **MIN** screen, the **INST.** option appears, which can be used to return to the screen that displays the instantaneous variables.

7.1.3 VOLTAGE HARMONICS

In the voltage harmonic decomposition screen, numerical values are shown for the phase 1 harmonic decomposition.

| Menu | | Harmonics | Disturb | | | |
|-------------|--|-----------|---------|------|------|------|
| Harmonics R | | THD U >> | | | | |
| | | THD I >> | | | | |
| FUND U1 | | Har. U | H11 | H21 | H31 | H41 |
| 2300.9V | | Har. I | 11.4 | 21.4 | 31.4 | 41.4 |
| | | | 20.4 | 12.4 | 22.4 | 32.4 |
| THD U1 | | | 50.4 | 13.4 | 23.4 | 33.4 |
| 10.4% | | | 30.4 | 14.4 | 24.4 | 34.4 |
| | | | 60.4 | 15.4 | 25.4 | 35.4 |
| THDU1 O. | | | 40.4 | 16.4 | 26.4 | 36.4 |
| 6.6% | | | 70.4 | 17.4 | 27.4 | 37.4 |
| | | | 8.4 | 18.4 | 28.4 | 38.4 |
| THDU1 E. | | | 9.4 | 19.4 | 29.4 | 39.4 |
| 4.5% | | | 10.4 | 20.4 | 30.4 | 40.4 |
| | | | | | 50.4 | |
| INFO | | NEXT | | GRAP | | |

The values are displayed in columns of 10, and the most important values are shown on the left side of the screen as a %. These values are :

U1 FUND: Value of the phase 1 fundamental.

U1 THD: Value of the phase 1 harmonic distortion rate expressed as a %.

ODD U1 THD: Value of the harmonic distortion rate for the phase 1 odd harmonics, expressed as a %.

EVEN U1 THD: Value of the harmonic distortion rate for the phase 1 even harmonics, expressed as a %.

The bottom menu offers the following buttons:


INFO : This displays the system information screen (Section 6.1.1.1., System Information).

NEXT: This displays the screen of values corresponding with the next phase. This is a rotating menu that contains phase 1, phase 2, phase 3 and neutral.

Values provided on this screen are real time values that correspond using the mean value calculated from the signal samples.

GRAP: This graphically displays the harmonics spectrum.

The phase displayed on the graphical interface corresponds to the one that was selected for numerical values on the previous screen. The options permitted by the graphical interface include: changing between viewing all harmonic values, odd harmonic values and even harmonic values.



The graphics screen menu has the following options.

Zvx1: This button can be pressed to vertically zoom in on the graphic displayed. This is a cyclic zoom with x1, x2, x4 and x10 options, which then returns to normal.

HOLD: This keeps the screen from refreshing. When this button is pressed, the menu on the bottom of the screen will change. Specifically, the button *RUN* (F3). The *RUN* button permits returning to the continuous graphical display.

DATA: Pressing *DATA* will return the user to the screen that displays the real time harmonic decomposition values. (See Section 7.1.3.)

To select total, odd or even harmonics on the graphical interface, use the up/down arrow buttons to navigate between the three options on the right side of the screen.

The bottom menu on the graphical display is the same for all three options. The menu can only be changed by returning to the screen of numerical values and pressing *DATA*.

If the user desires to view the values for the harmonics of another phase in graphical form, he or she should navigate to the numerical values screen, change to the preferred phase using the *NEXT* button and access the graphical interface by pressing *GRAP*.

7.1.4 CURRENT HARMONICS

In the current harmonic decomposition screen, numerical values are shown for the phase 1 harmonic decomposition.

| Menu | Harmonics | Disturb | | | |
|-----------------|-----------|------------|------------|------------|------------|
| Harmonics H1 | THD U >> | | | | |
| | THD I >> | | | | |
| | Har. U | | | | |
| | Har. I | | | | |
| FUND I1 | | H11 | H21 | H31 | H41 |
| 249.750A | | 11.5 | 21.5 | 31.5 | 41.5 |
| | 20.5 | 12.5 | 22.5 | 32.5 | 42.5 |
| THD I1 | 50.5 | 13.5 | 23.5 | 33.5 | 43.5 |
| 30.1% | 30.5 | 14.5 | 24.5 | 34.5 | 44.5 |
| | 60.5 | 15.5 | 25.5 | 35.5 | 45.5 |
| THDI1 O. | 40.5 | 16.5 | 26.5 | 36.5 | 46.5 |
| 16.3% | 70.5 | 17.5 | 27.5 | 37.5 | 47.5 |
| | 8.5 | 18.5 | 28.5 | 38.5 | 48.5 |
| THDI1 E. | 9.5 | 19.5 | 29.5 | 39.5 | 49.5 |
| 14.2% | 10.5 | 20.5 | 30.5 | 40.5 | 50.5 |
| INFO | NEXT | | GRAP | | |

The values are displayed in columns of 10, and the most important values are shown on the left side of the screen as a %. These values are :

I1 FUND: Phase 1 fundamental value.

I1 THD: Phase 1 harmonic distortion rate value, expressed as a %.

ODD I1 THD: Value of the harmonic distortion rate for the phase 1 odd harmonics, expressed as a %.

EVEN I1 THD: Value of the harmonic distortion rate for the phase 1 even harmonics, expressed as a %.

The bottom menu offers the following options:


INFO : This displays the system information screen (Section 6.1.1.1., System Information).

NEXT: This displays the screen of values corresponding with the next phase. This is a rotating menu that contains phase 1, phase 2, phase 3 and neutral.

Values provided on this screen are real time values that correspond using the mean value calculated from the signal samples.

GRAP: This graphically displays the harmonics spectrum.

The phase displayed on the graphical interface corresponds to the one that was selected for numerical values on the previous screen. The options permitted by the graphical interface include: changing between viewing all harmonic values, odd harmonic values and even harmonic values.



The graphics screen menu has the following options.

Zvx1: This button can be pressed to vertically zoom in on the graphic displayed. This is a cyclic zoom with x1, x2, x4 and x10 options, which then returns to normal.

HOLD: This keeps the screen from refreshing. Pressing this button will change the bottom of the screen. Specifically, the *RUN* button (F3). The *RUN* button permits returning to the continuous graphical display.

DATA: Pressing *DATA* will return the user to the screen that displays the numerical values for real time harmonic decomposition. (See Section 7.1.4.)


To select total, odd or even harmonics on the graphical interface, use the up/down arrow buttons to navigate between the three options on the right side of the screen.

The bottom menu on the graphical display is the same for all three options. The menu can only be changed by returning to the screen of numerical values and pressing *DATA*.

If the user desires to view the values for the harmonics of another phase in graphical form, should navigate to the numerical values screen, change to the preferred phase using the *NEXT* button and access the graphical interface by pressing *GRAP*.

7.2. DISTURBANCES

To access and display the variables from the quality menu, navigate to *QUALITY* in the main menu. In *QUALITY* menu, select the *DISTURBANCES* option.



The disturbances menu allows configuring the following options:

FLICKER: Flicker calculation. Weighted average and PST.

K FACTOR: Calculation of the K factor for the currents.

UNBALANCE.: Unbalance and asymmetry for voltages and currents.

CREST F.: Calculation of the crest factor for the voltages.

7.2.1 FLICKER

Flicker measures the low frequency voltage fluctuations (between 5 and 25 Hz).


The *FLICKER* menu permits selecting one of two methods for displaying the calculated values.

The options are PST calculation and instantaneous calculation.

7.2.1.1 PST Calculation

The flicker PST value is calculated by integrating the real time perceptibility every 10 minutes. The power supply standards recommend a value of less than 1.

The result is provided as a % in reference to the three phases.




The bottom menu offers the following options:

INFO : This displays the system information screen (Section 6.1.1.1., System Information).

7.2.1.2 Real Time Weighted Average Calculation

The real time flicker calculation is made using a weighted average (WA) of the real time values.

The result is given in real time weighted average values from which the PST is calculated.



The bottom menu offers the following options:


INFO : This displays the system information screen (Section 6.1.1.1, System Information).

7.2.2 K FACTOR

The K factor is calculated in accordance with the ANSI C57.110 standard.

This parameter indicates the additional power required or power lost by the transformer due to the current harmonics produced by the non-linear loads that are connected. This factor is related to the main transformer and its power efficiency, indicating if is necessary expansion or reduction.

For linear loads, the normal K factor value is 1.



The bottom menu offers the following options:

INFO : This displays the system information screen (Section 6.1.1.1., System Information).

MAX: This displays the screen with the maximum values stored. The maximum values for each variable recorded since the last reset are displayed on the screen, along with the date and time of registry.

On the *MAX* screen, the *INST.* option appears, which can be used to return to the screen that displays the real time values.


MIN : This displays the screen with the minimum values stored. The minimum values for each variable recorded since the last reset are displayed on the screen, along with the date and time of registry.

On the *MIN* screen, appears the *INST.* option, which can be used to return to the screen that displays the real time values.

7.2.3 UNBALANCE AND ASYMMETRY

Imbalance is calculated by applying the Fortescue and Stokvis symmetric components method. These values represent how imbalanced the facility is and the correct connection of the phases.

These values are displayed on the screen as a %. The following variables are displayed on the screen.



Kd U: Voltage imbalance coefficient.

Ka U: Voltage asymmetry coefficient.

Kd I: Current imbalance coefficient.

Ka I: Current asymmetry coefficient.

On this screen, the following options are shown above the function buttons:

INFO: This displays the system information screen (Section 6.1.1.1., System Information).

MAX: This displays the screen with the maximum values stored. The maximum values for each variable recorded since the last reset are displayed on the screen along with the date and time of registry.

On the *MAX* screen, the *INST.* option appears, which can be used to return to the screen that displays the instantaneous variables.

MIN: This displays the screen with the minimum values stored. The minimum values for each variable recorded since the last reset are displayed on the screen along with the date and time of registry.


On the *MIN* screen, the *INST.* option appears, which can be used to return to the screen that displays the instantaneous variables.

7.2.4 CREST FACTOR

The crest factor calculation is the ratio between peak and RMS values. When the signal is sinusoidal, the crest factor value is 1.41 (square root of 2).

The crest factor calculation is used to detect periodic voltage disturbances that cannot be detected with the THD.

These values are displayed on the screen as a %. The following variables are displayed on the screen.



On this screen, the following options are shown above the function buttons:

INFO : This displays the system information screen (Section 6.1.1.1., System Information).

MAX: This displays the screen with the maximum values stored. The maximum values for each variable recorded since the last reset are displayed on the screen along with the date and time of registry.

On the **MAX** screen, the **INST.** option appears, which can be used to return to the screen that displays the instantaneous variables.

MIN : This displays the screen with the minimum values stored. The minimum values for each variable recorded since the last reset are displayed on the screen along with the date and time of registry.

On the **MIN** screen, the **INST.** option appears, which can be used to return to the screen that displays the instantaneous variables.

8. COMMUNICATIONS

8.1. MODBUS/RTU PROTOCOL ©

CVMk2 uses the Modbus/RTU © as the communications protocol on the COM2 port. This is a question-response based protocol. The question frame format is:

NPAAXXXYYYY CRC.

PN: The number of the peripheral configured for the system.

AA: Modbus function to be executed.

XXXX: System's memory position where the function should be begin. (Example: If AA=04 the function is read only).

YYYY: Read positions, from the XXXX position, to be read or written. (This depends on the AA function).

CRC: Code for detecting 16 bit errors. (automatically generated).

The response format is

NPAABBCCCC..CRC

PN: Number of the peripheral that responds

AA: Function that responds.

BB: Number of bytes in the response.

CCCC: Registry value.

...

CRC: Error detection registry.


For more information, see the standard Modbus© protocol.

8.2. CONNECTION DIAGRAM

8.2.1. CIRCUTOR INTELLIGENT CONVERTER


CVMk2 has an RS-485 port with Modbus/RTU protocol communications. This port is to communicate the master or PC with the measurement module.

The connection with the measurement module using an intelligent converter is displayed in the figure.



8.2.2. TCP2RS CONVERTER

The connection with the measurement module using an Ethernet converter is displayed in the figure. This converter permits using the Modbus/TCP protocol. To communicate with the ethernet converter, the IP address configured has to be in the same range than the computer and configured with the same baudrate in the XPORT that the device. (See chapter 4.6 Communications)




8.2.3. USB CONVERTER

The connection between the PC and the measurement module using a USB to RS-485 converter is showed in the figure below.

| CONNECTOR | | DESCRIPTION |
|-----------|---|-------------|
| 1 | + | RS-485 - |
| | - | RS-485 + |
| 2 | + | RS-485 - |
| | - | RS-485 + |
| G | | Ground |


The USB converter output pins are described in the following table.



8.2.4 SCREEN-MODULES COMMUNICATIONS BUS

The other communications bus is set up by the COM1 port (DISPLAY). This bus allows the communications between the screen (master) and modules, and has the same features as the RS-485. One important consideration is the maximum distance of 1.200 m from the master (in this case the display) to the last slave and the number of measurement modules (slaves) that can be connected to the bus, which is 32.

This communication between display and measure modules is proprietary communications protocol.



8.3. MODBUS/RTU © MEMORY MAP

8.3.1 ELECTRIC VARIABLES

| MODBUS ELECTRICAL VARIABLES | | | | | | |
|-----------------------------|--------------|-----|-------|---------|---------|---------|
| VARIABLE | SYMBOL | COD | INST. | MAX. | MIN. | UNIT |
| PHASE 1 | | | | | | |
| Phase voltage | V 1 | 1 | 00-01 | 100-103 | 300-303 | V x100 |
| Current | A 1 | 2 | 02-03 | 104-107 | 304-307 | mA x10 |
| Active power | kW 1 | 3 | 04-05 | 108-10B | 308-30B | W x10 |
| Inductive reactive power | KvarL 1 | 4 | 06-07 | 10C-10F | 30C-30F | W x10 |
| Capacitive reactive power | KvarC 1 | 5 | 08-09 | 110-113 | 310-313 | W x10 |
| Apparent power | kV·A1 | 6 | 0A-0B | 114-117 | 314-317 | VA x10 |
| Power factor | PF 1 | 7 | 0C-0D | 118-11B | 318-31B | x1000 |
| Cos φ | Cos φ 1 | 8 | 0E-0F | 11C-11F | 31C-31F | x1000 |
| PHASE 2 | | | | | | |
| Phase voltage | V 2 | 9 | 10-11 | 120-123 | 320-323 | V x100 |
| Current | A 2 | 10 | 12-13 | 124-127 | 324-327 | mA x10 |
| Active power | kW 2 | 11 | 14-15 | 128-12B | 328-32B | W x10 |
| Inductive reactive power | KvarL 2 | 12 | 16-17 | 12C-12F | 32C-32F | W x10 |
| Capacitive reactive power | KvarC 2 | 13 | 18-19 | 130-133 | 330-333 | W x10 |
| Apparent power | kV·A2 | 14 | 1A-1B | 134-137 | 334-337 | VA x10 |
| Power factor | PF 2 | 15 | 1C-1D | 138-13B | 338-33B | x1000 |
| Cos φ | Cos φ 2 | 16 | 1E-1F | 13C-13F | 33C-33F | x1000 |
| PHASE 3 | | | | | | |
| Phase voltage | V 3 | 17 | 20-21 | 140-143 | 340-343 | V x100 |
| Current | A 3 | 18 | 22-23 | 144-147 | 344-347 | mA x10 |
| Active power | kW 3 | 19 | 24-25 | 148-14B | 348-34B | W x10 |
| Inductive reactive power | KvarL 3 | 20 | 26-27 | 14C-14F | 34C-34F | W x10 |
| Capacitive reactive power | KvarC 3 | 21 | 28-29 | 150-153 | 350-353 | W x10 |
| Apparent power | kV·A3 | 22 | 2A-2B | 154-157 | 354-357 | V·A x10 |
| Power factor | PF 3 | 23 | 2C-2D | 158-15B | 358-35B | x1000 |
| Cos φ | Cos φ 3 | 24 | 2E-2F | 15C-15F | 35C-35F | x1000 |
| NEUTRAL | | | | | | |
| Neutral voltage | U_N | 25 | 30-31 | 160-163 | 360-363 | V x100 |
| Neutral line current | I_N | 26 | 32-33 | 164-167 | 364-367 | mA x10 |
| Frequency (L1) | Hz | 27 | 34-35 | 168-16B | 368-36B | Hz x100 |
| L1-L2 ph voltage | V12 | 28 | 36-37 | 16C-16F | 36C-36F | V x100 |
| L2-L3 ph voltage | V23 | 29 | 38-39 | 170-173 | 370-373 | V x100 |
| L3-L1 ph voltage | V31 | 30 | 3A-3B | 174-177 | 374-377 | V x100 |
| Average phase voltage | U_{n_AVG} | 31 | 3C-3D | 178-17B | 378-37B | V x100 |
| Average line voltage | U_{p_AVG} | 32 | 3E-3F | 17C-17F | 37C-37F | V x100 |
| Average current | I_{AVG} | 33 | 40-41 | 180-183 | 380-383 | mA x10 |
| Three phase active power | kW III | 34 | 42-43 | 184-187 | 384-387 | W x10 |

| VARIABLE | SYMBOL | COD | INST. | MAX. | MIN. | UNIT |
|------------------------------|----------------|-----|-------|---------|---------|-------|
| Three phase inductive power | KvarL III | 35 | 44-45 | 188-18B | 388-38B | Wx10 |
| Three phase capacitive power | KvarC III | 36 | 46-47 | 18C-18F | 38C-38F | Wx10 |
| Three phase apparent power | KvaIII | 37 | 48-49 | 190-193 | 390-393 | Wx10 |
| Three phase power factor | PFIll | 38 | 4A-4B | 194-197 | 394-397 | x1000 |
| Cos ϕ three phase | Cos ϕ III | 39 | 4C-4D | 198-19B | 398-39B | x1000 |
| THD U_1 | THD U_1 | 40 | 4E-4F | 19C-19F | 39C-39F | %x10 |
| THD U_2 | THD U_2 | 41 | 50-51 | 1A0-1A3 | 3A0-3A3 | %x10 |
| THD U_3 | THD U_3 | 42 | 52-53 | 1A4-1A7 | 3A4-3A7 | %x10 |
| THD U_N | THD U_N | 43 | 54-55 | 1A8-1AB | 3A8-3AB | %x10 |
| THD I_1 | THD I_1 | 44 | 56-57 | 1AC-1AF | 3AC-3AF | %x10 |
| THD I_2 | THD I_2 | 45 | 58-59 | 1B0-1B3 | 3B0-3B3 | %x10 |
| THD I_3 | THD I_3 | 46 | 5A-5B | 1B4-1B7 | 3B4-3B7 | %x10 |
| THD I_N | THD I_N | 47 | 5C-5D | 1B8-1BB | 3B8-3BB | %x10 |
| THD- U_1 Even | THD U_1 -E | 48 | 5E-5F | 1BC-1BF | 3BC-3BF | %x10 |
| THD- U_2 Even | THD U_2 -E | 49 | 60-61 | 1C0-1C3 | 3C0-3C3 | %x10 |
| THD- U_3 Even | THD U_3 -E | 50 | 62-63 | 1C4-1C7 | 3C4-3C7 | %x10 |
| THD- U_N Even | THD U_N -E | 51 | 64-65 | 1C8-1CB | 3C8-3CB | %x10 |
| THD- I_1 Even | THD I_1 E | 52 | 66-67 | 1CC-1CF | 3CC-3CF | %x10 |
| THD- I_2 Even | THD I_2 E | 53 | 68-69 | 1D0-1D3 | 3D0-3D3 | %x10 |
| THD- I_3 Even | THD I_3 E | 54 | 6A-6B | 1D4-1D7 | 3D4-3D7 | %x10 |
| THD- I_N Even | THD I_N E | 55 | 6C-6D | 1D8-1DB | 3D8-3DB | %x10 |
| THD- U_1 Odd | THDU1-O | 56 | 6E-6F | 1DC-1DF | 3DC-3DF | %x10 |
| THD- U_2 Odd | THDU2-O | 57 | 70-71 | 1E0-1E3 | 3E0-3E3 | %x10 |
| THD- U_3 Odd | THDU3-O | 58 | 72-73 | 1E4-1E7 | 3E4-3E7 | %x10 |
| THD- U_N Odd | THD U_N -O | 59 | 74-75 | 1E8-1EB | 3E8-3EB | %x10 |
| THD- I_1 Odd | THD I_1 O | 60 | 76-77 | 1EC-1EF | 3EC-3EF | %x10 |
| THD- I_2 Odd | THD I_2 O | 61 | 78-79 | 1F0-1F3 | 3F0-3F3 | %x10 |
| THD- I_3 Odd | THD I_3 O | 62 | 7A-7B | 1F4-1F7 | 3F4-3F7 | %x10 |
| THD- I_N Odd | THD I_N O | 63 | 7C-7D | 1F8-1FB | 3F8-3FB | %x10 |
| U Unbalance | Kd U | 64 | 7E-7F | 1FC-1FF | 3FC-3FF | %x10 |
| U Asymmetry | Ka U | 65 | 80-81 | 200-203 | 400-403 | %x10 |
| I Unbalance | Kd I | 66 | 82-83 | 204-207 | 404-407 | %x10 |
| I Asymmetry | Ka I | 67 | 84-85 | 208-20B | 408-40B | %x10 |
| Temperature | T | 68 | 86-87 | 20C-20F | 40C-40F | °Cx10 |
| V1 WA real time flicker | WA_V1 | 69 | 88-89 | | | %x10 |
| V2 WA real time flicker | WA_V2 | 70 | 8A-8B | | | %x10 |
| V3 WA real time flicker | WA_V3 | 71 | 8C-8D | | | %x10 |
| V1 PST statistical flicker | PST_V1 | 72 | 8E-8F | | | %x10 |
| V2 PST statistical flicker | PST_V2 | 73 | 90-91 | | | %x10 |
| V3 PST statistical flicker | PST_V3 | 74 | 92-93 | | | %x10 |
| K Factor I1 | K-Fac_I1 | 75 | 94-95 | 228-22B | 428-42B | x100 |
| K Factor I2 | K-Fac_I2 | 76 | 96-97 | 22C-22F | 42C-42F | x100 |

| | | | | | | |
|----------------------------|------------|----|-------|---------|---------|--------|
| K Factor I3 | K-Fac_I3 | 77 | 98-99 | 230-233 | 430-433 | x100 |
| Crest Factor V1 | Cr-Fac_V1 | 78 | 9A-9B | 234-237 | 434-437 | x100 |
| Crest Factor V2 | Cr-Fac_V2 | 79 | 9C-9D | 238-23B | 438-43B | x100 |
| Crest Factor V3 | Cr-Fac_V3 | 80 | 9E-9F | 23C-23F | 43C-43F | x100 |
| Reactive Power L1 | Kvar1 | 81 | A0-A1 | 240-243 | 440-443 | varx10 |
| Reactive Power L2 | Kvar2 | 82 | A2-A3 | 244-247 | 444-447 | varx10 |
| Reactive Power L3 | Kvar3 | 83 | A4-A5 | 248-24B | 448-44B | carx10 |
| Potencia Reactiva III | kvar III | 84 | A6-A7 | 24C-24F | 44C-44F | varx10 |
| Reactive Power Consum. L1 | kvar_c_1 | 85 | A8-A9 | 250-253 | 450-453 | varx10 |
| Reactive Power Consum. L2 | kvar_c_2 | 86 | AA-AB | 254-257 | 454-457 | varx10 |
| Reactive Power Consum. L3 | kvar_c_3 | 87 | AC-AD | 258-25B | 458-45B | varx10 |
| Reactive Power Consum. III | kvar_c_III | 88 | AE-AF | 25C-25F | 45C-45F | varx10 |
| Reactive Power Gener. L1 | kvar_g_1 | 89 | B0-B1 | 260-263 | 460-463 | varx10 |
| Reactive Power Gener. L2 | kvar_g_2 | 90 | B2-B3 | 264-267 | 464-467 | varx10 |
| Reactive Power Gener. L3 | kvar_g_3 | 91 | B4-B5 | 268-26B | 468-46B | varx10 |
| Reactive Power Gener. III | kvar_g_III | 92 | B6-B7 | 26C-26F | 46C-46F | varx10 |

8.3.2. CURRENT ENERGY VARIABLES

| CURRENT ENERGY MODBUS VARIABLES | | | | |
|---------------------------------|-----------------|------|---------|-----|
| VARIABLE | SYMBOL | CODE | KW·H | W·H |
| TARIFF 1 | | | | |
| Active energy | kW·h III | 129 | 500-501 | 502 |
| Inductive reactive energy | kvar·h L III | 130 | 503-504 | 505 |
| Capacitive reactive energy | kvar·h C III | 131 | 506-507 | 508 |
| Three phase apparent energy | kV·A·hIII | 132 | 509-50A | 50B |
| Active energy generated | kW·hIII (-) | 133 | 50C-50D | 50E |
| Inductive energy generated | kvar·h LIII (-) | 134 | 50F-510 | 511 |
| Capacitive energy generated | kvar·h CIII (-) | 135 | 512-513 | 514 |
| Apparent energy generated | kV·A·hIII (-) | 136 | 515-516 | 517 |
| TARIFF 2 | | | | |
| Active energy | kW·h III | 137 | 518-519 | 51A |
| Inductive reactive energy | kvar·h L III | 138 | 51B-51C | 51D |
| Capacitive reactive energy | kvar·h C III | 139 | 51E-51F | 520 |
| Three phase apparent energy | kV·A·hIII | 140 | 521-522 | 523 |
| Active energy generated | kW·hIII (-) | 141 | 524-525 | 526 |
| Inductive energy generated | kvar·h LIII (-) | 142 | 527-528 | 529 |
| Capacitive energy generated | kvar·h CIII (-) | 143 | 52A-52B | 52C |
| Apparent energy generated | kV·A·hIII (-) | 144 | 52D-52E | 52F |
| TARIFF 3 | | | | |
| Active energy | kW·h III | 145 | 530-531 | 532 |
| Inductive reactive energy | kvar·h L III | 146 | 533-534 | 535 |
| Capacitive reactive energy | kvar·h C III | 147 | 536-537 | 538 |
| Three phase apparent energy | kV·A·hIII | 148 | 539-53A | 53B |
| Active energy generated | kW·hIII (-) | 149 | 53C-53D | 53E |
| Inductive energy generated | kvar·h LIII (-) | 150 | 53F-540 | 541 |
| Capacitive energy generated | kvar·h CIII (-) | 151 | 542-543 | 544 |
| Apparent energy generated | kV·A·hIII (-) | 152 | 545-546 | 547 |
| TARIFF 4 | | | | |
| Active energy | kW·h III | 153 | 548-549 | 54A |
| Inductive reactive energy | kvar·h L III | 154 | 54B-54C | 54D |
| Capacitive reactive energy | kvar·h C III | 155 | 54E-54F | 550 |
| Three phase apparent energy | kV·A·hIII | 156 | 551-552 | 553 |
| Active energy generated | kW·hIII (-) | 157 | 554-555 | 556 |
| Inductive energy generated | kvar·h LIII (-) | 158 | 557-558 | 559 |
| Capacitive energy generated | kvar·h CIII (-) | 159 | 55A-55B | 55C |
| Apparent energy generated | kV·A·hIII (-) | 160 | 55D-55E | 55F |
| TARIFF 5 | | | | |
| Active energy | kW·h III | 161 | 560-561 | 562 |
| Inductive reactive energy | kvar·h L III | 162 | 563-564 | 565 |
| Capacitive reactive energy | kvar·h C III | 163 | 566-567 | 568 |
| Three phase apparent energy | kV·A·hIII | 164 | 569-56A | 56B |

| | | | | |
|-----------------------------|-----------------|-----|---------|-----|
| Active energy generated | kW·hIII (-) | 165 | 56C-56D | 56E |
| Inductive energy generated | kvar·h LIII (-) | 166 | 56F-570 | 571 |
| Capacitive energy generated | kvar·h CIII (-) | 167 | 572-573 | 574 |
| Apparent energy generated | kV·A·hIII (-) | 168 | 575-576 | 577 |

TARIFF 6

| | | | | |
|-----------------------------|-----------------|-----|---------|-----|
| Active energy | kW·h III | 169 | 578-579 | 57A |
| Inductive reactive energy | kvar·h L III | 170 | 57B-57C | 57D |
| Capacitive reactive energy | kvar·h C III | 171 | 57E-57F | 580 |
| Three phase apparent energy | kV·A·hIII | 172 | 581-582 | 583 |
| Active energy generated | kW·hIII (-) | 173 | 584-585 | 586 |
| Inductive energy generated | kvar·h LIII (-) | 174 | 587-588 | 589 |
| Capacitive energy generated | kvar·h CIII (-) | 175 | 58A-58B | 58C |
| Apparent energy generated | kV·A·hIII (-) | 176 | 58D-58E | 58F |

TARIFF 7

| | | | | |
|-----------------------------|-----------------|-----|---------|-----|
| Active energy | kW·h III | 177 | 590-591 | 592 |
| Inductive reactive energy | kvar·h L III | 178 | 593-594 | 595 |
| Capacitive reactive energy | kvar·h C III | 179 | 596-597 | 598 |
| Three phase apparent energy | kV·A·hIII | 180 | 599-59A | 59B |
| Active energy generated | kW·hIII (-) | 181 | 59C-59D | 59E |
| Inductive energy generated | kvar·h LIII (-) | 182 | 59F-5A0 | 5A1 |
| Capacitive energy generated | kvar·h CIII (-) | 183 | 5A2-5A3 | 5A4 |
| Apparent energy generated | kV·A·hIII (-) | 184 | 5A5-5A6 | 5A7 |

TARIFF 8

| | | | | |
|-----------------------------|-----------------|-----|---------|-----|
| Active energy | kW·h III | 185 | 5A8-5A9 | 5AA |
| Inductive reactive energy | kvar·h L III | 186 | 5AB-5AC | 5AD |
| Capacitive reactive energy | kvar·h C III | 187 | 5AE-5AF | 5B0 |
| Three phase apparent energy | kV·A·hIII | 188 | 5B1-5B2 | 5B3 |
| Active energy generated | kW·hIII (-) | 189 | 5B4-5B5 | 5B6 |
| Inductive energy generated | kvar·h LIII (-) | 190 | 5B7-5B8 | 5B9 |
| Capacitive energy generated | kvar·h CIII (-) | 191 | 5BA-5BB | 5BC |
| Apparent energy generated | kV·A·hIII (-) | 192 | 5BD-5BE | 5BF |

TARIFF 9

| | | | | |
|-----------------------------|-----------------|-----|---------|-----|
| Active energy | kW·h III | 193 | 5C0-5C1 | 5C2 |
| Inductive reactive energy | kvar·h L III | 194 | 5C3-5C4 | 5C5 |
| Capacitive reactive energy | kvar·h C III | 195 | 5C6-5C7 | 5C8 |
| Three phase apparent energy | kV·A·hIII | 196 | 5C9-5CA | 5CB |
| Active energy generated | kW·hIII (-) | 197 | 5CC-5CD | 5CE |
| Inductive energy generated | kvar·h LIII (-) | 198 | 5CF-5D0 | 5D1 |
| Capacitive energy generated | kvar·h CIII (-) | 199 | 5D2-5D3 | 5D4 |
| Apparent energy generated | kV·A·hIII (-) | 200 | 5D5-5D6 | 5D7 |

TOTAL TARIFF

| | | | | |
|-----------------------------|--------------|-----|---------|-----|
| Active energy | kW·h III | 201 | 5D8-5D9 | 5DA |
| Inductive reactive energy | kvar·h L III | 202 | 5DB-5DC | 5DD |
| Capacitive reactive energy | kvar·h C III | 203 | 5DE-5DF | 5E0 |
| Three phase apparent energy | kV·A·hIII | 204 | 5E1-5E2 | 5E3 |

| | | | | |
|-----------------------------|-----------------|-----|---------|-----|
| Active energy generated | kW·hIII (-) | 205 | 5E4-5E5 | 5E6 |
| Inductive energy generated | kvar·h LIII (-) | 206 | 5E7-5E8 | 5E9 |
| Capacitive energy generated | kvar·h CIII (-) | 207 | 5EA-5EB | 5EC |
| Apparent energy generated | kV·A·hIII (-) | 208 | 5ED-5EE | 5EF |

8.3.3. ENERGY VARIABLES FROM PREVIOUS PERIODS

| PREVIOUS MONTH MODBUS ENERGY VARIABLES | | | |
|--|-----------------|---------|-----|
| VARIABLE | SYMBOL | KW·H | W·H |
| TARIFF 1 | | | |
| Active energy | kW·h III | 600-601 | 602 |
| Inductive reactive energy | kvar·h L III | 603-604 | 605 |
| Capacitive reactive energy | kvar·h C III | 606-607 | 608 |
| Three phase apparent energy | kV·A·hIII | 609-60A | 60B |
| Active energy generated | kW·hIII (-) | 60C-60D | 60E |
| Inductive energy generated | kvar·h LIII (-) | 60F-610 | 611 |
| Capacitive energy generated | kvar·h CIII (-) | 612-613 | 614 |
| Apparent energy generated | kV·A·hIII (-) | 615-616 | 617 |
| TARIFF 2 | | | |
| Active energy | kW·h III | 618-619 | 61A |
| Inductive reactive energy | kvar·h L III | 61B-61C | 61D |
| Capacitive reactive energy | kvar·h C III | 61E-61F | 620 |
| Three phase apparent energy | kV·A·hIII | 621-622 | 623 |
| Active energy generated | kW·hIII (-) | 624-625 | 626 |
| Inductive energy generated | kvar·h LIII (-) | 627-628 | 629 |
| Capacitive energy generated | kvar·h CIII (-) | 62A-62B | 62C |
| Apparent energy generated | kV·A·hIII (-) | 62D-62E | 62F |
| TARIFF 3 | | | |
| Active energy | kW·h III | 630-631 | 632 |
| Inductive reactive energy | kvar·h L III | 633-634 | 635 |
| Capacitive reactive energy | kvar·h C III | 636-637 | 638 |
| Three phase apparent energy | kV·A·hIII | 639-63A | 63B |
| Active energy generated | kW·hIII (-) | 63C-63D | 63E |
| Inductive energy generated | kvar·h LIII (-) | 63F-640 | 641 |
| Capacitive energy generated | kvar·h CIII (-) | 642-643 | 644 |
| Apparent energy generated | kV·A·hIII (-) | 645-646 | 647 |
| TARIFF 4 | | | |
| Active energy | kW·h III | 648-649 | 64A |
| Inductive reactive energy | kvar·h L III | 64B-64C | 64D |
| Capacitive reactive energy | kvar·h C III | 64E-64F | 650 |
| Three phase apparent energy | kV·A·hIII | 651-652 | 653 |
| Active energy generated | kW·hIII (-) | 654-655 | 656 |
| Inductive energy generated | kvar·h LIII (-) | 657-658 | 659 |

| | | | |
|-----------------------------|-----------------|---------|-----|
| Capacitive energy generated | kvar·h CIII (-) | 65A-65B | 65C |
| Apparent energy generated | kV·A·hIII (-) | 65D-65E | 65F |
| TARIFF 5 | | | |
| Active energy | kW·h III | 660-661 | 662 |
| Inductive reactive energy | kvar·h L III | 663-664 | 665 |
| Capacitive reactive energy | kvar·h C III | 666-667 | 668 |
| Three phase apparent energy | kV·A·hIII | 669-66A | 66B |
| Active energy generated | kW·hIII (-) | 66C-66D | 66E |
| Inductive energy generated | kvar·h LIII (-) | 66F-670 | 671 |
| Capacitive energy generated | kvar·h CIII (-) | 672-673 | 674 |
| Apparent energy generated | kV·A·hIII (-) | 675-676 | 677 |
| TARIFF 6 | | | |
| Active energy | kW·h III | 678-679 | 67A |
| Inductive reactive energy | kvar·h L III | 67B-67C | 67D |
| Capacitive reactive energy | kvar·h C III | 67E-67F | 680 |
| Three phase apparent energy | kV·A·hIII | 681-682 | 683 |
| Active energy generated | kW·hIII (-) | 684-685 | 686 |
| Inductive energy generated | kvar·h LIII (-) | 687-688 | 689 |
| Capacitive energy generated | kvar·h CIII (-) | 68A-68B | 68C |
| Apparent energy generated | kV·A·hIII (-) | 68D-68E | 68F |
| TARIFF 7 | | | |
| Active energy | kW·h III | 690-691 | 692 |
| Inductive reactive energy | kvar·h L III | 693-694 | 695 |
| Capacitive reactive energy | kvar·h C III | 696-697 | 698 |
| Three phase apparent energy | kV·A·hIII | 699-69A | 69B |
| Active energy generated | kW·hIII (-) | 69C-69D | 69E |
| Inductive energy generated | kvar·h LIII (-) | 69F-6A0 | 6A1 |
| Capacitive energy generated | kvar·h CIII (-) | 6A2-6A3 | 6A4 |
| Apparent energy generated | kV·A·hIII (-) | 6A5-6A6 | 6A7 |
| TARIFF 8 | | | |
| Active energy | kW·h III | 6A8-6A9 | 6AA |
| Inductive reactive energy | kvar·h L III | 6AB-6AC | 6AD |
| Capacitive reactive energy | kvar·h C III | 6AE-6AF | 6B0 |
| Three phase apparent energy | kV·A·hIII | 6B1-6B2 | 6B3 |
| Active energy generated | kW·hIII (-) | 6B4-6B5 | 6B6 |
| Inductive energy generated | kvar·h LIII (-) | 6B7-6B8 | 6B9 |
| Capacitive energy generated | kvar·h CIII (-) | 6BA-6BB | 6BC |
| Apparent energy generated | kV·A·hIII (-) | 6BD-6BE | 6BF |
| TARIFF 9 | | | |
| Active energy | kW·h III | 6C0-6C1 | 6C2 |
| Inductive reactive energy | kvar·h L III | 6C3-6C4 | 6C5 |
| Capacitive reactive energy | kvar·h C III | 6C6-6C7 | 6C8 |
| Three phase apparent energy | kV·A·hIII | 6C9-6CA | 6CB |
| Active energy generated | kW·hIII (-) | 6CC-6CD | 6CE |
| Inductive energy generated | kvar·h LIII (-) | 6CF-6D0 | 6D1 |

| | | | |
|-----------------------------|-----------------|---------|-----|
| Capacitive energy generated | kvar·h CIII (-) | 6D2-6D3 | 6D4 |
| Apparent energy generated | kV·A·hIII (-) | 6D5-6D6 | 6D7 |
| TOTAL TARIFF | | | |
| Active energy | kW·h III | 6D8-6D9 | 6DA |
| Inductive reactive energy | kvar·h L III | 6DB-6DC | 6DD |
| Capacitive reactive energy | kvar·h C III | 6DE-6DF | 6E0 |
| Three phase apparent energy | kV·A·hIII | 6E1-6E2 | 6E3 |
| Active energy generated | kW·hIII (-) | 6E4-6E5 | 6E6 |
| Inductive energy generated | kvar·h LIII (-) | 6E7-6E8 | 6E9 |
| Capacitive energy generated | kvar·h CIII (-) | 6EA-6EB | 6EC |
| Apparent energy generated | kV·A·hIII (-) | 6ED-6EE | 6EF |

8.3.4. ENERGY VARIABLES FOR THE PREVIOUS YEAR

| PREVIOUS YEAR MODBUS ENERGY VARIABLES | | | |
|--|-----------------|------------|-----------|
| VARIABLE | SYMBOL | KWH | WH |
| TARIFF 1 | | | |
| Active energy | kW·h III | 700-701 | 702 |
| Inductive reactive energy | kvar·h L III | 703-704 | 705 |
| Capacitive reactive energy | kvar·h C III | 706-707 | 708 |
| Three phase apparent energy | kV·A·hIII | 709-70A | 70B |
| Active energy generated | kW·hIII (-) | 70C-70D | 70E |
| Inductive energy generated | kvar·h LIII (-) | 70F-710 | 711 |
| Capacitive energy generated | kvar·h CIII (-) | 712-713 | 714 |
| Apparent energy generated | kV·A·hIII (-) | 715-716 | 717 |
| TARIFF 2 | | | |
| Active energy | kW·h III | 718-719 | 71A |
| Inductive reactive energy | kvar·h L III | 71B-71C | 71D |
| Capacitive reactive energy | kvar·h C III | 71E-71F | 720 |
| Three phase apparent energy | kV·A·hIII | 721-722 | 723 |
| Active energy generated | kW·hIII (-) | 724-725 | 726 |
| Inductive energy generated | kvar·h LIII (-) | 727-728 | 729 |
| Capacitive energy generated | kvar·h CIII (-) | 72A-72B | 72C |
| Apparent energy generated | kV·A·hIII (-) | 72D-72E | 72F |
| TARIFF 3 | | | |
| Active energy | kW·h III | 730-731 | 732 |
| Inductive reactive energy | kvar·h L III | 733-734 | 735 |
| Capacitive reactive energy | kvar·h C III | 736-737 | 738 |
| Three phase apparent energy | kV·A·hIII | 739-73A | 73B |
| Active energy generated | kW·hIII (-) | 73C-73D | 73E |
| Inductive energy generated | kvar·h LIII (-) | 73F-740 | 741 |
| Capacitive energy generated | kvar·h CIII (-) | 742-743 | 744 |
| Apparent energy generated | kV·A·hIII (-) | 745-746 | 747 |

TARIFF 4

| | | | |
|-----------------------------|-----------------|---------|-----|
| Active energy | kW·h III | 748-749 | 74A |
| Inductive reactive energy | kvar·h L III | 74B-74C | 74D |
| Capacitive reactive energy | kvar·h C III | 74E-74F | 750 |
| Three phase apparent energy | kV·A·hIII | 751-752 | 753 |
| Active energy generated | kW·hIII (-) | 754-755 | 756 |
| Inductive energy generated | kvar·h LIII (-) | 757-758 | 759 |
| Capacitive energy generated | kvar·h CIII (-) | 75A-75B | 75C |
| Apparent energy generated | kV·A·hIII (-) | 75D-75E | 75F |

TARIFF 5

| | | | |
|-----------------------------|-----------------|---------|-----|
| Active energy | kW·h III | 760-761 | 762 |
| Inductive reactive energy | kvar·h L III | 763-764 | 765 |
| Capacitive reactive energy | kvar·h C III | 766-767 | 768 |
| Three phase apparent energy | kV·A·hIII | 769-76A | 76B |
| Active energy generated | kW·hIII (-) | 76C-76D | 76E |
| Inductive energy generated | kvar·h LIII (-) | 76F-770 | 771 |
| Capacitive energy generated | kvar·h CIII (-) | 772-773 | 774 |
| Apparent energy generated | kV·A·hIII (-) | 775-776 | 777 |

TARIFF 6

| | | | |
|-----------------------------|-----------------|---------|-----|
| Active energy | kW·h III | 778-779 | 77A |
| Inductive reactive energy | kvar·h L III | 77B-77C | 77D |
| Capacitive reactive energy | kvar·h C III | 77E-77F | 780 |
| Three phase apparent energy | kV·A·hIII | 781-782 | 783 |
| Active energy generated | kW·hIII (-) | 784-785 | 786 |
| Inductive energy generated | kvar·h LIII (-) | 787-788 | 789 |
| Capacitive energy generated | kvar·h CIII (-) | 78A-78B | 78C |
| Apparent energy generated | kV·A·hIII (-) | 78D-78E | 78F |

TARIFF 7

| | | | |
|-----------------------------|-----------------|---------|-----|
| Active energy | kW·h III | 790-791 | 792 |
| Inductive reactive energy | kvar·h L III | 793-794 | 795 |
| Capacitive reactive energy | kvar·h C III | 796-797 | 798 |
| Three phase apparent energy | kV·A·hIII | 799-79A | 79B |
| Active energy generated | kW·hIII (-) | 79C-79D | 79E |
| Inductive energy generated | kvar·h LIII (-) | 79F-7A0 | 7A1 |
| Capacitive energy generated | kvar·h CIII (-) | 7A2-7A3 | 7A4 |
| Apparent energy generated | kV·A·hIII (-) | 7A5-7A6 | 7A7 |

TARIFF 8

| | | | |
|-----------------------------|-----------------|---------|-----|
| Active energy | kW·h III | 7A8-7A9 | 7AA |
| Inductive reactive energy | kvar·h L III | 7AB-7AC | 7AD |
| Capacitive reactive energy | kvar·h C III | 7AE-7AF | 7B0 |
| Three phase apparent energy | kV·A·hIII | 7B1-7B2 | 7B3 |
| Active energy generated | kW·hIII (-) | 7B4-7B5 | 7B6 |
| Inductive energy generated | kvar·h LIII (-) | 7B7-7B8 | 7B9 |
| Capacitive energy generated | kvar·h CIII (-) | 7BA-7BB | 7BC |
| Apparent energy generated | kV·A·hIII (-) | 7BD-7BE | 7BF |

| TARIFF 9 | | | |
|-----------------------------|-----------------|---------|-----|
| Active energy | kW·h III | 7C0-7C1 | 7C2 |
| Inductive reactive energy | kvar·h L III | 7C3-7C4 | 7C5 |
| Capacitive reactive energy | kvar·h C III | 7C6-7C7 | 7C8 |
| Three phase apparent energy | kV·A·hIII | 7C9-7CA | 7CB |
| Active energy generated | kW·hIII (-) | 7CC-7CD | 7CE |
| Inductive energy generated | kvar·h LIII (-) | 7CF-7D0 | 7D1 |
| Capacitive energy generated | kvar·h CIII (-) | 7D2-7D3 | 7D4 |
| Apparent energy generated | kV·A·hIII (-) | 7D5-7D6 | 7D7 |
| TOTAL TARIFF | | | |
| Active energy | kW·h III | 7D8-7D9 | 7DA |
| Inductive reactive energy | kvar·h L III | 7DB-7DC | 7DD |
| Capacitive reactive energy | kvar·h C III | 7DE-7DF | 7E0 |
| Three phase apparent energy | kV·A·hIII | 7E1-7E2 | 7E3 |
| Active energy generated | kW·hIII (-) | 7E4-7E5 | 7E6 |
| Inductive energy generated | kvar·h LIII (-) | 7E7-7E8 | 7E9 |
| Capacitive energy generated | kvar·h CIII (-) | 7EA-7EB | 7EC |
| Apparent energy generated | kV·A·hIII (-) | 7ED-7EE | 7EF |

8.3.2. MAXIMUM DEMAND VARIABLES

| MAXIMUM DEMAND MODBUS VARIABLES | | | | | |
|---------------------------------|-----------|------|---------|---------|------|
| MAXIMUM DEMAND VARIABLE | SYMBOL | CODE | INST. | MAX | UNIT |
| TARIFF 1 | | | | | |
| Three phase active power | Pd_kWIII | 300 | 800-801 | 900-903 | W |
| Three phase apparent power | Pd_kVAIII | 301 | 802-803 | 904-907 | V·A |
| Three-phase current (average) | Pd_I_AVG | 302 | 804-805 | 908-90B | mA |
| Phase 1 current | Pd_I1 | 303 | 806-807 | 90C-90F | mA |
| Phase 2 current | Pd_I2 | 304 | 808-809 | 910-913 | mA |
| Phase 3 current | Pd_I3 | 305 | 80A-80B | 914-917 | mA |
| TARIFF 2 | | | | | |
| Three phase active power | Pd_kWIII | 306 | 80C-80D | 918-91B | W |
| Three phase apparent power | Pd_kVAIII | 307 | 80E-80F | 91C-91F | V·A |
| Three-phase current (average) | Pd_I_AVG | 308 | 810-811 | 920-923 | mA |
| Phase 1 current | Pd_I1 | 309 | 812-813 | 924-927 | mA |
| Phase 2 current | Pd_I2 | 310 | 814-815 | 928-92B | mA |
| Phase 3 current | Pd_I3 | 311 | 816-817 | 92C-92F | mA |
| TARIFF 3 | | | | | |
| Three phase active power | Pd_kWIII | 312 | 818-819 | 930-933 | W |
| Three phase apparent power | Pd_kVAIII | 313 | 81A-81B | 934-937 | V·A |
| Three-phase current (average) | Pd_I_AVG | 314 | 81C-81D | 938-93B | mA |

| | | | | | |
|-------------------------------|-----------|-----|---------|---------|-----|
| Phase 1 current | Pd_I1 | 315 | 81E-81F | 93C-93F | mA |
| Phase 2 current | Pd_I2 | 316 | 820-821 | 940-943 | mA |
| Phase 3 current | Pd_I3 | 317 | 822-823 | 944-947 | mA |
| TARIFF 4 | | | | | |
| Three phase active power | Pd_kWIII | 318 | 824-825 | 948-94B | W |
| Three phase apparent power | Pd_kVAIII | 319 | 826-827 | 94C-94F | V·A |
| Three-phase current (average) | Pd_I_AVG | 320 | 828-829 | 950-953 | mA |
| Phase 1 current | Pd_I1 | 321 | 82A-82B | 954-957 | mA |
| Phase 2 current | Pd_I2 | 322 | 82C-82D | 958-95B | mA |
| Phase 3 current | Pd_I3 | 323 | 82E-82F | 95C-95F | mA |
| TARIFF 5 | | | | | |
| Three phase active power | Pd_kWIII | 324 | 830-831 | 960-963 | W |
| Three phase apparent power | Pd_kVAIII | 325 | 832-833 | 964-967 | V·A |
| Three-phase current (average) | Pd_I_AVG | 326 | 834-835 | 968-96B | mA |
| Phase 1 current | Pd_I1 | 327 | 836-837 | 96C-96F | mA |
| Phase 2 current | Pd_I2 | 328 | 838-839 | 970-973 | mA |
| Phase 3 current | Pd_I3 | 329 | 83A-83B | 974-977 | mA |
| TARIFF 6 | | | | | |
| Three phase active power | Pd_kWIII | 330 | 83C-83D | 978-97B | W |
| Three phase apparent power | Pd_kVAIII | 331 | 83E-83F | 97C-97F | V·A |
| Three-phase current (average) | Pd_I_AVG | 332 | 840-841 | 980-983 | mA |
| Phase 1 current | Pd_I1 | 333 | 842-843 | 984-987 | mA |
| Phase 2 current | Pd_I2 | 334 | 844-845 | 988-98B | mA |
| Phase 3 current | Pd_I3 | 335 | 846-847 | 98C-98F | mA |
| TARIFF 7 | | | | | |
| Three phase active power | Pd_kWIII | 336 | 848-849 | 990-993 | W |
| Three phase apparent power | Pd_kVAIII | 337 | 84A-84B | 994-997 | V·A |
| Three-phase current (average) | Pd_I_AVG | 338 | 84C-84D | 998-99B | mA |
| Phase 1 current | Pd_I1 | 339 | 84E-84F | 99C-99F | mA |
| Phase 2 current | Pd_I2 | 340 | 850-851 | 9A0-9A3 | mA |
| Phase 3 current | Pd_I3 | 341 | 852-853 | 9A4-9A7 | mA |
| TARIFF 8 | | | | | |
| Three phase active power | Pd_kWIII | 342 | 854-855 | 9A8-9AB | W |
| Three phase apparent power | Pd_kVAIII | 343 | 856-857 | 9AC-9AF | V·A |
| Three-phase current (average) | Pd_I_AVG | 344 | 858-859 | 9B0-9B3 | mA |
| Phase 1 current | Pd_I1 | 345 | 85A-85B | 9B4-9B7 | mA |
| Phase 2 current | Pd_I2 | 346 | 85C-85D | 9B8-9BB | mA |
| Phase 3 current | Pd_I3 | 347 | 85E-85F | 9BC-9BF | mA |
| TARIFF 9 | | | | | |
| Three phase active power | Pd_kWIII | 348 | 860-861 | 9C0-9C3 | W |
| Three phase apparent power | Pd_kVAIII | 349 | 862-863 | 9C4-9C7 | V·A |
| Three-phase current (average) | Pd_I_AVG | 350 | 864-865 | 9C8-9CB | mA |
| Phase 1 current | Pd_I1 | 351 | 866-867 | 9CC-9CF | mA |
| Phase 2 current | Pd_I2 | 352 | 868-869 | 9D0-9D3 | mA |
| Phase 3 current | Pd_I3 | 353 | 86A-86B | 9D4-9D7 | mA |

8.3.6. VOLTAGE HARMONICS VARIABLES

| VARIABLE | SYMBOL | U_1 | U_2 | U_3 | U_N | UNIT |
|-------------|--------|-----------|-----------|-----------|-----------|------|
| Fundamental | V_fund | 0A28-0A29 | 0A5B-0A5C | 0A8E-0A8F | 0AC1-0AC2 | Vx10 |
| Harmonic 2 | H2 | 0A2A | 0A5D | 0A90 | 0AC3 | %x10 |
| Harmonic 3 | H3 | 0A2B | 0A5E | 0A91 | 0AC4 | %x10 |
| Harmonic 4 | H4 | 0A2C | 0A5F | 0A92 | 0AC5 | %x10 |
| Harmonic 5 | H5 | 0A2D | 0A60 | 0A93 | 0AC6 | %x10 |
| Harmonic 6 | H6 | 0A2E | 0A61 | 0A94 | 0AC7 | %x10 |
| Harmonic 7 | H7 | 0A2F | 0A62 | 0A95 | 0AC8 | %x10 |
| Harmonic 8 | H8 | 0A30 | 0A63 | 0A96 | 0AC9 | %x10 |
| Harmonic 9 | H9 | 0A31 | 0A64 | 0A97 | 0ACA | %x10 |
| Harmonic 10 | H10 | 0A32 | 0A65 | 0A98 | 0ACB | %x10 |
| Harmonic 11 | H11 | 0A33 | 0A66 | 0A99 | 0ACC | %x10 |
| Harmonic 12 | H12 | 0A34 | 0A67 | 0A9A | 0ACD | %x10 |
| Harmonic 13 | H13 | 0A35 | 0A68 | 0A9B | 0ACE | %x10 |
| Harmonic 14 | H14 | 0A36 | 0A69 | 0A9C | 0ACF | %x10 |
| Harmonic 15 | H15 | 0A37 | 0A6A | 0A9D | 0AD0 | %x10 |
| Harmonic 16 | H16 | 0A38 | 0A6B | 0A9E | 0AD1 | %x10 |
| Harmonic 17 | H17 | 0A39 | 0A6C | 0A9F | 0AD2 | %x10 |
| Harmonic 18 | H18 | 0A3A | 0A6D | 0AA0 | 0AD3 | %x10 |
| Harmonic 19 | H19 | 0A3B | 0A6E | 0AA1 | 0AD4 | %x10 |
| Harmonic 20 | H20 | 0A3C | 0A6F | 0AA2 | 0AD5 | %x10 |
| Harmonic 21 | H21 | 0A3D | 0A70 | 0AA3 | 0AD6 | %x10 |
| Harmonic 22 | H22 | 0A3E | 0A71 | 0AA4 | 0AD7 | %x10 |
| Harmonic 23 | H23 | 0A3F | 0A72 | 0AA5 | 0AD8 | %x10 |
| Harmonic 24 | H24 | 0A40 | 0A73 | 0AA6 | 0AD9 | %x10 |
| Harmonic 25 | H25 | 0A41 | 0A74 | 0AA7 | 0ADA | %x10 |
| Harmonic 26 | H26 | 0A42 | 0A75 | 0AA8 | 0ADB | %x10 |
| Harmonic 27 | H27 | 0A43 | 0A76 | 0AA9 | 0ADC | %x10 |
| Harmonic 28 | H28 | 0A44 | 0A77 | 0AAA | 0ADD | %x10 |
| Harmonic 29 | H29 | 0A45 | 0A78 | 0AAB | 0ADE | %x10 |
| Harmonic 30 | H30 | 0A46 | 0A79 | 0AAC | 0ADF | %x10 |
| Harmonic 31 | H31 | 0A47 | 0A7A | 0AAD | 0AE0 | %x10 |
| Harmonic 32 | H32 | 0A48 | 0A7B | 0AAE | 0AE1 | %x10 |
| Harmonic 33 | H33 | 0A49 | 0A7C | 0AAF | 0AE2 | %x10 |
| Harmonic 34 | H34 | 0A4A | 0A7D | 0AB0 | 0AE3 | %x10 |
| Harmonic 35 | H35 | 0A4B | 0A7E | 0AB1 | 0AE4 | %x10 |
| Harmonic 36 | H36 | 0A4C | 0A7F | 0AB2 | 0AE5 | %x10 |
| Harmonic 37 | H37 | 0A4D | 0A80 | 0AB3 | 0AE6 | %x10 |
| Harmonic 38 | H38 | 0A4E | 0A81 | 0AB4 | 0AE7 | %x10 |
| Harmonic 39 | H39 | 0A4F | 0A82 | 0AB5 | 0AE8 | %x10 |
| Harmonic 40 | H40 | 0A50 | 0A83 | 0AB6 | 0AE9 | %x10 |
| Harmonic 41 | H41 | 0A51 | 0A84 | 0AB7 | 0AEA | %x10 |

| | | | | | | |
|-------------|-----|------|------|------|------|------|
| Harmonic 42 | H42 | 0A52 | 0A85 | 0AB8 | 0AEB | %x10 |
| Harmonic 43 | H43 | 0A53 | 0A86 | 0AB9 | 0AEC | %x10 |
| Harmonic 44 | H44 | 0A54 | 0A87 | 0ABA | 0AED | %x10 |
| Harmonic 45 | H45 | 0A55 | 0A88 | 0ABB | 0AEE | %x10 |
| Harmonic 46 | H46 | 0A56 | 0A89 | 0ABC | 0AEF | %x10 |
| Harmonic 47 | H47 | 0A57 | 0A8A | 0ABD | 0AF0 | %x10 |
| Harmonic 48 | H48 | 0A58 | 0A8B | 0ABE | 0AF1 | %x10 |
| Harmonic 49 | H49 | 0A59 | 0A8C | 0ABF | 0AF2 | %x10 |
| Harmonic 50 | H50 | 0A5A | 0A8D | 0AC0 | 0AF3 | %x10 |



The fundamental variable should be requested independently from the rest of the voltage harmonics variables.

8.3.7. CURRENT HARMONICS VARIABLES

| VARIABLE | SYMBOL | I_1 | I_2 | I_3 | I_N | UNIT |
|-------------|--------|-----------|-----------|-----------|-----------|------|
| Fundamental | I_fund | 0B54-0B55 | 0B87-0B88 | 0BBA-0BBB | 0BED-0BEE | mA |
| Harmonic 2 | H2 | 0B56 | 0B89 | 0BBC | 0BEF | %x10 |
| Harmonic 3 | H3 | 0B57 | 0B8A | 0BBD | 0BF0 | %x10 |
| Harmonic 4 | H4 | 0B58 | 0B8B | 0BBE | 0BF1 | %x10 |
| Harmonic 5 | H5 | 0B59 | 0B8C | 0BBF | 0BF2 | %x10 |
| Harmonic 6 | H6 | 0B5A | 0B8D | 0BC0 | 0BF3 | %x10 |
| Harmonic 7 | H7 | 0B5B | 0B8E | 0BC1 | 0BF4 | %x10 |
| Harmonic 8 | H8 | 0B5C | 0B8F | 0BC2 | 0BF5 | %x10 |
| Harmonic 9 | H9 | 0B5D | 0B90 | 0BC3 | 0BF6 | %x10 |
| Harmonic 10 | H10 | 0B5E | 0B91 | 0BC4 | 0BF7 | %x10 |
| Harmonic 11 | H11 | 0B5F | 0B92 | 0BC5 | 0BF8 | %x10 |
| Harmonic 12 | H12 | 0B60 | 0B93 | 0BC6 | 0BF9 | %x10 |
| Harmonic 13 | H13 | 0B61 | 0B94 | 0BC7 | 0BFA | %x10 |
| Harmonic 14 | H14 | 0B62 | 0B95 | 0BC8 | 0BFB | %x10 |
| Harmonic 15 | H15 | 0B63 | 0B96 | 0BC9 | 0BFC | %x10 |
| Harmonic 16 | H16 | 0B64 | 0B97 | 0BCA | 0BFD | %x10 |
| Harmonic 17 | H17 | 0B65 | 0B98 | 0BCB | 0BFE | %x10 |
| Harmonic 18 | H18 | 0B66 | 0B99 | 0BCC | 0BFF | %x10 |
| Harmonic 19 | H19 | 0B67 | 0B9A | 0BCD | 0C00 | %x10 |
| Harmonic 20 | H20 | 0B68 | 0B9B | 0BCE | 0C01 | %x10 |
| Harmonic 21 | H21 | 0B69 | 0B9C | 0BCF | 0C02 | %x10 |
| Harmonic 22 | H22 | 0B6A | 0B9D | 0BD0 | 0C03 | %x10 |
| Harmonic 23 | H23 | 0B6B | 0B9E | 0BD1 | 0C04 | %x10 |
| Harmonic 24 | H24 | 0B6C | 0B9F | 0BD2 | 0C05 | %x10 |

| | | | | | | |
|-------------|-----|------|------|------|------|------|
| Harmonic 25 | H25 | 0B6D | 0BA0 | 0BD3 | 0C06 | %x10 |
| Harmonic 26 | H26 | 0B6E | 0BA1 | 0BD4 | 0C07 | %x10 |
| Harmonic 27 | H27 | 0B6F | 0BA2 | 0BD5 | 0C08 | %x10 |
| Harmonic 28 | H28 | 0B70 | 0BA3 | 0BD6 | 0C09 | %x10 |
| Harmonic 29 | H29 | 0B71 | 0BA4 | 0BD7 | 0C0A | %x10 |
| Harmonic 30 | H30 | 0B72 | 0BA5 | 0BD8 | 0C0B | %x10 |
| Harmonic 31 | H31 | 0B73 | 0BA6 | 0BD9 | 0C0C | %x10 |
| Harmonic 32 | H32 | 0B74 | 0BA7 | 0BDA | 0C0D | %x10 |
| Harmonic 33 | H33 | 0B75 | 0BA8 | 0BDB | 0C0E | %x10 |
| Harmonic 34 | H34 | 0B76 | 0BA9 | 0BDC | 0C0F | %x10 |
| Harmonic 35 | H35 | 0B77 | 0BAA | 0BDD | 0C10 | %x10 |
| Harmonic 36 | H36 | 0B78 | 0BAB | 0BDE | 0C11 | %x10 |
| Harmonic 37 | H37 | 0B79 | 0BAC | 0BDF | 0C12 | %x10 |
| Harmonic 38 | H38 | 0B7A | 0BAD | 0BE0 | 0C13 | %x10 |
| Harmonic 39 | H39 | 0B7B | 0BAE | 0BE1 | 0C14 | %x10 |
| Harmonic 40 | H40 | 0B7C | 0BAF | 0BE2 | 0C15 | %x10 |
| Harmonic 41 | H41 | 0B7D | 0BB0 | 0BE3 | 0C16 | %x10 |
| Harmonic 42 | H42 | 0B7E | 0BB1 | 0BE4 | 0C17 | %x10 |
| Harmonic 43 | H43 | 0B7F | 0BB2 | 0BE5 | 0C18 | %x10 |
| Harmonic 44 | H44 | 0B80 | 0BB3 | 0BE6 | 0C19 | %x10 |
| Harmonic 45 | H45 | 0B81 | 0BB4 | 0BE7 | 0C1A | %x10 |
| Harmonic 46 | H46 | 0B82 | 0BB5 | 0BE8 | 0C1B | %x10 |
| Harmonic 47 | H47 | 0B83 | 0BB6 | 0BE9 | 0C1C | %x10 |
| Harmonic 48 | H48 | 0B84 | 0BB7 | 0BEA | 0C1D | %x10 |
| Harmonic 49 | H49 | 0B85 | 0BB8 | 0BEB | 0C1E | %x10 |
| Harmonic 50 | H50 | 0B86 | 0BB9 | 0BEC | 0C1F | %x10 |



The fundamental variable should be requested independently from the rest of the current harmonics variables.

8.3.8. DIGITAL INPUT EXPANSION CARD VARIABLES

| CARD POSITION | VARIABLE | SYMBOL | CODE | MODBUS ADDRESS |
|---------------|---------------|---------|------|----------------|
| CARD 1 | Input 1 meter | IN_1001 | 400 | 0C80-0C81 |
| | Input 2 meter | IN_1002 | 401 | 0C82-0C83 |
| | Input 3 meter | IN_1003 | 402 | 0C84-0C85 |
| | Input 4 meter | IN_1004 | 403 | 0C86-0C87 |
| | Input 5 meter | IN_1005 | 404 | 0C88-0C89 |
| | Input 6 meter | IN_1006 | 405 | 0C8A-0C8B |
| | Input 7 meter | IN_1007 | 406 | 0C8C-0C8D |
| | Input 8 meter | IN_1008 | 407 | 0C8E-0C8F |

| | | | | |
|--------|---------------|---------|-----|-----------|
| CARD 2 | Input 1 meter | IN_2001 | 408 | 0C90-0C91 |
| | Input 2 meter | IN_2002 | 409 | 0C92-0C93 |
| | Input 3 meter | IN_2003 | 410 | 0C94-0C95 |
| | Input 4 meter | IN_2004 | 411 | 0C96-0C97 |
| | Input 5 meter | IN_2005 | 412 | 0C98-0C99 |
| | Input 6 meter | IN_2006 | 413 | 0C9A-0C9B |
| | Input 7 meter | IN_2007 | 414 | 0C9C-0C9D |
| | Input 8 meter | IN_2008 | 415 | 0C9E-0C9F |
| CARD 3 | Input 1 meter | IN_3001 | 416 | 0CA0-0CA1 |
| | Input 2 meter | IN_3002 | 417 | 0CA2-0CA3 |
| | Input 3 meter | IN_3003 | 418 | 0CA4-0CA5 |
| | Input 4 meter | IN_3004 | 419 | 0CA6-0CA7 |
| | Input 5 meter | IN_3005 | 420 | 0CA8-0CA9 |
| | Input 6 meter | IN_3006 | 421 | 0CAA-0CAB |
| | Input 7 meter | IN_3007 | 422 | 0CAC-0CAD |
| | Input 8 meter | IN_3008 | 423 | 0CAE-0CAF |

8.3.9. ANALOGUE INPUT EXPANSION CARD VARIABLES

| CARD POSITION | VARIABLE | SYMBOL | CODE | MODBUS ADDRESS |
|---------------|------------------|---------|------|----------------|
| CARD 1 | Analogue input 1 | AD_1001 | 424 | 0CB2-0CB3 |
| | Analogue input 2 | AD_1002 | 425 | 0CB4-0CB5 |
| | Analogue input 3 | AD_1003 | 426 | 0CB6-0CB7 |
| | Analogue input 4 | AD_1004 | 427 | 0CB8-0CB9 |
| | Analogue input 5 | AD_1005 | 428 | 0CBA-0CBB |
| | Analogue input 6 | AD_1006 | 429 | 0CBC-0CBD |
| | Analogue input 7 | AD_1007 | 430 | 0CBE-0CBF |
| | Analogue input 8 | AD_1008 | 431 | 0CC0-0CC1 |
| CARD 2 | Analogue input 1 | AD_2001 | 432 | 0CC2-0CC3 |
| | Analogue input 2 | AD_2002 | 433 | 0CC4-0CC5 |
| | Analogue input 3 | AD_2003 | 434 | 0CC6-0CC7 |
| | Analogue input 4 | AD_2004 | 435 | 0CC8-0CC9 |
| | Analogue input 5 | AD_2005 | 436 | 0CCA-0CCB |
| | Analogue input 6 | AD_2006 | 437 | 0CCC-0CCD |
| | Analogue input 7 | AD_2007 | 438 | 0CCE-0CCF |
| | Analogue input 8 | AD_2008 | 439 | 0CD0-0CD1 |
| CARD 3 | Analogue input 1 | AD_3001 | 440 | 0CD2-0CD3 |
| | Analogue input 2 | AD_3002 | 441 | 0CD4-0CD5 |
| | Analogue input 3 | AD_3003 | 442 | 0CD6-0CD7 |
| | Analogue input 4 | AD_3004 | 443 | 0CD8-0CD9 |
| | Analogue input 5 | AD_3005 | 444 | 0CDA-0CDB |
| | Analogue input 6 | AD_3006 | 445 | 0CDC-0CDD |
| | Analogue input 7 | AD_3007 | 446 | 0CDE-0CDF |
| | Analogue input 8 | AD_3008 | 447 | 0CE0-0CE1 |

8.4. RS-485 NETWORK FEATURES

The RS-485 connection is made with screened but flexible twisted pair communication cable with a minimum of three wires. Maximum distance between the master and the last peripheral device is 1.200 metres.

For RS-485 connection over longer distances or where there are hi level of disturbances environment, twisted screened cable should always be used.

RECOMMENDED CABLE

Flexible category 5 cable, 4 conductors x 0.5 mm² (AWG 20) shield. The shield should be connected to ground in order to discharge noise that it may be induce. This cable can also use conductors with 0.22 mm² cross sections (AWG 24), although the 0.25 mm² or higher, (AWG 23) is recommended.

No. OF PERIPHERAL DEVICES:

A maximum of 32 peripheral devices can be connected to the network, and amplifiers can be used to extend the bus 1.200 additional metres.

Other considerations:

- Install the RS-485 BUS far away from electrical power lines.
- In facilities with long distances of RS-485 BUS, it is recommended to install components to protect against overvoltages in the BUS (voltages induced in the BUS by atmospheric discharges or ground potential differences).
- Do not make a star connection for the RS-485 BUS; i.e., do not make branches off the bus. The connection between a group of 485 peripherals and the BUS should be as short as possible.
- The analyzers GND should not be connected in the 485 BUS, i.e. system GNDs should not be connected one to another in order to avoid currents circulating between grounds at different potentials.
- The systems GND should neither be connected to the cable screen nor to the facility's ground.

9 . MAINTENANCE AND CALIBRATION

9.1 MAINTENANCE

CVMk2 does not require maintenance work since it is a completely static instrument. Nonetheless, it is recommended to verify that the terminals are properly tightened.



To increase the system's capacity with expansion cards before handling, modify its connections or replace equipment; **CVMk2** must be power OFF. Handling the system while it is powered up is dangerous for the persons and the equipment.


10. FEATURES

10.1. STANDARDS

- CE Marking
- CAT III - 300 / 520 Vac in accordance with EN-61010 Standard.
- Protected against electrical shock by class II double insulation.
- Mounted on the DIN 46227 rail in accordance with EN50022 Standard.
- Energy accuracy according IEC 62053-22

10.2. TECHNICAL FEATURES

| VOLTAGE INPUTS | |
|------------------------------------|--|
| Minimum measurable voltage | 10 V a.c |
| Measuring range | from 5 to 120% of U_n for $U_n = 300$ V a.c. (f-N) |
| | from 5 to 120% of U_n for $U_n = 520$ V a.c (f-f) |
| Frequency | 45...65 Hz |
| Maximum measured voltage | 360 Vac |
| Acceptable overvoltage | 750 Vac |
| Consumption | < 0.6 V·A |
| CURRENT INPUTS | |
| Minimum measurable current | 40 mA |
| Measuring range | from 1 to 120% of I_n for $I_n = 5$ A |
| Secondary for the TCs (I_n) | 1 or 5 A |
| Primary current measured | Programmable < 30.000 A |
| Acceptable overload | 6 A continuous, 100 A $t < 1$ s |
| Consumption for (.../5 and .../1) | < 0.45 V·A |
| AUXILIARY POWER SUPPLY | |
| Power supply | 85 to 265 Vac (50-60 Hz) (consumption < 30 V·A) |
| | 100 to 300 Vdc (consumption < 25 W) |
| DIGITAL INPUTS | |
| Use voltage | 24 V d.c. $\pm 20\%$ |
| Minimum signal width | 30 ms |
| Consumption (each input) | < 0.5 W |
| DIGITAL PULSE OUTPUTS | |
| Type: | Optocoupler |
| Use voltage | 24 V d.c |
| Maximum power (per output) | 0.8 W |
| Máximum R_{ON} | 35 Ω |
| RELAY DIGITAL OUTPUTS | |
| Type: | Mechanical relay |
| Use voltage | 250 V a.c |
| Maximum current (resistive charge) | 3 A |
| ANALOGUE OUTPUT | |
| Scale | from 0 20 mA or 4 ... 20 mA |
| Maximum acceptable charge | 300 Ω |
| Response time | < 2 s |
| Output range points | 4.000 |

| COMMUNICATIONS | |
|---|---|
| Network protocol | RS-485 |
| Communication protocol | Modbus/RTU |
| Speed (configurable) | 9600, 19200, 38400, 57600 baud |
| Parity | even, odd or no parity |
| Stop bits | 1 or 2 |
| ETHERNET OUTPUT | |
| Network protocol | RJ-45 ETHERNET |
| Communication protocol | Modbus/TCP |
| Speed | 10baseT / 100baseTx compatible |
| ENVIRONMENT | |
| Operating temperature | - 10...+ 40 °C |
| Storage temperature | - 20... + 65°C |
| Relative Humidity | 95% with no condensation |
| Facility category | CAT III in accordance with CEI 61010 |
| Degree of contamination | 2 in accordance with IEC 61010 |
| Protection index | IP51 front - IP20 rear |
| MECHANICAL | |
| Connection | Terminal board with screws for rigid 2.5 mm (4.5 mm ²) or flexible wires (AWG 11) |
| STANDARDS | |
| EMC | 61000-4-2, 61000-4-3, 61000-4-11, 61000-4-4, 61000-4-5 |
|  | Listed for industrial control equipment miscellaneous device. FILE: NMTR E227534 |

| MODEL 405 ACCURACY | (% MEASURE) ± (DIGIT) |
|--------------------|--------------------------------------|
| Currents | ± 0,5% ± 1 from 10% to 120% of I_n |
| Neutral current | ± 0,5% ± 1 from 10% to 120% of I_n |
| Voltages | ± 0,5% ± 1 from 20% to 120% of U_n |
| Active Power P | ± 0,5% ± 1 from 10% to 120% of I_n |
| Reactive Power Q | ± 0,5% from 10% to 120% of I_n |
| Apparent Power S | ± 0,5% from 10% to 120% of I_n |
| Frequency | ± 0,01 Hz from 45 to 65 Hz |
| Active Energy | ± 0,5% |
| Reactive Energy | ± 0,5% |

| MODEL 402 ACCURACY | (% MEASURE) ± (DIGIT) |
|--------------------|---------------------------------------|
| Currents | ± 0,2% ± 2 from 10% to 120% of I_n |
| Neutral current | ± 0,5% ± 1 from 10% to 120% of I_n |
| Voltages | ± 0,2% ± 2 from 20% to 120% of U_n |
| Active Power P | ± 0,2% ± 1 from 10 % to 120% of I_n |
| Reactive Power Q | ± 0,5% from 10% al 120% of I_n |
| Apparent Power S | ± 0,5% from 10% al 120% of I_n |
| Frequency | ± 0,01 Hz from 45 to 65 Hz |
| Active Energy | ± 0,2% |
| Reactive Energy | ± 0,5% |

10.3. OTHER CONCEPTS

The **CVMk2** applies the symmetric components method conceived by Fortescue and Stokvis to make network quality calculations.

This method makes a vector comparison of phasors, taking the phase difference and the module into consideration. It is used for voltage and current alike.

To indicate the degree of imbalance in a system, two coefficients are used.

10.3.1 UNBALANCE COEFFICIENT (KD)

The unbalance coefficient (Kd) is the ratio between the amplitude of the components in the direct and inverse sequence.

$$k_d \% = \frac{|U_i|}{|U_d|} \cdot 100$$


10.3.1 ASYMMETRY COEFFICIENT (KA)

The asymmetry coefficient (Ka) is the ratio between the amplitude of the components in the direct and homopolar sequence. The components of the homopolar sequence are zero if there is not a neutral.

$$k_a \% = \frac{|U_0|}{|U_d|} \cdot 100$$

10.3.3 FLICKER

Flicker is considered to be the low frequency disturbances or variations in amplitude of the voltage between 0.5 and 25 Hz. ($f < 2,500\text{Hz}$). Human eye is sensible to modulated frequency of 8...10 Hz with 0,3 or 0,4% magnitude voltage variations.



The measurement is taken via a parameter known as perceptibility (P).

- For short time frames (10 minutes) it is defined as P_{ST} .

$$\frac{\Delta U}{U}$$

- For long time frames (10 minutes) it is defined as P_{LT} .

$$P_{LT} = \frac{\sqrt[3]{\sum_{i=1}^{12} P_{sti}^3}}{12}$$

A flicker is considered to be perceivable if $P_{ST} > 1$ and $P_{LT} > 0,8$

10.3.4. K FACTOR

The K Factor is considered to be a transformer power reduction factor.

Losses generated by the harmonics are taken into consideration to calculate the K factor.

The unit is always higher to the unit in facilities with non-linear loads.

$$k = \sqrt{1 + \frac{e}{1+e} \cdot \left(\frac{I_1}{I_e}\right)^2 \cdot \sum_{n=2}^{40} n^q \cdot \left(\frac{I_n}{I_1}\right)^2}$$

e: represents the ratio of copper losses and iron losses of the transformer. This value can be obtained from the test data of the transformer or else may be the approximate value of 0.3.


q: exponent value between 1.7 or 1.8.

10.3.5. CREST FACTOR

The Crest Factor is equal to the peak amplitude of the waveform divided by RMS value. The purpose of calculating the crest factor is to give the analyst a quick idea that such an impact is occurring in the waveform. The impact is continually associated with the roller bearing, wear, cavitation and wear of teeth gear, etc.

$$C.F = \frac{U_{pic}}{U_{rms}}$$

The crest factor is an important measure of the state of the machine and is an analysis of the waveform that would be visible only to the calculation of the rate of harmonic distortion.



In a perfect sine wave with an amplitude of "1", the RMS value is equal to 0.707 and the crest factor is then equal to 1.41. A perfect sine wave contains no impacts and therefore the crest factor with a value above 1.41 implies that there is some degree of impact.


11. SOFTWARE

11.1 POWER STUDIO SCADA.

As many other **CIRCUTOR** systems, the **CVMk2** system drivers are managed by the Power Studio and **PowerStudio Scada** energy management software.

<http://powerstudio.circutor.com>

This software makes it possible to constantly communicate with the **CVMk2** network analyzer(s) (as well as with many other analyzer models), and to generate databases in a PC in order to graphically display all the parameters.



All the **CVMk2** parameters can be configured in real time using the **PowerStudio Scada** or **Power Studio**


To integrate **CVMk2** parameters into others Scada is possible to use the OPC Server (special module for the **PowerStudio Scada** or **Power Studio**).

All the **CVMk2** variables can be displayed in real time in the **PowerStudio Scada**. It also displays maximum, minimum and harmonic values for voltage and current.



All the **CVMk2** variables stored in the database can be graphically displayed or displayed in tables and exported to other software.

Power Studio and **PowerStudio Scada** are DDE and XML servers, which allow exporting data and communicating with other programs.



More than 3000 Products

Broken down into 4 solution providing divisions that support the electric energy generation, transport and distribution process



Measuring

Analogue and digital instrumentation, transformers and input signal converters, energy meters, portable and mounted panel network analyzers, management software, etc.



Protection and Control

Industrial earth leakage protection, protection relays, transformer substation measuring and verification equipment, filtering reactances, etc.



Quality & Metering

Electric energy meters for fixing rates, electric power supply quality analyzers and accessories for remote reading.



Compensation for reactive energy and filtering harmonics.

Automatic regulators for reactive energy, Low Voltage and Medium Voltage capacitors, automatic batteries, harmonic filtering equipment, etc.



<http://powerstudio.circutor.com>

Technical Support:

National Meter Industries, Inc. P - 800.325.6674 F - 603.668.2700 email: tech@national-meter.com
www.national-meter.com

NATIONAL

METER

INDUSTRIES